

## **OsmoSGSN VTY Reference**

Copyright © 2013-2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

**COLLABORATORS**

	<i>TITLE :</i> OsmoSGSN VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		September 15, 2022	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v1	13th January 2013	Initial	hw
v2	5th March 2014	Update to match osmo-bsc version 0.13.0-305	hf

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list [with-flags]	2
1.1.5	show running-config	3
1.1.6	show vty-attributes	3
1.1.7	show vty-attributes (application library global)	3
1.1.8	write	4
1.1.9	write file [PATH]	4
1.1.10	write memory	4
1.1.11	write terminal	4
1.2	view	5
1.2.1	bssgp bvc nsei <0-65535> bvci <0-65535> reset	5
1.2.2	enable [expert-mode]	5
1.2.3	logging color (0 1)	6
1.2.4	logging disable	6
1.2.5	logging enable	6
1.2.6	logging filter all (0 1)	7
1.2.7	logging filter bvc nsei <0-65535> bvci <0-65535>	7
1.2.8	logging filter nse nsei <0-65535>	8
1.2.9	logging filter nsvc nsvci <0-65535>	8
1.2.10	logging level (mml pagl meas refl gprs llc sncd pls hcl ranap sua v42bis gt prim lgl ...	9
1.2.11	logging level force-all (debug info notice error fatal)	11
1.2.12	logging level set-all (debug info notice error fatal)	12
1.2.13	logging print category (0 1)	12
1.2.14	logging print category-hex (0 1)	13
1.2.15	logging print extended-timestamp (0 1)	13
1.2.16	logging print file (0 1 basename) [last]	14

1.2.17	logging print level (01)	14
1.2.18	logging print thread-id (01)	15
1.2.19	logging set-log-mask MASK	15
1.2.20	logging timestamp (01)	16
1.2.21	logp (mm pag meas ref gprs llc s ndcp s hcl ranap sua v42bis gt prim l global llapd...	16
1.2.22	no logging level force-all	19
1.2.23	show alarms	19
1.2.24	show asciidoc counters	19
1.2.25	show bssgp	20
1.2.26	show bssgp nsei <0-65535> [stats]	20
1.2.27	show bssgp stats	20
1.2.28	show cpu-sched threads	21
1.2.29	show cs7 (sualm3ualipa) [<0-65534>]	21
1.2.30	show cs7 config	21
1.2.31	show cs7 instance <0-15> as (activelalllm3ualsua)	22
1.2.32	show cs7 instance <0-15> asp	22
1.2.33	show cs7 instance <0-15> route	23
1.2.34	show cs7 instance <0-15> sccp addressbook	23
1.2.35	show cs7 instance <0-15> sccp connections	24
1.2.36	show cs7 instance <0-15> sccp ssn <0-65535>	24
1.2.37	show cs7 instance <0-15> sccp timers	25
1.2.38	show cs7 instance <0-15> sccp users	25
1.2.39	show cs7 instance <0-15> users	26
1.2.40	show history	26
1.2.41	show llc	27
1.2.42	show logging vty	27
1.2.43	show mm-context all [pdp]	27
1.2.44	show mm-context imsi IMSI [pdp]	28
1.2.45	show ns (nseilnsvc) <0-65535> [stats]	28
1.2.46	show ns binds [stats]	29
1.2.47	show ns entities [stats]	29
1.2.48	show ns persistent	29
1.2.49	show online-help	30
1.2.50	show pdp-context all	30
1.2.51	show pid	30
1.2.52	show rate-counters [skip-zero]	31
1.2.53	show sgsn	31
1.2.54	show sndcp	31
1.2.55	show stats [skip-zero]	32

1.2.56	show stats level (global peer subscriber) [skip-zero]	32
1.2.57	show subscriber cache	33
1.2.58	show talloc-context (application global all) (full brief DEPTH)	33
1.2.59	show talloc-context (application global all) (full brief DEPTH) filter REGEXP	34
1.2.60	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS	34
1.2.61	show timer [TNNNN]	35
1.2.62	show uptime	35
1.2.63	show version	36
1.2.64	terminal length <0-512>	36
1.2.65	terminal no length	36
1.2.66	who	37
1.3	enable	37
1.3.1	bssgp bvc nsei <0-65535> bvci <0-65535> reset	37
1.3.2	configure terminal	38
1.3.3	copy running-config startup-config	38
1.3.4	disable	38
1.3.5	logging color (0 1)	39
1.3.6	logging disable	39
1.3.7	logging enable	39
1.3.8	logging filter all (0 1)	40
1.3.9	logging filter bvc nsei <0-65535> bvci <0-65535>	40
1.3.10	logging filter nse nsei <0-65535>	41
1.3.11	logging filter nsvc nsvci <0-65535>	41
1.3.12	logging level (mml pag meas ref gprs llc sncd pls hcl ranap sua v42bis gt prim l glo...	42
1.3.13	logging level force-all (debug info notice error fatal)	44
1.3.14	logging level set-all (debug info notice error fatal)	45
1.3.15	logging print category (0 1)	45
1.3.16	logging print category-hex (0 1)	46
1.3.17	logging print extended-timestamp (0 1)	46
1.3.18	logging print file (0 1 basename) [last]	47
1.3.19	logging print level (0 1)	47
1.3.20	logging print thread-id (0 1)	48
1.3.21	logging set-log-mask MASK	48
1.3.22	logging timestamp (0 1)	49
1.3.23	logp (mml pag meas ref gprs llc sncd pls hcl ranap sua v42bis gt prim l glo...	49
1.3.24	no logging level force-all	52
1.3.25	nsvc <0-65535> (block unblock reset)	52
1.3.26	page imsi IMSI	52
1.3.27	show alarms	53

1.3.28	show asciidoc counters . . . . .	53
1.3.29	show bssgp . . . . .	53
1.3.30	show bssgp nsei <0-65535> [stats] . . . . .	54
1.3.31	show bssgp stats . . . . .	54
1.3.32	show cpu-sched threads . . . . .	54
1.3.33	show cs7 (sualm3ualipa) [<0-65534>] . . . . .	55
1.3.34	show cs7 config . . . . .	55
1.3.35	show cs7 instance <0-15> as (active all m3ualsua) . . . . .	55
1.3.36	show cs7 instance <0-15> asp . . . . .	56
1.3.37	show cs7 instance <0-15> route . . . . .	57
1.3.38	show cs7 instance <0-15> sccp addressbook . . . . .	57
1.3.39	show cs7 instance <0-15> sccp connections . . . . .	58
1.3.40	show cs7 instance <0-15> sccp ssn <0-65535> . . . . .	58
1.3.41	show cs7 instance <0-15> sccp timers . . . . .	59
1.3.42	show cs7 instance <0-15> sccp users . . . . .	59
1.3.43	show cs7 instance <0-15> users . . . . .	60
1.3.44	show history . . . . .	60
1.3.45	show llc . . . . .	60
1.3.46	show logging vty . . . . .	61
1.3.47	show mm-context all [pdp] . . . . .	61
1.3.48	show mm-context imsi IMSI [pdp] . . . . .	61
1.3.49	show ns (nseilnsvc) <0-65535> [stats] . . . . .	62
1.3.50	show ns binds [stats] . . . . .	62
1.3.51	show ns entities [stats] . . . . .	63
1.3.52	show ns persistent . . . . .	63
1.3.53	show online-help . . . . .	63
1.3.54	show pdp-context all . . . . .	64
1.3.55	show rate-counters [skip-zero] . . . . .	64
1.3.56	show sgsn . . . . .	64
1.3.57	show sndcp . . . . .	65
1.3.58	show startup-config . . . . .	65
1.3.59	show stats [skip-zero] . . . . .	65
1.3.60	show stats level (global peer subscriber) [skip-zero] . . . . .	66
1.3.61	show subscriber cache . . . . .	66
1.3.62	show talloc-context (application global all) (full brief DEPTH) . . . . .	67
1.3.63	show talloc-context (application global all) (full brief DEPTH) filter REGEXP . . . . .	67
1.3.64	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS . . . . .	68
1.3.65	show timer [TNNNN] . . . . .	69
1.3.66	show version . . . . .	69

1.3.67	shutdown	69
1.3.68	stats report	69
1.3.69	stats reset	70
1.3.70	terminal length <0-512>	70
1.3.71	terminal monitor	70
1.3.72	terminal no length	71
1.3.73	terminal no monitor	71
1.3.74	update-subscriber imsi IMSI cancel (update-procedurelsupscription-withdraw)	71
1.3.75	update-subscriber imsi IMSI create	72
1.3.76	update-subscriber imsi IMSI destroy	72
1.3.77	update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC	73
1.3.78	update-subscriber imsi IMSI update-auth-info	73
1.3.79	update-subscriber imsi IMSI update-location-result (oklsystem-failureldata-missi...	74
1.3.80	who	74
1.4	config	75
1.4.1	banner motd default	75
1.4.2	banner motd file [FILE]	75
1.4.3	bssgp	75
1.4.4	cpu-sched	76
1.4.5	cs7 instance <0-15>	76
1.4.6	ctrl	76
1.4.7	enable password (8l) WORD	77
1.4.8	enable password LINE	77
1.4.9	hostname WORD	77
1.4.10	line vty	78
1.4.11	log alarms <2-32700>	78
1.4.12	log file FILENAME [blocking-io]	78
1.4.13	log gsmmap [HOSTNAME]	79
1.4.14	log stderr [blocking-io]	79
1.4.15	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	79
1.4.16	log syslog local <0-7>	80
1.4.17	log systemd-journal [raw]	80
1.4.18	no banner motd	81
1.4.19	no enable password	81
1.4.20	no hostname [HOSTNAME]	82
1.4.21	no log alarms	82
1.4.22	no log file FILENAME	82
1.4.23	no log gsmmap [HOSTNAME]	83
1.4.24	no log stderr	83



1.4.25	no log syslog . . . . .	83
1.4.26	no log systemd-journal . . . . .	84
1.4.27	no service advanced-vty . . . . .	84
1.4.28	no service terminal-length [<0-512>] . . . . .	84
1.4.29	no stats reporter log [NAME] . . . . .	85
1.4.30	no stats reporter statsd [NAME] . . . . .	85
1.4.31	ns . . . . .	85
1.4.32	password (8l) WORD . . . . .	86
1.4.33	password LINE . . . . .	86
1.4.34	service advanced-vty . . . . .	86
1.4.35	service terminal-length <0-512> . . . . .	87
1.4.36	sgsn . . . . .	87
1.4.37	show history . . . . .	87
1.4.38	stats interval <0-65535> . . . . .	88
1.4.39	stats reporter log [NAME] . . . . .	88
1.4.40	stats reporter statsd [NAME] . . . . .	88
1.4.41	stats-tcp batch-size <1-65535> . . . . .	89
1.4.42	stats-tcp interval <0-65535> . . . . .	89
1.5	config-log . . . . .	89
1.5.1	logging color (0l1) . . . . .	89
1.5.2	logging filter all (0l1) . . . . .	90
1.5.3	logging filter bvc nsei <0-65535> bvci <0-65535> . . . . .	90
1.5.4	logging filter nse nsei <0-65535> . . . . .	91
1.5.5	logging filter nsvc nsvci <0-65535> . . . . .	91
1.5.6	logging level (mmlpaglmeasreflgrslllclsndcplslhclranaplsualv42bislgtplrimllglo... . . . .	92
1.5.7	logging level force-all (debuglinfofnoticeerrorlfatal) . . . . .	94
1.5.8	logging level set-all (debuglinfofnoticeerrorlfatal) . . . . .	95
1.5.9	logging print category (0l1) . . . . .	96
1.5.10	logging print category-hex (0l1) . . . . .	96
1.5.11	logging print extended-timestamp (0l1) . . . . .	97
1.5.12	logging print file (0l1 basename) [last] . . . . .	97
1.5.13	logging print level (0l1) . . . . .	98
1.5.14	logging print thread-id (0l1) . . . . .	98
1.5.15	logging timestamp (0l1) . . . . .	99
1.5.16	no logging level force-all . . . . .	99
1.6	config-stats . . . . .	99
1.6.1	disable . . . . .	99
1.6.2	enable . . . . .	100
1.6.3	flush-period <0-65535> . . . . .	100

1.6.4	level (globalpeerlsubscriber) . . . . .	100
1.6.5	local-ip ADDR . . . . .	101
1.6.6	mtu <100-65535> . . . . .	101
1.6.7	no local-ip . . . . .	101
1.6.8	no mtu . . . . .	101
1.6.9	no prefix . . . . .	102
1.6.10	prefix PREFIX . . . . .	102
1.6.11	remote-ip ADDR . . . . .	102
1.6.12	remote-port <1-65535> . . . . .	102
1.7	config-line . . . . .	103
1.7.1	bind A.B.C.D [<0-65535>] . . . . .	103
1.7.2	login . . . . .	103
1.7.3	no login . . . . .	103
1.8	config-ns . . . . .	104
1.8.1	bind (frludp) ID . . . . .	104
1.8.2	ip-sns-default bind ID . . . . .	104
1.8.3	no bind ID . . . . .	104
1.8.4	no ip-sns-default bind ID . . . . .	105
1.8.5	no nse <0-65535> . . . . .	105
1.8.6	nse <0-65535> [ip-sns-role-sgsn] . . . . .	105
1.8.7	timer (tns-block tns-block-retries tns-reset tns-reset-retries tns-test tns-aliv... . . . .	106
1.9	config-bssgp . . . . .	107
1.10	config-ctrl . . . . .	107
1.10.1	bind A.B.C.D . . . . .	107
1.11	config-cs7 . . . . .	107
1.11.1	as NAME (sualm3ualipa) . . . . .	107
1.11.2	asp NAME <0-65535> <0-65535> (sualm3ualipa) . . . . .	108
1.11.3	description .TEXT . . . . .	108
1.11.4	network-indicator (international   national   reserved   spare) . . . . .	109
1.11.5	no as NAME . . . . .	109
1.11.6	no asp NAME . . . . .	110
1.11.7	no sccp-address NAME . . . . .	110
1.11.8	point-code POINT_CODE . . . . .	111
1.11.9	point-code delimiter (default dash) . . . . .	111
1.11.10	point-code format <1-24> [<1-23>] [<1-22>] . . . . .	112
1.11.11	point-code format default . . . . .	112
1.11.12	sccp-address NAME . . . . .	113
1.11.13	sccp-timer (conn_est ias iar rellrepeat_rellint guard reset reassembly) <1-99999... . . . .	113
1.11.14	xua rkm routing-key-allocation (static-only dynamic-permitted) . . . . .	114

1.12	config-cs7-as	115
1.12.1	asp NAME	115
1.12.2	description .TEXT	115
1.12.3	no asp NAME	115
1.12.4	no traffic-mode	116
1.12.5	point-code override dpc PC	116
1.12.6	point-code override patch-sccp (disabledlboth)	116
1.12.7	qos-class <0-255>	117
1.12.8	recovery-timeout <1-2000>	117
1.12.9	routing-key RCONTEXT DPC	118
1.12.10	routing-key RCONTEXT DPC si (aal2lbicclb-isuplh248lisuplsat-isuplsccpltup)	118
1.12.11	routing-key RCONTEXT DPC si (aal2lbicclb-isuplh248lisuplsat-isuplsccpltup) ssn S...	119
1.12.12	routing-key RCONTEXT DPC ssn SSN	120
1.12.13	traffic-mode (broadcast   loadshare   roundrobin   override)	121
1.13	config-cs7-asp	121
1.13.1	block	121
1.13.2	description .TEXT	121
1.13.3	local-ip (A.B.C.D X::X::X:X)	122
1.13.4	no quirk (no_notify aud_in_asplnm_inactive)	122
1.13.5	qos-class <0-255>	123
1.13.6	quirk (no_notify aud_in_asplnm_inactive)	123
1.13.7	remote-ip (A.B.C.D X::X::X:X)	124
1.13.8	role (sglasplisp)	124
1.13.9	sctp-role (client server)	125
1.13.10	shutdown	125
1.14	config-cs7-sccpaddr	125
1.14.1	global-title	125
1.14.2	no global-title	126
1.14.3	no point-code	126
1.14.4	no subsystem-number	126
1.14.5	point-code POINT_CODE	127
1.14.6	routing-indicator (GT PC IP)	127
1.14.7	subsystem-number <0-4294967295>	128
1.15	config-cs7-sccpaddr-gt	128
1.15.1	digits DIGITS	128
1.15.2	global-title-indicator <0-15>	128
1.15.3	nature-of-address-indicator <0-127>	129
1.15.4	numbering-plan-indicator <0-15>	129
1.15.5	translation-type <0-255>	130

1.16	config-cpu-sched . . . . .	130
1.16.1	cpu-affinity (self all <0-4294967295> THREADNAME) CPUHEXMASK [delay] . . . . .	130
1.16.2	policy rr <1-32> . . . . .	131
1.17	config-ns-bind . . . . .	131
1.17.1	accept-dynamic-ip-sns . . . . .	131
1.17.2	accept-ipaccess . . . . .	131
1.17.3	dscp <0-63> . . . . .	132
1.17.4	fr NETIF (fr frnet) . . . . .	132
1.17.5	ip-sns signalling-weight <0-254> data-weight <0-254> . . . . .	132
1.17.6	listen (A.B.C.D X:X::X:X) <1-65535> . . . . .	133
1.17.7	no accept-dynamic-ip-sns . . . . .	133
1.17.8	no accept-ipaccess . . . . .	133
1.17.9	no dscp . . . . .	134
1.17.10	no fr NETIF . . . . .	134
1.17.11	no listen . . . . .	134
1.17.12	socket-priority <0-255> . . . . .	135
1.18	config-ns-nse . . . . .	135
1.18.1	ip-sns-bind BINDID . . . . .	135
1.18.2	ip-sns-remote (A.B.C.D X:X::X:X) <1-65535> . . . . .	135
1.18.3	no ip-sns-bind BINDID . . . . .	136
1.18.4	no ip-sns-remote (A.B.C.D X:X::X:X) <1-65535> . . . . .	136
1.18.5	no nsvc fr NETIF dlci <16-1007> . . . . .	136
1.18.6	no nsvc ipa BIND (A.B.C.D X:X::X:X) <1-65535> nsvci <0-65535> . . . . .	137
1.18.7	no nsvc nsvci <0-65535> . . . . .	138
1.18.8	no nsvc udp BIND (A.B.C.D X:X::X:X) <1-65535> . . . . .	138
1.18.9	nsvc fr NETIF dlci <16-1007> nsvci <0-65535> . . . . .	139
1.18.10	nsvc ipa BIND (A.B.C.D X:X::X:X) <1-65535> nsvci <0-65535> . . . . .	139
1.18.11	nsvc udp BIND (A.B.C.D X:X::X:X) <1-65535> . . . . .	140
1.18.12	nsvc udp BIND (A.B.C.D X:X::X:X) <1-65535> signalling-weight <0-254> data-weight... . . . .	140
1.19	config-sgsn . . . . .	141
1.19.1	access-point-name NAME . . . . .	141
1.19.2	apn APNAME ggsn <0-255> . . . . .	141
1.19.3	apn APNAME imsi-prefix IMSIPRE ggsn <0-255> . . . . .	142
1.19.4	asn1 debug (1 0) . . . . .	142
1.19.5	asn1 xer-print (1 0) . . . . .	143
1.19.6	auth-policy (accept-all closed acl-only remote) . . . . .	143
1.19.7	authentication (optional required) . . . . .	144
1.19.8	cdr filename NAME . . . . .	144
1.19.9	cdr interval <1-2147483647> . . . . .	144

1.19.10 cdr trap . . . . .	145
1.19.11 compression rfc1144 active slots <1-256> . . . . .	145
1.19.12 compression rfc1144 passive . . . . .	145
1.19.13 compression v42bis active direction (mslsgsnlboth) codewords <512-65535> strlen ... . . . .	146
1.19.14 compression v42bis passive . . . . .	146
1.19.15 cs7-instance-iu <0-15> . . . . .	147
1.19.16 encryption gea <0-4> [<0-4>] [<0-4>] [<0-4>] [<0-4>] . . . . .	147
1.19.17 encryption uea <0-2> [<0-2>] [<0-2>] . . . . .	147
1.19.18 ggsn <0-255> echo-interval <1-36000> . . . . .	148
1.19.19 ggsn <0-255> gtp-version (0 1) . . . . .	148
1.19.20 ggsn <0-255> no echo-interval . . . . .	149
1.19.21 ggsn <0-255> remote-ip A.B.C.D . . . . .	149
1.19.22 ggsn dynamic . . . . .	149
1.19.23 grx-dns-add A.B.C.D . . . . .	150
1.19.24 gsup ipa-name NAME . . . . .	150
1.19.25 gsup oap-id <0-65535> . . . . .	150
1.19.26 gsup oap-k K . . . . .	151
1.19.27 gsup oap-opc OPC . . . . .	151
1.19.28 gsup remote-ip A.B.C.D . . . . .	151
1.19.29 gsup remote-port <0-65535> . . . . .	152
1.19.30 gtp local-ip A.B.C.D . . . . .	152
1.19.31 gtp state-dir PATH . . . . .	152
1.19.32 imsi-acl (add del) IMSI . . . . .	153
1.19.33 iu rab-assign-addr-enc (x213 v4raw) . . . . .	153
1.19.34 mme NAME . . . . .	153
1.19.35 no access-point-name NAME . . . . .	154
1.19.36 no cdr filename . . . . .	154
1.19.37 no cdr trap . . . . .	154
1.19.38 no compression rfc1144 . . . . .	155
1.19.39 no compression v42bis . . . . .	155
1.19.40 no mme NAME . . . . .	155
1.19.41 timer [TNNNN] [(<0-2147483647> default)] . . . . .	156
1.20 config-sgsn-mme . . . . .	156
1.20.1 gtp ran-info-relay <0-999> <0-999> <0-65535> . . . . .	156
1.20.2 gtp ran-info-relay default . . . . .	157
1.20.3 gtp remote-ip A.B.C.D . . . . .	157
1.20.4 no gtp ran-info-relay <0-999> <0-999> <0-65535> . . . . .	157
1.20.5 no gtp ran-info-relay default . . . . .	158

# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

## Chapter 1

# VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list [with-flags]

#### Command

```
list [with-flags]
```

#### Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

---



### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.1.6 show vty-attributes

#### Command

```
show vty-attributes
```

#### Parameters

show

Show running system information

vty-attributes

List of VTY attributes

### 1.1.7 show vty-attributes (application|library|global)

#### Command

```
show vty-attributes (application|library|global)
```

#### Parameters

show

Show running system information

vty-attributes

List of VTY attributes

application

Application specific attributes only

library

Library specific attributes only

global

Global attributes only

---

### 1.1.8 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.1.9 write file [PATH]

#### Command

```
write file [PATH]
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

### 1.1.10 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.1.11 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 bssgp bvc nsei <0-65535> bvci <0-65535> reset

#### Command

```
bssgp bvc nsei <0-65535> bvci <0-65535> reset
```

#### Parameters

##### bssgp

Initiate BVC RESET procedure for a given NSEI and BVCI

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

##### <0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

##### <0-65535>

BSSGP Virtual Connection Identifier (BVCI)

##### reset

Perform reset procedure

### 1.2.2 enable [expert-mode]

#### Command

```
enable [expert-mode]
```

#### Parameters

##### enable

Turn on privileged mode command

##### [expert-mode]

Enable the expert mode (show hidden commands)

### 1.2.3 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.4 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.2.5 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

---

### 1.2.6 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.2.7 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

##### <0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

##### <0-65535>

BSSGP Virtual Connection Identifier (BVCI)

---

### 1.2.8 logging filter nse nsei <0-65535>

#### Command

```
logging filter nse nsei <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nse

Filter based on NS Entity

##### nsei

Identify NSE by NSEI

##### <0-65535>

Numeric identifier

### 1.2.9 logging filter nsvc nsvci <0-65535>

#### Command

```
logging filter nsvc nsvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nsvc

Filter based on NS Virtual Connection

##### nsvci

Identify NS-VC by NSVCI

##### <0-65535>

Numeric identifier

### 1.2.10 logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglo...

#### Command

```
logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal| ↵  
             llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua| ↵  
             lmgcp|ljibuf|lrspro|lns|lbssgp|lndata|lnssignal|liuup|lpfcp) (debug|info|notice| ↵  
             error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

##### slhc

RFC1144 TCP/IP Header compression (SLHC)

##### ranap

RAN Application Part (RANAP)

##### sua

SCCP User Adaptation (SUA)

##### v42bis

V.42bis data compression (SND CP)

##### gtp

GPRS Tunnelling Protocol (GTP)

##### rim

RAN Information Management (RIM)

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

---



lms

GPRS NS layer

lbssgp

GPRS BSSGP layer

lmsdata

GPRS NS layer data PDU

lmsignal

GPRS NS layer signal PDU

liuup

Iu UP layer

lpfcp

libosmo-pfcp Packet Forwarding Control Protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.11 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.12 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.13 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

---

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

#### 1.2.14 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

#### 1.2.15 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

#### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.16 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.17 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.2.18 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.2.19 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.20 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.21 logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal|llapd...

#### Command

```
logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal|llapd|linp| ↵
    lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf| ↵
    lrspro|lms|lbssgp|lmsdata|lmsignal|liuup|lpfcp) (debug|info|notice|error|fatal) . ↵
    LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

slhc  
RFC1144 TCP/IP Header compression (SLHC)

ranap  
RAN Application Part (RANAP)

sua  
SCCP User Adaptation (SUA)

v42bis  
V.42bis data compression (SNDTCP)

gtp  
GPRS Tunnelling Protocol (GTP)

rim  
RAN Information Management (RIM)

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

---

lscpp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnssignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

---



### 1.2.22 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.23 show alarms

#### Command

```
show alarms
```

#### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.24 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

---

### 1.2.25 show bssgp

#### Command

```
show bssgp
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

### 1.2.26 show bssgp nsei <0-65535> [stats]

#### Command

```
show bssgp nsei <0-65535> [stats]
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

nsei

Show all BVCs on one NSE

<0-65535>

The NSEI

[stats]

Include Statistics

### 1.2.27 show bssgp stats

#### Command

```
show bssgp stats
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

stats

Include statistics

### 1.2.28 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.2.29 show cs7 (sua|m3ua|ipa) [<0-65534>]

#### Command

```
show cs7 (sua|m3ua|ipa) [<0-65534>]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

[<0-65534>]

Port Number

### 1.2.30 show cs7 config

#### Command

```
show cs7 config
```

#### Parameters

---

show

Show running system information

cs7

ITU-T Signaling System 7

config

Currently running cs7 configuration

### 1.2.31 show cs7 instance <0-15> as (active|all|m3ua|sua)

Command

```
show cs7 instance <0-15> as (active|all|m3ua|sua)
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

as

Application Server (AS)

active

Display all active ASs

all

Display all ASs (default)

m3ua

Display all m3ua ASs

sua

Display all SUA ASs

### 1.2.32 show cs7 instance <0-15> asp

Command

```
show cs7 instance <0-15> asp
```

Parameters

---

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

asp

Application Server Process (ASP)

### 1.2.33 show cs7 instance <0-15> route

Command

```
show cs7 instance <0-15> route
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

route

Routing Table

### 1.2.34 show cs7 instance <0-15> sccp addressbook

Command

```
show cs7 instance <0-15> sccp addressbook
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

addressbook

List all SCCP addressbook entries

### 1.2.35 show cs7 instance <0-15> sccp connections

Command

```
show cs7 instance <0-15> sccp connections
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

connections

Show List of active SCCP connections

### 1.2.36 show cs7 instance <0-15> sccp ssn <0-65535>

Command

```
show cs7 instance <0-15> sccp ssn <0-65535>
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

ssn

Find an SCCP User registered for the given SSN

<0-65535>

Subsystem Number (SSN)

### 1.2.37 show cs7 instance <0-15> sccp timers

Command

```
show cs7 instance <0-15> sccp timers
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signaling Connection Control Part

timers

Show List of SCCP timers

### 1.2.38 show cs7 instance <0-15> sccp users

Command

```
show cs7 instance <0-15> sccp users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

users

Show List of SCCP Users registered

### 1.2.39 show cs7 instance <0-15> users

Command

```
show cs7 instance <0-15> users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

users

User Table

### 1.2.40 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history



### 1.2.41 show llc

#### Command

```
show llc
```

#### Parameters

##### show

Show running system information

##### llc

Display information about the LLC protocol

### 1.2.42 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

### 1.2.43 show mm-context all [pdp]

#### Command

```
show mm-context all [pdp]
```

#### Parameters

##### show

Show running system information

##### mm-context

MM Context

##### all

All MM Contexts

##### [pdp]

Include PDP Context Information

---

### 1.2.44 show mm-context imsi IMSI [pdp]

#### Command

```
show mm-context imsi IMSI [pdp]
```

#### Parameters

show

Show running system information

mm-context

MM Context

imsi

Identify by IMSI

IMSI

IMSI of the MM Context

[pdp]

Include PDP Context Information

### 1.2.45 show ns (nsei|nsvc) <0-65535> [stats]

#### Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

### 1.2.46 show ns binds [stats]

#### Command

```
show ns binds [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

binds

Display information about the NS protocol binds

[stats]

Include statistic

### 1.2.47 show ns entities [stats]

#### Command

```
show ns entities [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

entities

Display information about the NS protocol entities (NSEs)

[stats]

Include statistics

### 1.2.48 show ns persistent

#### Command

```
show ns persistent
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

### 1.2.49 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.2.50 show pdp-context all

#### Command

```
show pdp-context all
```

#### Parameters

##### show

Show running system information

##### pdp-context

Display information on PDP Context

##### all

Show everything

### 1.2.51 show pid

#### Command

```
show pid
```

#### Parameters

##### show

Show running system information

##### pid

Displays the process ID

### 1.2.52 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

[skip-zero]

Skip items with total count zero

### 1.2.53 show sgsn

#### Command

```
show sgsn
```

#### Parameters

show

Show running system information

sgsn

Display information about the SGSN

### 1.2.54 show sndcp

#### Command

```
show sndcp
```

#### Parameters

show

Show running system information

sndcp

Display information about the SNDTCP protocol

### 1.2.55 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### [skip-zero]

Skip items with total count zero

### 1.2.56 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### level

Set the maximum group level

##### global

Show global groups only

##### peer

Show global and network peer related groups

##### subscriber

Show global, peer, and subscriber groups

##### [skip-zero]

Skip items with total count zero

---

### 1.2.57 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

##### show

Show running system information

##### subscriber

Show information about subscribers

##### cache

Display contents of subscriber cache

### 1.2.58 show talloc-context (application|global|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### global

Global context (OTC\_GLOBAL)

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

---

### 1.2.59 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### global

Global context (OTC\_GLOBAL)

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### filter

Filter chunks using regular expression

##### REGEXP

Regular expression

### 1.2.60 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context



global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.2.61 show timer [TNNNN]

Command

```
show timer [TNNNN]
```

Parameters

show

Show running system information

timer

Show timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.62 show uptime

Command

```
show uptime
```

Parameters

show

Show running system information

uptime

Displays how long the program has been running

### 1.2.63 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.2.64 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.65 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

---

## 1.2.66 who

### Command

```
who
```

### Parameters

who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

### 1.3.1 bssgp bvc nsei <0-65535> bvci <0-65535> reset

### Command

```
bssgp bvc nsei <0-65535> bvci <0-65535> reset
```

### Parameters

bssgp

Initiate BVC RESET procedure for a given NSEI and BVCI

bvc

Filter based on BSSGP Virtual Connection

nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

reset

Perform reset procedure

### 1.3.2 configure terminal

#### Command

```
configure terminal
```

#### Parameters

##### configure

Configuration from vty interface

##### terminal

Configuration terminal

### 1.3.3 copy running-config startup-config

#### Command

```
copy running-config startup-config
```

#### Parameters

##### copy

Copy configuration

##### running-config

Copy running config to...

##### startup-config

Copy running config to startup config (same as write file)

### 1.3.4 disable

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

### 1.3.5 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.3.6 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.7 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

---

### 1.3.8 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.3.9 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

##### <0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

##### <0-65535>

BSSGP Virtual Connection Identifier (BVCI)

---

### 1.3.10 logging filter nse nsei <0-65535>

#### Command

```
logging filter nse nsei <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nse

Filter based on NS Entity

##### nsei

Identify NSE by NSEI

##### <0-65535>

Numeric identifier

### 1.3.11 logging filter nsvc nsvci <0-65535>

#### Command

```
logging filter nsvc nsvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nsvc

Filter based on NS Virtual Connection

##### nsvci

Identify NS-VC by NSVCI

##### <0-65535>

Numeric identifier

### 1.3.12 logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglo...

#### Command

```
logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal| ↵  
             llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua| ↵  
             lmgcp|ljibuf|lrspro|lns|lbssgp|lndata|lnssignal|liuup|lpfcp) (debug|info|notice| ↵  
             error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

##### slhc

RFC1144 TCP/IP Header compression (SLHC)

##### ranap

RAN Application Part (RANAP)

##### sua

SCCP User Adaptation (SUA)

##### v42bis

V.42bis data compression (SND CP)

##### gtp

GPRS Tunnelling Protocol (GTP)

##### rim

RAN Information Management (RIM)



lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

---

lms	
lms	GPRS NS layer
lbssgp	
lbssgp	GPRS BSSGP layer
lmsdata	
lmsdata	GPRS NS layer data PDU
lmsignal	
lmsignal	GPRS NS layer signal PDU
liuup	
liuup	Iu UP layer
lpfcp	
lpfcp	libosmo-pfcp Packet Forwarding Control Protocol
debug	
debug	Log debug messages and higher levels
info	
info	Log informational messages and higher levels
notice	
notice	Log noticeable messages and higher levels
error	
error	Log error messages and higher levels
fatal	
fatal	Log only fatal messages

### 1.3.13 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

##### debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.14 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.15 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

---

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.3.16 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.17 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

#### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.18 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.19 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.3.20 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.3.21 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.22 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.3.23 logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal|llapd...

#### Command

```
logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal|llapd|linp| ↵
    lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf| ↵
    lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp) (debug|info|notice|error|fatal) . ↵
    LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

slhc  
RFC1144 TCP/IP Header compression (SLHC)

ranap  
RAN Application Part (RANAP)

sua  
SCCP User Adaptation (SUA)

v42bis  
V.42bis data compression (SNDTCP)

gtp  
GPRS Tunnelling Protocol (GTP)

rim  
RAN Information Management (RIM)

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7



---

lscpp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnssignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

---

### 1.3.24 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.25 nsvc <0-65535> (block|unblock|reset)

#### Command

```
nsvc <0-65535> (block|unblock|reset)
```

#### Parameters

nsvc

NS Virtual Connection

<0-65535>

NS Virtual Connection ID (NS-VCI)

block

Block a NSVC. As cause code O&M intervention will be used.

unblock

Unblock a NSVC. As cause code O&M intervention will be used.

reset

Reset a NSVC. As cause code O&M intervention will be used.

### 1.3.26 page imsi IMSI

#### Command

```
page imsi IMSI
```

#### Parameters

---

page

Send a PS paging request to subscriber

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

### 1.3.27 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.3.28 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.3.29 show bssgp

Command

```
show bssgp
```

Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

### 1.3.30 show bssgp nsei <0-65535> [stats]

#### Command

```
show bssgp nsei <0-65535> [stats]
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

nsei

Show all BVCs on one NSE

<0-65535>

The NSEI

[stats]

Include Statistics

### 1.3.31 show bssgp stats

#### Command

```
show bssgp stats
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

stats

Include statistics

### 1.3.32 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

---

### 1.3.33 show cs7 (sua|m3ua|ipa) [<0-65534>]

#### Command

```
show cs7 (sua|m3ua|ipa) [<0-65534>]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

[<0-65534>]

Port Number

### 1.3.34 show cs7 config

#### Command

```
show cs7 config
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

config

Currently running cs7 configuration

### 1.3.35 show cs7 instance <0-15> as (active|all|m3ua|sua)

#### Command

```
show cs7 instance <0-15> as (active|all|m3ua|sua)
```

#### Parameters

---

show  
    Show running system information

cs7  
    ITU-T Signaling System 7

instance  
    An instance of the SS7 stack

<0-15>  
    An instance of the SS7 stack

as  
    Application Server (AS)

active  
    Display all active ASs

all  
    Display all ASs (default)

m3ua  
    Display all m3ua ASs

sua  
    Display all SUA ASs

### 1.3.36 show cs7 instance <0-15> asp

#### Command

```
show cs7 instance <0-15> asp
```

#### Parameters

show  
    Show running system information

cs7  
    ITU-T Signaling System 7

instance  
    An instance of the SS7 stack

<0-15>  
    An instance of the SS7 stack

asp  
    Application Server Process (ASP)

### 1.3.37 show cs7 instance <0-15> route

#### Command

```
show cs7 instance <0-15> route
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

route

Routing Table

### 1.3.38 show cs7 instance <0-15> sccp addressbook

#### Command

```
show cs7 instance <0-15> sccp addressbook
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

addressbook

List all SCCP addressbook entries

---

### 1.3.39 show cs7 instance <0-15> sccp connections

#### Command

```
show cs7 instance <0-15> sccp connections
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

connections

Show List of active SCCP connections

### 1.3.40 show cs7 instance <0-15> sccp ssn <0-65535>

#### Command

```
show cs7 instance <0-15> sccp ssn <0-65535>
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

ssn

Find an SCCP User registered for the given SSN

<0-65535>

Subsystem Number (SSN)

---



### 1.3.41 show cs7 instance <0-15> sccp timers

#### Command

```
show cs7 instance <0-15> sccp timers
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signaling Connection Control Part

timers

Show List of SCCP timers

### 1.3.42 show cs7 instance <0-15> sccp users

#### Command

```
show cs7 instance <0-15> sccp users
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

users

Show List of SCCP Users registered

### 1.3.43 show cs7 instance <0-15> users

#### Command

```
show cs7 instance <0-15> users
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

users

User Table

### 1.3.44 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.3.45 show llc

#### Command

```
show llc
```

#### Parameters

show

Show running system information

llc

Display information about the LLC protocol

---

### 1.3.46 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

### 1.3.47 show mm-context all [pdp]

#### Command

```
show mm-context all [pdp]
```

#### Parameters

##### show

Show running system information

##### mm-context

MM Context

##### all

All MM Contexts

##### [pdp]

Include PDP Context Information

### 1.3.48 show mm-context imsi IMSI [pdp]

#### Command

```
show mm-context imsi IMSI [pdp]
```

#### Parameters

##### show

Show running system information

##### mm-context

MM Context

---

imsi

Identify by IMSI

IMSI

IMSI of the MM Context

[pdp]

Include PDP Context Information

### 1.3.49 show ns (nsei|nsvc) <0-65535> [stats]

Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

### 1.3.50 show ns binds [stats]

Command

```
show ns binds [stats]
```

Parameters

show

Show running system information

ns

Display information about the NS protocol

binds

Display information about the NS protocol binds

[stats]

Include statistic

### 1.3.51 show ns entities [stats]

#### Command

```
show ns entities [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

entities

Display information about the NS protocol entities (NSEs)

[stats]

Include statistics

### 1.3.52 show ns persistent

#### Command

```
show ns persistent
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

### 1.3.53 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.3.54 show pdp-context all

#### Command

```
show pdp-context all
```

#### Parameters

##### show

Show running system information

##### pdp-context

Display information on PDP Context

##### all

Show everything

### 1.3.55 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

##### [skip-zero]

Skip items with total count zero

### 1.3.56 show sgsn

#### Command

```
show sgsn
```

#### Parameters

##### show

Show running system information

##### sgsn

Display information about the SGSN

---

### 1.3.57 show sndcp

#### Command

```
show sndcp
```

#### Parameters

##### show

Show running system information

##### sndcp

Display information about the SNDTCP protocol

### 1.3.58 show startup-config

#### Command

```
show startup-config
```

#### Parameters

##### show

Show running system information

##### startup-config

Contentes of startup configuration

### 1.3.59 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### [skip-zero]

Skip items with total count zero

---

### 1.3.60 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### level

Set the maximum group level

##### global

Show global groups only

##### peer

Show global and network peer related groups

##### subscriber

Show global, peer, and subscriber groups

##### [skip-zero]

Skip items with total count zero

### 1.3.61 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

##### show

Show running system information

##### subscriber

Show information about subscribers

##### cache

Display contents of subscriber cache



### 1.3.62 show talloc-context (application|global|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### global

Global context (OTC\_GLOBAL)

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

### 1.3.63 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### global

Global context (OTC\_GLOBAL)

##### all

All contexts, if NULL-context tracking is enabled

---

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

### 1.3.64 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.3.65 show timer [TNNNN]

#### Command

```
show timer [TNNNN]
```

#### Parameters

show

Show running system information

timer

Show timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.3.66 show version

#### Command

```
show version
```

#### Parameters

show

Show running system information

version

Displays program version

### 1.3.67 shutdown

#### Command

```
shutdown
```

#### Parameters

shutdown

Request a shutdown of the program

### 1.3.68 stats report

#### Command

```
stats report
```

#### Parameters

stats

Stats related commands

report

Manurally trigger reporting of stats

---

### 1.3.69 stats reset

#### Command

```
stats reset
```

#### Parameters

##### stats

Stats related commands

##### reset

Reset all rate counter stats

### 1.3.70 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.3.71 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.72 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.3.73 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.3.74 update-subscriber imsi IMSI cancel (update-procedure|subscription-withdraw)

#### Command

```
update-subscriber imsi IMSI cancel (update-procedure|subscription-withdraw)
```

#### Parameters

##### update-subscriber

Update subscriber list

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

---

cancel

Cancel (remove) subscriber record

update-procedure

The MS moved to another SGSN

subscription-withdraw

The subscription is no longer valid

### 1.3.75 update-subscriber imsi IMSI create

Command

```
update-subscriber imsi IMSI create
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

create

Create a subscriber entry

### 1.3.76 update-subscriber imsi IMSI destroy

Command

```
update-subscriber imsi IMSI destroy
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

destroy

Destroy a subscriber entry

---

### 1.3.77 update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC

#### Command

```
update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC
```

#### Parameters

##### update-subscriber

Update subscriber list

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

##### insert

Insert data into the subscriber record

##### auth-triplet

Update authentication triplet

##### <1-5>

Triplet index

##### sres

Set SRES value

##### SRES

SRES value (4 byte) in hex

##### rand

Set RAND value

##### RAND

RAND value (16 byte) in hex

##### kc

Set Kc value

##### KC

Kc value (8 byte) in hex

### 1.3.78 update-subscriber imsi IMSI update-auth-info

#### Command

```
update-subscriber imsi IMSI update-auth-info
```

#### Parameters

##### update-subscriber

Update subscriber list

---

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

update-auth-info

Complete the send authentication info procedure

### 1.3.79 update-subscriber imsi IMSI update-location-result (ok|system-failure|data-missi...

Command

```
update-subscriber imsi IMSI update-location-result (ok|system-failure|data-missing| ←  
unexpected-data-value|unknown-subscriber|roaming-not-allowed)
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

update-location-result

Complete the update location procedure

ok

The update location request succeeded

system-failure

Force error code SystemFailure

data-missing

Force error code DataMissing

unexpected-data-value

Force error code UnexpectedDataValue

unknown-subscriber

Force error code UnknownSubscriber

roaming-not-allowed

Force error code RoamingNotAllowed

### 1.3.80 who

Command

```
who
```

Parameters

who

Display who is on vty



## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

### 1.4.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

##### banner

Set banner

##### motd

Banner for motd

##### file

Banner from a file

##### [FILE]

Filename

### 1.4.3 bssgp

#### Command

```
bssgp
```

#### Parameters

##### bssgp

Configure the GPRS BSS Gateway Protocol

### 1.4.4 cpu-sched

#### Command

```
cpu-sched
```

#### Parameters

cpu-sched

Configure CPU Scheduler related settings

### 1.4.5 cs7 instance <0-15>

#### Command

```
cs7 instance <0-15>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cs7

ITU-T Signaling System 7

instance

Configure a SS7 Instance

<0-15>

An instance of the SS7 stack

### 1.4.6 ctrl

#### Command

```
ctrl
```

#### Parameters

ctrl

Configure the Control Interface

### 1.4.7 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN 'enable' password string

### 1.4.8 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.9 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

---

### 1.4.10 line vty

#### Command

```
line vty
```

#### Parameters

line

Configure a terminal line

vtty

Virtual terminal

### 1.4.11 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.12 log file FILENAME [blocking-io]

#### Command

```
log file FILENAME [blocking-io]
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

[blocking-io]

Use blocking, synchronous I/O

---

### 1.4.13 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.14 log stderr [blocking-io]

#### Command

```
log stderr [blocking-io]
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

[blocking-io]

Use blocking, synchronous I/O

### 1.4.15 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

#### 1.4.16 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

#### 1.4.17 log systemd-journal [raw]

Command

```
log systemd-journal [raw]
```

Parameters

---

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

[raw]

Offload rendering of the meta information (location, category) to systemd

### 1.4.18 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.4.19 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.20 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.21 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.22 no log file FILENAME

#### Command

```
no log file FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

---



### 1.4.23 no log gsmtap [HOSTNAME]

#### Command

```
no log gsmtap [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.24 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.25 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.26 no log systemd-journal

#### Command

```
no log systemd-journal
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

### 1.4.27 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.28 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

---

### 1.4.29 no stats reporter log [NAME]

#### Command

```
no stats reporter log [NAME]
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.30 no stats reporter statsd [NAME]

#### Command

```
no stats reporter statsd [NAME]
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

### 1.4.31 ns

#### Command

```
ns
```

#### Parameters

ns

Configure the GPRS Network Service

---

### 1.4.32 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

##### password

Assign the terminal connection password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN line password string

### 1.4.33 password LINE

#### Command

```
password LINE
```

#### Parameters

##### password

Assign the terminal connection password

##### LINE

The UNENCRYPTED (cleartext) line password

### 1.4.34 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

---

### 1.4.35 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

### 1.4.36 sgsn

#### Command

```
sgsn
```

#### Parameters

##### sgsn

Configure the SGSN

### 1.4.37 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.38 stats interval <0-65535>

#### Command

```
stats interval <0-65535>
```

#### Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<0-65535>

Interval in seconds (0 disables the reporting interval)

### 1.4.39 stats reporter log [NAME]

#### Command

```
stats reporter log [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.40 stats reporter statsd [NAME]

#### Command

```
stats reporter statsd [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

---

### 1.4.41 stats-tcp batch-size <1-65535>

#### Command

```
stats-tcp batch-size <1-65535>
```

#### Parameters

##### stats-tcp

Configure stats sub-system

##### batch-size

Set the number of tcp sockets that are processed per stats polling interval

<1-65535>

Number of sockets per interval

### 1.4.42 stats-tcp interval <0-65535>

#### Command

```
stats-tcp interval <0-65535>
```

#### Parameters

##### stats-tcp

Configure stats sub-system

##### interval

Set the tcp socket stats polling interval

<0-65535>

Interval in seconds (0 disables the polling interval)

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

---

## logging

Configure logging

## color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

## logging

Configure logging

## filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.5.3 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

## logging

Configure logging



filter

Filter log messages

bvc

Filter based on BSSGP Virtual Connection

nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

#### 1.5.4 logging filter nse nsei <0-65535>

Command

```
logging filter nse nsei <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nse

Filter based on NS Entity

nsei

Identify NSE by NSEI

<0-65535>

Numeric identifier

#### 1.5.5 logging filter nsvc nsvci <0-65535>

Command

```
logging filter nsvc nsvci <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nsvc

Filter based on NS Virtual Connection

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

## 1.5.6 logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglo...

Command

```
logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|lglobal| ↵
llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua| ↵
lmgcp|ljibuf|lrspro|lms|lbssgp|lmsdata|lmsignal|liuup|lpfcp) (debug|info|notice| ↵
error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

mm

Layer3 Mobility Management (MM)

pag

Paging Subsystem

meas

Radio Measurement Processing

ref

Reference Counting

gprs

GPRS Packet Service

llc

GPRS Logical Link Control Protocol (LLC)

sndcp

GPRS Sub-Network Dependent Control Protocol (SNDP)

slhc

RFC1144 TCP/IP Header compression (SLHC)

ranap

RAN Application Part (RANAP)

---

sua  
    SCCP User Adaptation (SUA)

v42bis  
    V.42bis data compression (SNDTCP)

gtp  
    GPRS Tunnelling Protocol (GTP)

rim  
    RAN Information Management (RIM)

lglobal  
    Library-internal global log family

llapd  
    LAPD in libosmogsm

linp  
    A-bis Input Subsystem

lmux  
    A-bis B-Subchannel TRAU Frame Multiplex

lmi  
    A-bis Input Driver for Signalling

lmib  
    A-bis Input Driver for B-Channels (voice)

lsms  
    Layer3 Short Message Service (SMS)

lctrl  
    Control Interface

lgtp  
    GPRS GTP library

lstats  
    Statistics messages and logging

lgsup  
    Generic Subscriber Update Protocol

loap  
    Osmocom Authentication Protocol

lss7  
    libosmo-sigtran Signalling System 7

lsccp  
    libosmo-sigtran SCCP Implementation

lsua  
    libosmo-sigtran SCCP User Adaptation

---

lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol
ljibuf	libosmo-netif Jitter Buffer
lrspro	Remote SIM protocol
lns	GPRS NS layer
lbssgp	GPRS BSSGP layer
lndata	GPRS NS layer data PDU
lnsignal	GPRS NS layer signal PDU
liuup	Iu UP layer
lpfcp	libosmo-pfcp Packet Forwarding Control Protocol
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

### 1.5.7 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

#### level

Set the log level for a specified category

#### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

#### debug

Log debug messages and higher levels

#### info

Log informational messages and higher levels

#### notice

Log noticeable messages and higher levels

#### error

Log error messages and higher levels

#### fatal

Log only fatal messages

### 1.5.8 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

---

### 1.5.9 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.5.10 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.12 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.13 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.14 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID



### 1.5.15 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.16 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

#### Command

```
disable
```

#### Parameters

##### disable

Disable the reporter

---

### 1.6.2 enable

#### Command

```
enable
```

#### Parameters

enable

Enable the reporter

### 1.6.3 flush-period <0-65535>

#### Command

```
flush-period <0-65535>
```

#### Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush) every N-th reporting interval. Set to 0 to disable regular flush (default).

### 1.6.4 level (global|peer|subscriber)

#### Command

```
level (global|peer|subscriber)
```

#### Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

---

### 1.6.5 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.6 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

### 1.6.7 no local-ip

#### Command

```
no local-ip
```

#### Parameters

##### no

Negate a command or set its defaults

##### local-ip

Set the IP address to which we bind locally

### 1.6.8 no mtu

#### Command

```
no mtu
```

#### Parameters

##### no

Negate a command or set its defaults

##### mtu

Set the maximum packet size

---

### 1.6.9 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.10 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.11 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

### 1.6.12 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

---

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

### 1.7.2 login

#### Command

```
login
```

#### Parameters

login

Enable password checking

### 1.7.3 no login

#### Command

```
no login
```

#### Parameters

no

Negate a command or set its defaults

login

Enable password checking

## 1.8 config-ns

### 1.8.1 bind (fr|udp) ID

Command

```
bind (fr|udp) ID
```

Parameters

bind

Configure local Bind

fr

Frame Relay

udp

UDP/IP

ID

Unique identifier for this bind (to reference from NS-VCs, NSEs, ...)

### 1.8.2 ip-sns-default bind ID

Command

```
ip-sns-default bind ID
```

Parameters

ip-sns-default

Defaults for dynamically created NSEs created by IP-SNS in SGSN role

bind

IP SNS binds

ID

Name of NS udp bind whose IP endpoint will be used as IP-SNS local endpoint. Can be given multiple times.

### 1.8.3 no bind ID

Command

```
no bind ID
```

Parameters

no

Negate a command or set its defaults

bind

Delete a bind

ID

Unique identifier for this bind

### 1.8.4 no ip-sns-default bind ID

#### Command

```
no ip-sns-default bind ID
```

#### Parameters

no

Negate a command or set its defaults

ip-sns-default

Defaults for dynamically created NSEs created by IP-SNS in SGSN role

bind

IP SNS binds

ID

Name of NS udp bind whose IP endpoint will be removed as IP-SNS local endpoint.

### 1.8.5 no nse <0-65535>

#### Command

```
no nse <0-65535>
```

#### Parameters

no

Negate a command or set its defaults

nse

Delete a Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

### 1.8.6 nse <0-65535> [ip-sns-role-sgsn]

#### Command

```
nse <0-65535> [ip-sns-role-sgsn]
```

#### Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

[ip-sns-role-sgsn]

Create NSE in SGSN role (default: BSS)

## 1.8.7 timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-aliv...

### Command

```
timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-alive|tns- ↵
    alive-retries|tsns-prov|tsns-size-retries|tsns-config-retries|tsns-procedures- ↵
    retries) <0-65535>
```

### Parameters

#### timer

Network Service Timer

#### tns-block

(un)blocking Timer (Tns-block) timeout

#### tns-block-retries

(un)blocking Timer (Tns-block) number of retries

#### tns-reset

Reset Timer (Tns-reset) timeout

#### tns-reset-retries

Reset Timer (Tns-reset) number of retries

#### tns-test

Test Timer (Tns-test) timeout

#### tns-alive

Alive Timer (Tns-alive) timeout

#### tns-alive-retries

Alive Timer (Tns-alive) number of retries

#### tsns-prov

SNS Provision Timer (Tsns-prov) timeout

#### tsns-size-retries

SNS Size number of retries

#### tsns-config-retries

SNS Config number of retries

#### tsns-procedures-retries

SNS Procedures number of retries

#### <0-65535>

Timer Value



## 1.9 config-bssgp

## 1.10 config-ctrl

### 1.10.1 bind A.B.C.D

#### Command

```
bind A.B.C.D
```

#### Parameters

##### bind

Set bind address to listen for Control connections

##### A.B.C.D

Local IP address (default 127.0.0.1)

## 1.11 config-cs7

### 1.11.1 as NAME (sua|m3ua|ipa)

#### Command

```
as NAME (sua|m3ua|ipa)
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### as

Configure an Application Server

##### NAME

Name of the Application Server

##### sua

SCCP User Adaptation

##### m3ua

MTP3 User Adaptation

##### ipa

IPA Multiplex (SCCP Lite)

---

### 1.11.2 asp NAME <0-65535> <0-65535> (sua|m3ua|ipa)

#### Command

```
asp NAME <0-65535> <0-65535> (sua|m3ua|ipa)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

asp

Configure Application Server Process

NAME

Name of ASP

<0-65535>

Remote SCTP port number

<0-65535>

Local SCTP port number

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

### 1.11.3 description .TEXT

#### Command

```
description .TEXT
```

#### Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

### 1.11.4 network-indicator (international | national | reserved | spare)

#### Command

```
network-indicator (international | national | reserved | spare)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

network-indicator

Configure the Network Indicator

international

International Network

national

National Network

reserved

Reserved Network

spare

Spare Network

### 1.11.5 no as NAME

#### Command

```
no as NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

as

Disable Application Server

NAME

Name of AS

### 1.11.6 no asp NAME

#### Command

```
no asp NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

asp

Disable Application Server Process

NAME

Name of ASP

### 1.11.7 no sccp-address NAME

#### Command

```
no sccp-address NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

sccp-address

Delete an SCCP addressbook entry

NAME

Name of the SCCP Address

### 1.11.8 point-code POINT\_CODE

#### Command

```
point-code POINT_CODE
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Configure the local Point Code

POINT\_CODE

Point Code

### 1.11.9 point-code delimiter (default|dash)

#### Command

```
point-code delimiter (default|dash)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code

delimiter

Configure Point Code Delimiter

default

Use dot as delimiter

dash

User dash as delimiter

### 1.11.10 point-code format <1-24> [<1-23>] [<1-22>]

#### Command

```
point-code format <1-24> [<1-23>] [<1-22>]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code

format

Configure Point Code Format

<1-24>

Length of first PC component

[<1-23>]

Length of second PC component

[<1-22>]

Length of third PC component

### 1.11.11 point-code format default

#### Command

```
point-code format default
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code

format

Configure Point Code Format

default

Default Point Code Format (3.8.3)

---

### 1.11.12 sccp-address NAME

Command

```
sccp-address NAME
```

Global attributes

Flag: !

This command applies immediately

Parameters

sccp-address

Create/Modify an SCCP addressbook entry

NAME

Name of the SCCP Address

### 1.11.13 sccp-timer (conn\_est|ias|iar|rel|repeat\_rel|int|guard|reset|reassembly) <1-99999...

Command

```
sccp-timer (conn_est|ias|iar|rel|repeat_rel|int|guard|reset|reassembly) <1-99999>
```

Global attributes

Flag: !

This command applies immediately

Parameters

sccp-timer

Configure SCCP timer values, see ITU-T Q.714

conn\_est

Waiting for connection confirm message, 1 to 2 minutes (default: 60)

ias

Send keep-alive: on an idle connection, delay before sending an Idle Timer message, 5 to 10 minutes (default: 420)

iar

Receive keep-alive: on an idle connection, delay until considering a connection as stale, 11 to 21 minutes (default: 900)

rel

Waiting for release complete message, 10 to 20 seconds (default: 10)

repeat\_rel

Waiting for release complete message; or to repeat sending released message after the initial expiry, 10 to 20 seconds (default: 10)

**int**

Waiting for release complete message; or to release connection resources, freeze the LRN and alert a maintenance function after the initial expiry, extending to 1 minute (default: 60)

**guard**

Waiting to resume normal procedure for temporary connection sections during the restart procedure, 23 to 25 minutes (default: 1380)

**reset**

Waiting to release temporary connection section or alert maintenance function after reset request message is sent, 10 to 20 seconds (default: 10)

**reassembly**

Waiting to receive all the segments of the remaining segments, single segmented message after receiving the first segment, 10 to 20 seconds (default: 10)

**<1-999999>**

Timer value, in seconds

### 1.11.14 xua rkm routing-key-allocation (static-only|dynamic-permitted)

**Command**

```
xua rkm routing-key-allocation (static-only|dynamic-permitted)
```

**Global attributes****Flag: !**

This command applies immediately

**Parameters****xua**

SIGTRAN xxxUA related

**rkm**

Routing Key Management

**routing-key-allocation**

Routing Key Management Allocation Policy

**static-only**

Only static (pre-configured) Routing Keys permitted

**dynamic-permitted**

Dynamically allocate Routing Keys for what ASPs request



## 1.12 config-cs7-as

### 1.12.1 asp NAME

Command

```
asp NAME
```

Global attributes

Flag: !

This command applies immediately

Parameters

asp

Specify that a given ASP is part of this AS

NAME

Name of ASP to be added to AS

### 1.12.2 description .TEXT

Command

```
description .TEXT
```

Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

### 1.12.3 no asp NAME

Command

```
no asp NAME
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

asp

Specify ASP to be removed from this AS

NAME

Name of ASP to be removed

### 1.12.4 no traffic-mode

#### Command

```
no traffic-mode
```

#### Parameters

no

Negate a command or set its defaults

traffic-mode

Remove explicit traffic mode of operation of this AS

### 1.12.5 point-code override dpc PC

#### Command

```
point-code override dpc PC
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code Specific Features

override

Override (force) a point-code to hard-coded value

dpc

Override Source Point Code

PC

Override Destination Point Code

### 1.12.6 point-code override patch-sccp (disabled|both)

#### Command

```
point-code override patch-sccp (disabled|both)
```

#### Global attributes

Flag: !

This command applies immediately

---

#### Parameters

##### point-code

Point Code Specific Features

##### override

Override (force) a point-code to hard-coded value

##### patch-sccp

Patch point code values into SCCP called/calling address

##### disabled

Don't patch any point codes into SCCP called/calling address

##### both

Patch both origin and destination point codes into SCCP called/calling address

### 1.12.7 qos-class <0-255>

#### Command

```
qos-class <0-255>
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### qos-class

Specity QoS Class of AS

##### <0-255>

QoS Class of AS

### 1.12.8 recovery-timeout <1-2000>

#### Command

```
recovery-timeout <1-2000>
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### recovery-timeout

Specifies the recovery timeout value in milliseconds

##### <1-2000>

Recovery Timeout in Milliseconds

### 1.12.9 routing-key RCONTEXT DPC

#### Command

```
routing-key RCONTEXT DPC
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### routing-key

Define a routing key

##### RCONTEXT

Routing context number

##### DPC

Destination Point Code

### 1.12.10 routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup)

#### Command

```
routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### routing-key

Define a routing key

##### RCONTEXT

Routing context number

##### DPC

Destination Point Code

##### si

Match on Service Indicator

##### aal2

ATM Adaption Layer 2

##### bicc

Bearer Independent Call Control

b-isup

Broadband ISDN User Part

h248

H.248

isup

ISDN User Part

sat-isup

Sattelite ISDN User Part

sccp

Signalling Connection Control Part

tup

Telephony User Part

### 1.12.11 routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup) ssn S...

Command

```
routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup) ssn SSN
```

Global attributes

Flag: !

This command applies immediately

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

si

Match on Service Indicator

aal2

ATM Adaption Layer 2

bicc

Bearer Independent Call Control

b-isup

Broadband ISDN User Part

h248

H.248

isup

ISDN User Part

sat-isup

Sattelite ISDN User Part

sccp

Signalling Connection Control Part

tup

Telephony User Part

ssn

Match on Sub-System Number

SSN

Sub-System Number to match on

### 1.12.12 routing-key RCONTEXT DPC ssn SSN

Command

```
routing-key RCONTEXT DPC ssn SSN
```

Global attributes

Flag: !

This command applies immediately

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

ssn

Match on Sub-System Number

SSN

Sub-System Number to match on

### 1.12.13 traffic-mode (broadcast | loadshare | roundrobin | override)

#### Command

```
traffic-mode (broadcast | loadshare | roundrobin | override)
```

#### Parameters

##### traffic-mode

Specifies traffic mode of operation of the ASP within the AS

##### broadcast

Broadcast to all ASP within AS

##### loadshare

Share Load among all ASP within AS

##### roundrobin

Round-Robin between all ASP within AS

##### override

Override

## 1.13 config-cs7-asp

### 1.13.1 block

#### Command

```
block
```

#### Global attributes

##### Flag: @

This command applies on VTY node exit

#### Parameters

##### block

Allows a SCTP Association with ASP, but doesn't let it become active

### 1.13.2 description .TEXT

#### Command

```
description .TEXT
```

#### Parameters

##### description

Save human-readable description of the object

##### .TEXT

Text until the end of the line

---

### 1.13.3 local-ip (A.B.C.D|X:X::X:X)

#### Command

```
local-ip (A.B.C.D|X:X::X:X)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

local-ip

Specify Local IP Address from which to contact ASP

A.B.C.D

Local IPv4 Address from which to contact of ASP

X:X::X:X

Local IPv6 Address from which to contact of ASP

### 1.13.4 no quirk (no\_notify|daud\_in\_asp|snm\_inactive)

#### Command

```
no quirk (no_notify|daud_in_asp|snm_inactive)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

quirk

Disable quirk to work around interop issues

no\_notify

Peer SG doesn't send NTFY(AS-INACTIVE) after ASP-UP

daud\_in\_asp

Allow Rx of DAUD in ASP role

snm\_inactive

Allow Rx of [S]SNM in AS-INACTIVE state



### 1.13.5 qos-class <0-255>

#### Command

```
qos-class <0-255>
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

qos-class

Specify QoS Class of ASP

<0-255>

QoS Class of ASP

### 1.13.6 quirk (no\_notify|daud\_in\_asp|snm\_inactive)

#### Command

```
quirk (no_notify|daud_in_asp|snm_inactive)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

quirk

Enable quirk to work around interop issues

no\_notify

Peer SG doesn't send NTFY(AS-INACTIVE) after ASP-UP

daud\_in\_asp

Allow Rx of DAUD in ASP role

snm\_inactive

Allow Rx of [S]SNM in AS-INACTIVE state

### 1.13.7 remote-ip (A.B.C.D|X:X::X:X)

#### Command

```
remote-ip (A.B.C.D|X:X::X:X)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

remote-ip

Specify Remote IP Address of ASP

A.B.C.D

Remote IPv4 Address of ASP

X:X::X:X

Remote IPv6 Address of ASP

### 1.13.8 role (sg|asp|ipsp)

#### Command

```
role (sg|asp|ipsp)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

role

Specify the xUA role for this ASP

sg

SG (Signaling Gateway)

asp

ASP (Application Server Process)

ipsp

IPSP (IP Signalling Point)

### 1.13.9 sctp-role (client|server)

#### Command

```
sctp-role (client|server)
```

#### Global attributes

#### Flag: @

This command applies on VTY node exit

#### Parameters

#### sctp-role

Specify the SCTP role for this ASP

#### client

Operate as SCTP client; connect to a server

#### server

Operate as SCTP server; wait for client connections

### 1.13.10 shutdown

#### Command

```
shutdown
```

#### Global attributes

#### Flag: @

This command applies on VTY node exit

#### Parameters

#### shutdown

Terminates SCTP association; New associations will be rejected

## 1.14 config-cs7-sccpaddr

### 1.14.1 global-title

#### Command

```
global-title
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### global-title

Add/Modify Global Title

---

### 1.14.2 no global-title

#### Command

```
no global-title
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### no

Negate a command or set its defaults

#### global-title

Remove Global Title

### 1.14.3 no point-code

#### Command

```
no point-code
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### no

Negate a command or set its defaults

#### point-code

Remove point-code Number

### 1.14.4 no subsystem-number

#### Command

```
no subsystem-number
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### no

Negate a command or set its defaults

#### subsystem-number

Remove Subsystem Number

---

### 1.14.5 point-code POINT\_CODE

#### Command

```
point-code POINT_CODE
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Add point-code Number

POINT\_CODE

PC

### 1.14.6 routing-indicator (GT|PC|IP)

#### Command

```
routing-indicator (GT|PC|IP)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

routing-indicator

Add Routing Indicator

GT

by global-title

PC

by point-code

IP

by ip-address

### 1.14.7 subsystem-number <0-4294967295>

#### Command

```
subsystem-number <0-4294967295>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

subsystem-number

Add Subsystem Number

<0-4294967295>

SSN

## 1.15 config-cs7-sccpaddr-gt

### 1.15.1 digits DIGITS

#### Command

```
digits DIGITS
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

digits

Set Global Title Digits

DIGITS

Number digits

### 1.15.2 global-title-indicator <0-15>

#### Command

```
global-title-indicator <0-15>
```

#### Global attributes

---

Flag: !

This command applies immediately

Parameters

global-title-indicator

Set Global Title Indicator

<0-15>

GTI

### 1.15.3 nature-of-address-indicator <0-127>

Command

```
nature-of-address-indicator <0-127>
```

Global attributes

Flag: !

This command applies immediately

Parameters

nature-of-address-indicator

Set Global Title Nature of Address Indicator

<0-127>

NAI

### 1.15.4 numbering-plan-indicator <0-15>

Command

```
numbering-plan-indicator <0-15>
```

Global attributes

Flag: !

This command applies immediately

Parameters

numbering-plan-indicator

Set Global Title Numbering Plan Indicator

<0-15>

NPI

### 1.15.5 translation-type <0-255>

#### Command

```
translation-type <0-255>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

translation-type

Set Global Title Translation Type

<0-255>

TT

## 1.16 config-cpu-sched

### 1.16.1 cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]

#### Command

```
cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cpu-affinity

Set CPU affinity mask on a (group of) thread(s)

self

Set CPU affinity mask on thread running the VTY

all

Set CPU affinity mask on all process' threads

<0-4294967295>

Set CPU affinity mask on a thread with specified PID

THREADNAME

Set CPU affinity mask on a thread with specified thread name

CPUHEXMASK

CPU affinity mask

[delay]

If set, delay applying the affinity mask now and let the app handle it at a later point

---



## 1.16.2 policy rr <1-32>

### Command

```
policy rr <1-32>
```

### Global attributes

#### Flag: !

This command applies immediately

### Parameters

#### policy

Set the scheduling policy to use for the process

#### rr

Use the SCHED\_RR real-time scheduling algorithm

#### <1-32>

Set the SCHED\_RR real-time priority

## 1.17 config-ns-bind

### 1.17.1 accept-dynamic-ip-sns

### Command

```
accept-dynamic-ip-sns
```

### Parameters

#### accept-dynamic-ip-sns

Allow to create dynamic NS Entities by IP-SNS PDUs

### 1.17.2 accept-ipaccess

### Command

```
accept-ipaccess
```

### Parameters

#### accept-ipaccess

Allow to create dynamic NS Entity by NS Reset PDU on UDP (ip.access style)

---

### 1.17.3 dscp <0-63>

#### Command

```
dscp <0-63>
```

#### Parameters

dscp

Set DSCP/TOS on the UDP socket

<0-63>

DSCP Value

### 1.17.4 fr NETIF (fr|frnet)

#### Command

```
fr NETIF (fr|frnet)
```

#### Parameters

fr

frame relay

NETIF

Interface name(e.g. ep0)

fr

fr (user) is used by BSS or SGSN attached to UNI of a FR network

frnet

frnet (network) is used by SGSN if BSS is directly attached

### 1.17.5 ip-sns signalling-weight <0-254> data-weight <0-254>

#### Command

```
ip-sns signalling-weight <0-254> data-weight <0-254>
```

#### Parameters

ip-sns

IP SNS

signalling-weight

signalling weight used by IP-SNS dynamic configuration

<0-254>

signalling weight used by IP-SNS dynamic configuration

data-weight

data weight used by IP-SNS dynamic configuration

<0-254>

data weight used by IP-SNS dynamic configuration

### 1.17.6 listen (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
listen (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

##### listen

Configure local IP + Port of this bind

##### A.B.C.D

Local IPv4 Address

##### X:X::X:X

Local IPv6 Address

##### <1-65535>

Local UDP Port

### 1.17.7 no accept-dynamic-ip-sns

#### Command

```
no accept-dynamic-ip-sns
```

#### Parameters

##### no

Negate a command or set its defaults

##### accept-dynamic-ip-sns

Disable dynamic creation of NS Entities by IP-SNS PDUs

### 1.17.8 no accept-ipaccess

#### Command

```
no accept-ipaccess
```

#### Parameters

##### no

Negate a command or set its defaults

##### accept-ipaccess

Reject NS Reset PDU on UDP (ip.access style)

---

### 1.17.9 no dscp

#### Command

```
no dscp
```

#### Parameters

no

Set DSCP/TOS on the UDP socket

dscp

DSCP Value

### 1.17.10 no fr NETIF

#### Command

```
no fr NETIF
```

#### Parameters

no

Negate a command or set its defaults

fr

Delete a frame relay link

NETIF

Delete a frame relay link

### 1.17.11 no listen

#### Command

```
no listen
```

#### Parameters

no

Negate a command or set its defaults

listen

Delete a IP/Port assignment

### 1.17.12 socket-priority <0-255>

#### Command

```
socket-priority <0-255>
```

#### Parameters

##### socket-priority

Set socket priority on the UDP socket

##### <0-255>

Priority Value (>6 requires CAP\_NET\_ADMIN)

## 1.18 config-ns-nse

### 1.18.1 ip-sns-bind BINDID

#### Command

```
ip-sns-bind BINDID
```

#### Parameters

##### ip-sns-bind

IP SNS binds

##### BINDID

Name of NS udp bind whose IP endpoint will be used as IP-SNS local endpoint. Can be given multiple times.

### 1.18.2 ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

##### ip-sns-remote

SNS Initial Endpoint

##### A.B.C.D

SGSN IPv4 Address

##### X:X::X:X

SGSN IPv6 Address

##### <1-65535>

SGSN UDP Port

---

### 1.18.3 no ip-sns-bind BINDID

#### Command

```
no ip-sns-bind BINDID
```

#### Parameters

no

Negate a command or set its defaults

ip-sns-bind

IP SNS binds

BINDID

Name of NS udp bind whose IP endpoint will not be used as IP-SNS local endpoint

### 1.18.4 no ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
no ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

no

Negate a command or set its defaults

ip-sns-remote

Delete a SNS Initial Endpoint

A.B.C.D

SGSN IPv4 Address

X:X::X:X

SGSN IPv6 Address

<1-65535>

SGSN UDP Port

### 1.18.5 no nsvc fr NETIF dlci <16-1007>

#### Command

```
no nsvc fr NETIF dlci <16-1007>
```

#### Parameters

no

Negate a command or set its defaults

nsvc

Delete frame relay NS-VC

fr

frame relay

NETIF

frame relay interface. Must be registered via fr vty

dlci

Data Link connection identifier

<16-1007>

Data Link connection identifier

### 1.18.6 no nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>

Command

```
no nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>
```

Parameters

no

Negate a command or set its defaults

nsvc

Delete a NS Virtual Connection

ipa

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

nsvci

NS Virtual Connection ID (NS-VCI)

<0-65535>

NS Virtual Connection ID (NS-VCI)

### 1.18.7 no nsvc nsvci <0-65535>

#### Command

```
no nsvc nsvci <0-65535>
```

#### Parameters

no

Negate a command or set its defaults

nsvc

Delete NSVC

nsvci

NS Virtual Connection ID (NS-VCI)

<0-65535>

NS Virtual Connection ID (NS-VCI)

### 1.18.8 no nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
no nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

no

Negate a command or set its defaults

nsvc

Delete a NS Virtual Connection

udp

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port



### 1.18.9 nsvc fr NETIF dlci <16-1007> nsvci <0-65535>

#### Command

```
nsvc fr NETIF dlci <16-1007> nsvci <0-65535>
```

#### Parameters

nsvc

NS Virtual Connection

fr

frame relay

NETIF

frame relay interface. Must be registered via fr vty

dlci

NS Virtual Connection ID (NS-VCI)

<16-1007>

NS Virtual Connection ID (NS-VCI)

nsvci

Data Link connection identifier

<0-65535>

Data Link connection identifier

### 1.18.10 nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>

#### Command

```
nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>
```

#### Parameters

nsvc

NS Virtual Connection

ipa

NS over UDP ip.access style (uses RESET/BLOCK)

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

nsvci

NS Virtual Connection ID (NS-VCI)

<0-65535>

NS Virtual Connection ID (NS-VCI)

### 1.18.11 nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>

Command

```
nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>
```

Parameters

nsvc

NS Virtual Connection

udp

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

### 1.18.12 nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535> signalling-weight <0-254> data-weight...

Command

```
nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535> signalling-weight <0-254> data-weight <0-254>
```

Parameters

nsvc

NS Virtual Connection

udp

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

signalling-weight

Signalling weight of the NSVC (default = 1)

<0-254>

Signalling weight of the NSVC (default = 1)

data-weight

Data weight of the NSVC (default = 1)

<0-254>

Data weight of the NSVC (default = 1)

## 1.19 config-sgsn

Configure the remote GGSN, access-control and other attributes of the SGSN

### 1.19.1 access-point-name NAME

Command

```
access-point-name NAME
```

Parameters

access-point-name

Globally allow the given APN name for all subscribers.

NAME

Add this NAME to the list

### 1.19.2 apn APNAME ggsn <0-255>

Command

```
apn APNAME ggsn <0-255>
```

Parameters

apn

Configure the information per APN

APNAME

The APN gateway name optionally prefixed by '\*' (wildcard)

ggsn

Select the GGSN to use for the given APN gateway prefix

<0-255>

The GGSN id

### 1.19.3 apn APNAME imsi-prefix IMSIPRE ggsn <0-255>

#### Command

```
apn APNAME imsi-prefix IMSIPRE ggsn <0-255>
```

#### Parameters

##### apn

Configure the information per APN

##### APNAME

The APN gateway name optionally prefixed by '\*' (wildcard)

##### imsi-prefix

Select the GGSN to use for the given APN gateway prefix if and only if the IMSI matches the given prefix.

##### IMSIPRE

An IMSI prefix

##### ggsn

Select the GGSN to use when APN gateway and IMSI prefix match

##### <0-255>

The GGSN id

### 1.19.4 asn1 debug (1|0)

#### Command

```
asn1 debug (1|0)
```

#### Parameters

##### asn1

ASN.1 settings

##### debug

Enable ASN.1 debug messages

##### 1

Log ASN.1 debug messages to stderr

##### 0

Do not log ASN.1 debug messages to stderr

### 1.19.5 asn1 xer-print (1|0)

#### Command

```
asn1 xer-print (1|0)
```

#### Parameters

##### asn1

ASN.1 settings

##### xer-print

Log human readable representations of all ASN.1 messages to stderr

1

Log XML representation of all ASN.1 messages to stderr

0

Do not log decoded ASN.1 messages to stderr

### 1.19.6 auth-policy (accept-all|closed|acl-only|remote)

#### Command

```
auth-policy (accept-all|closed|acl-only|remote)
```

#### Parameters

##### auth-policy

Configure the Authorization policy of the SGSN. This setting determines which subscribers are permitted to register to the network.

##### accept-all

Accept all IMSIs (DANGEROUS)

##### closed

Accept only home network subscribers or those in the ACL

##### acl-only

Accept only subscribers in the ACL

##### remote

Use remote subscription data only (HLR)

---

### 1.19.7 authentication (optional|required)

#### Command

```
authentication (optional|required)
```

#### Parameters

##### authentication

Whether to enforce MS authentication in GERAN (only with auth-policy remote)

##### optional

Allow MS to attach via GERAN without authentication (default and only possible value for non-remote auth-policy)

##### required

Always require authentication (only available for auth-policy remote, default with that auth-policy)

### 1.19.8 cdr filename NAME

#### Command

```
cdr filename NAME
```

#### Parameters

##### cdr

CDR

##### filename

Set the file name for the call-data-record file, logging the data usage of each subscriber.

##### NAME

filename

### 1.19.9 cdr interval <1-2147483647>

#### Command

```
cdr interval <1-2147483647>
```

#### Parameters

##### cdr

CDR

##### interval

Set the interval for the call-data-record file

##### <1-2147483647>

interval in seconds

---

### 1.19.10 cdr trap

#### Command

```
cdr trap
```

#### Parameters

cdr

CDR

trap

Enable sending CDR via TRAP CTRL messages

### 1.19.11 compression rfc1144 active slots <1-256>

#### Command

```
compression rfc1144 active slots <1-256>
```

#### Parameters

compression

Configure compression

rfc1144

RFC1144 Header compression scheme

active

Compression is actively proposed

slots

Number of compression state slots

<1-256>

Number of compression state slots

### 1.19.12 compression rfc1144 passive

#### Command

```
compression rfc1144 passive
```

#### Parameters

compression

Configure compression

rfc1144

RFC1144 Header compression scheme

passive

Compression is available on request

### 1.19.13 compression v42bis active direction (ms|sgsn|both) codewords <512-65535> strlen ...

#### Command

```
compression v42bis active direction (ms|sgsn|both) codewords <512-65535> strlen <6-250>
```

#### Parameters

##### compression

Configure compression

##### v42bis

V.42bis data compression scheme

##### active

Compression is actively proposed

##### direction

Direction in which the compression shall be active (p0)

##### ms

Compress ms->sgsn direction only

##### sgsn

Compress sgsn->ms direction only

##### both

Both directions

##### codewords

Number of codewords (p1)

##### <512-65535>

Number of codewords

##### strlen

Maximum string length (p2)

##### <6-250>

Maximum string length

### 1.19.14 compression v42bis passive

#### Command

```
compression v42bis passive
```

#### Parameters

##### compression

Configure compression

##### v42bis

V.42bis data compression scheme

##### passive

Compression is available on request



### 1.19.15 cs7-instance-iu <0-15>

#### Command

```
cs7-instance-iu <0-15>
```

#### Parameters

##### cs7-instance-iu

Set SS7 to be used by the Iu-Interface.

##### <0-15>

SS7 instance reference number (default: 0)

### 1.19.16 encryption gea <0-4> [<0-4>] [<0-4>] [<0-4>] [<0-4>]

#### Command

```
encryption gea <0-4> [<0-4>] [<0-4>] [<0-4>] [<0-4>]
```

#### Parameters

##### encryption

Set encryption algorithms for SGSN

##### gea

GPRS Encryption Algorithm

##### <0-4>

GEAn Algorithm Number

##### [<0-4>]

GEAn Algorithm Number

##### [<0-4>]

GEAn Algorithm Number

##### [<0-4>]

GEAn Algorithm Number

##### [<0-4>]

GEAn Algorithm Number

### 1.19.17 encryption uea <0-2> [<0-2>] [<0-2>]

#### Command

```
encryption uea <0-2> [<0-2>] [<0-2>]
```

#### Parameters

---

### encryption

Set encryption algorithms for SGSN

### uea

UTRAN (3G) encryption algorithms to allow: 0 = UEA0 (no encryption), 1 = UEA1, 2 = UEA2.

<0-2>

UEAn Algorithm Number

[<0-2>]

UEAn Algorithm Number

[<0-2>]

UEAn Algorithm Number

## 1.19.18 ggsn <0-255> echo-interval <1-36000>

### Command

```
ggsn <0-255> echo-interval <1-36000>
```

### Parameters

#### ggsn

Configure the GGSN information

<0-255>

GGSN Number

#### echo-interval

Send an echo request to this static GGSN every interval.

<1-36000>

Interval between echo requests in seconds.

## 1.19.19 ggsn <0-255> gtp-version (0|1)

### Command

```
ggsn <0-255> gtp-version (0|1)
```

### Parameters

#### ggsn

Configure the GGSN information

<0-255>

GGSN Number

#### gtp-version

GTP Version

0

Version 0

1

Version 1

### 1.19.20 ggsn <0-255> no echo-interval

#### Command

```
ggsn <0-255> no echo-interval
```

#### Parameters

##### ggsn

Configure the GGSN information

##### <0-255>

GGSN Number

##### no

Negate a command or set its defaults

##### echo-interval

Send an echo request to this static GGSN every interval.

### 1.19.21 ggsn <0-255> remote-ip A.B.C.D

#### Command

```
ggsn <0-255> remote-ip A.B.C.D
```

#### Parameters

##### ggsn

Configure the GGSN information

##### <0-255>

GGSN Number

##### remote-ip

Configure this static GGSN to use the specified remote IP address.

##### A.B.C.D

IPv4 Address

### 1.19.22 ggsn dynamic

#### Command

```
ggsn dynamic
```

#### Parameters

##### ggsn

Configure the GGSN information

##### dynamic

Enable dynamic resolving of GGSNs based on DNS resolving the APN name like in a GRX-style setup. Changing this setting requires a restart.

---

### 1.19.23 grx-dns-add A.B.C.D

#### Command

```
grx-dns-add A.B.C.D
```

#### Parameters

##### grx-dns-add

Use the specified IP address for DNS-resolving the AP names to GGSN IP addresses

##### A.B.C.D

IPv4 address

### 1.19.24 gsup ipa-name NAME

#### Command

```
gsup ipa-name NAME
```

#### Parameters

##### gsup

GSUP Parameters

##### ipa-name

Set the IPA name of this SGSN

##### NAME

A unique name for this SGSN. For example: PLMN + redundancy server number: SGSN-901-70-0. This name is used for GSUP routing and must be set if more than one SGSN is connected to the network. The default is 'SGSN-00-00-00-00-00-00'.

### 1.19.25 gsup oap-id <0-65535>

#### Command

```
gsup oap-id <0-65535>
```

#### Parameters

##### gsup

GSUP Parameters

##### oap-id

Set the OAP client ID for authentication on the GSUP protocol. This setting only applies if 'auth-policy remote' is used.

##### <0-65535>

OAP client ID (0 == disabled)

---

### 1.19.26 gsup oap-k K

#### Command

```
gsup oap-k K
```

#### Parameters

gsup

GSUP Parameters

oap-k

Set the OAP shared secret key K for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

K

K value (16 byte) hex

### 1.19.27 gsup oap-opc OPC

#### Command

```
gsup oap-opc OPC
```

#### Parameters

gsup

GSUP Parameters

oap-opc

Set the OAP shared secret OPC for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

OPC

OPC value (16 byte) hex

### 1.19.28 gsup remote-ip A.B.C.D

#### Command

```
gsup remote-ip A.B.C.D
```

#### Parameters

gsup

GSUP Parameters

remote-ip

Set the IP address of the remote GSUP server (e.g. OsmoHLR). This setting only applies if 'auth-policy remote' is used.

A.B.C.D

IPv4 Address

### 1.19.29 gsup remote-port <0-65535>

#### Command

```
gsup remote-port <0-65535>
```

#### Parameters

gsup

GSUP Parameters

remote-port

Set the TCP port of the remote GSUP server, see also 'gsup remote-ip'

<0-65535>

Remote TCP port

### 1.19.30 gtp local-ip A.B.C.D

#### Command

```
gtp local-ip A.B.C.D
```

#### Parameters

gtp

GTP Parameters

local-ip

Set the IP address for the local GTP bind for the Gp interface (towards the GGSNs). Note: in case you would like to run the GGSN on the same machine as the SGSN, you can not run both on the same IP address, since both sides are specified to use the same GTP port numbers (2123 and 2152). For example, you could use 127.0.0.1 for the SGSN and 127.0.0.2 for the GGSN in such situations.

A.B.C.D

IPv4 Address

### 1.19.31 gtp state-dir PATH

#### Command

```
gtp state-dir PATH
```

#### Parameters

gtp

GTP Parameters

state-dir

Set the directory for the GTP State file

PATH

Local Directory

---

### 1.19.32 imsi-acl (add|del) IMSI

#### Command

```
imsi-acl (add|del) IMSI
```

#### Parameters

##### imsi-acl

Access Control List of foreign IMSIs

##### add

Add IMSI to ACL

##### del

Remove IMSI from ACL

##### IMSI

IMSI of subscriber

### 1.19.33 iu rab-assign-addr-enc (x213|v4raw)

#### Command

```
iu rab-assign-addr-enc (x213|v4raw)
```

#### Parameters

##### iu

Iu interface protocol options

##### rab-assign-addr-enc

Choose RAB Assignment's Transport Layer Address encoding

##### x213

ITU-T X.213 compliant address encoding (default)

##### v4raw

32bit length raw IPv4 address (for ip.access nano3G)

### 1.19.34 mme NAME

#### Command

```
mme NAME
```

#### Parameters

##### mme

Configure an MME peer

##### NAME

Name identifying the MME peer

---

### 1.19.35 no access-point-name NAME

#### Command

```
no access-point-name NAME
```

#### Parameters

no

Negate a command or set its defaults

access-point-name

Configure a global list of allowed APNs

NAME

Remove entry with NAME

### 1.19.36 no cdr filename

#### Command

```
no cdr filename
```

#### Parameters

no

Negate a command or set its defaults

cdr

CDR

filename

Disable saving CDR to file

### 1.19.37 no cdr trap

#### Command

```
no cdr trap
```

#### Parameters

no

Negate a command or set its defaults

cdr

CDR

trap

Disable sending CDR via TRAP CTRL messages

---



### 1.19.38 no compression rfc1144

#### Command

```
no compression rfc1144
```

#### Parameters

no

Negate a command or set its defaults

compression

Configure compression

rfc1144

disable rfc1144 TCP/IP header compression

### 1.19.39 no compression v42bis

#### Command

```
no compression v42bis
```

#### Parameters

no

Negate a command or set its defaults

compression

Configure compression

v42bis

disable V.42bis data compression

### 1.19.40 no mme NAME

#### Command

```
no mme NAME
```

#### Parameters

no

Negate a command or set its defaults

mme

Delete an MME peer configuration

NAME

Name identifying the MME peer

---

### 1.19.41 timer [TNNNN] [(**<0-2147483647>**|default)]

#### Command

```
timer [TNNNN] [(<0-2147483647>|default)]
```

#### Parameters

##### timer

Configure or show timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

##### [**<0-2147483647>**]

New timer value

##### [default]

Set to default timer value

## 1.20 config-sgsn-mme

### 1.20.1 gtp ran-info-relay **<0-999>** **<0-999>** **<0-65535>**

#### Command

```
gtp ran-info-relay <0-999> <0-999> <0-65535>
```

#### Parameters

##### gtp

Configure GTP connection

##### ran-info-relay

Configure RAN Information Relay routing

##### **<0-999>**

MCC

##### **<0-999>**

MNC

##### **<0-65535>**

TAC

---

### 1.20.2 gtp ran-info-relay default

#### Command

```
gtp ran-info-relay default
```

#### Parameters

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

default

Set as default route

### 1.20.3 gtp remote-ip A.B.C.D

#### Command

```
gtp remote-ip A.B.C.D
```

#### Parameters

gtp

Configure GTP connection

remote-ip

Set Remote GTP IP address

A.B.C.D

IP information

### 1.20.4 no gtp ran-info-relay <0-999> <0-999> <0-65535>

#### Command

```
no gtp ran-info-relay <0-999> <0-999> <0-65535>
```

#### Parameters

no

Negate a command or set its defaults

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

---

<0-999>

MCC

<0-999>

MNC

<0-65535>

TAC

### 1.20.5 no gtp ran-info-relay default

Command

```
no gtp ran-info-relay default
```

Parameters

no

Negate a command or set its defaults

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

default

Set as default route