

## **OsmoGGSN VTY Reference**

Copyright © 2017

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

<b>COLLABORATORS</b>
----------------------

	<i>TITLE :</i> OsmoGGSN VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		February 16, 2024	

<b>REVISION HISTORY</b>
-------------------------

NUMBER	DATE	DESCRIPTION	NAME
DRAFT	unknown	Automatically Generated VTY Reference	hw

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list [with-flags]	2
1.1.5	show running-config	3
1.1.6	show vty-attributes	3
1.1.7	show vty-attributes (application library global)	3
1.1.8	write	4
1.1.9	write file [PATH]	4
1.1.10	write memory	4
1.1.11	write terminal	4
1.2	view	5
1.2.1	enable [expert-mode]	5
1.2.2	logging color (0 1)	5
1.2.3	logging disable	5
1.2.4	logging enable	6
1.2.5	logging filter all (0 1)	6
1.2.6	logging level (ip tun ggsn sgsn licmp6 global llapd linpl muxl mill mibl smsl ctr...	6
1.2.7	logging level force-all (debug info notice error fatal)	9
1.2.8	logging level set-all (debug info notice error fatal)	9
1.2.9	logging print category (0 1)	10
1.2.10	logging print category-hex (0 1)	10
1.2.11	logging print extended-timestamp (0 1)	11
1.2.12	logging print file (0 1 basename) [last]	11
1.2.13	logging print level (0 1)	12
1.2.14	logging print thread-id (0 1)	12
1.2.15	logging set-log-mask MASK	13
1.2.16	logging timestamp (0 1)	13

1.2.17	logp (iptun ggsn sgsn icmp6 global lapd linp mux millmib sms ctr l gtp ls...	13
1.2.18	no logging level force-all	16
1.2.19	show alarms	16
1.2.20	show asciidoc counters	16
1.2.21	show cpu-sched threads	17
1.2.22	show ggsn [NAME]	17
1.2.23	show history	17
1.2.24	show logging vty	18
1.2.25	show online-help	18
1.2.26	show pdp-context ggsn NAME	18
1.2.27	show pdp-context ggsn NAME apn APN	19
1.2.28	show pdp-context ggsn NAME imsi IMSI [<0-15>]	19
1.2.29	show pdp-context ggsn NAME ipv4 A.B.C.D	20
1.2.30	show pid	20
1.2.31	show rate-counters [skip-zero]	20
1.2.32	show stats [skip-zero]	21
1.2.33	show stats level (global peer subscriber) [skip-zero]	21
1.2.34	show talloc-context (application global all) (full brief DEPTH)	22
1.2.35	show talloc-context (application global all) (full brief DEPTH) filter REGEXP	22
1.2.36	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS	23
1.2.37	show timer [(gtp)] [TNNNN]	24
1.2.38	show uptime	24
1.2.39	show version	24
1.2.40	terminal length <0-512>	25
1.2.41	terminal no length	25
1.2.42	who	25
1.3	enable	25
1.3.1	configure [terminal]	26
1.3.2	copy running-config startup-config	26
1.3.3	disable	26
1.3.4	logging color (0 1)	27
1.3.5	logging disable	27
1.3.6	logging enable	27
1.3.7	logging filter all (0 1)	28
1.3.8	logging level (iptun ggsn sgsn icmp6 global lapd linp mux millmib sms ctr...	28
1.3.9	logging level force-all (debug info notice error fatal)	30
1.3.10	logging level set-all (debug info notice error fatal)	31
1.3.11	logging print category (0 1)	32
1.3.12	logging print category-hex (0 1)	32

1.3.13	logging print extended-timestamp (0 1)	33
1.3.14	logging print file (0 1 basename) [last]	33
1.3.15	logging print level (0 1)	34
1.3.16	logging print thread-id (0 1)	34
1.3.17	logging set-log-mask MASK	35
1.3.18	logging timestamp (0 1)	35
1.3.19	logp (iptun ggsn sgsn icmp6 global lapd linp mux mill mb sms ctrl gtp ls...	35
1.3.20	no logging level force-all	38
1.3.21	show alarms	38
1.3.22	show asciidoc counters	38
1.3.23	show cpu-sched threads	39
1.3.24	show ggsn [NAME]	39
1.3.25	show history	39
1.3.26	show logging vty	40
1.3.27	show online-help	40
1.3.28	show pdp-context ggsn NAME	40
1.3.29	show pdp-context ggsn NAME apn APN	41
1.3.30	show pdp-context ggsn NAME imsi IMSI [<0-15>]	41
1.3.31	show pdp-context ggsn NAME ipv4 A.B.C.D	42
1.3.32	show rate-counters [skip-zero]	42
1.3.33	show startup-config	42
1.3.34	show stats [skip-zero]	43
1.3.35	show stats level (global peer subscriber) [skip-zero]	43
1.3.36	show talloc-context (application global all) (full brief DEPTH)	44
1.3.37	show talloc-context (application global all) (full brief DEPTH) filter REGEXP	44
1.3.38	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS	45
1.3.39	show timer [(gtp)] [TNNNN]	46
1.3.40	show version	46
1.3.41	shutdown	46
1.3.42	stats report	47
1.3.43	stats reset	47
1.3.44	terminal length <0-512>	47
1.3.45	terminal monitor	48
1.3.46	terminal no length	48
1.3.47	terminal no monitor	48
1.3.48	who	49
1.4	config	49
1.4.1	banner motd default	49
1.4.2	banner motd file [FILE]	49

1.4.3	cpu-sched . . . . .	50
1.4.4	ctrl . . . . .	50
1.4.5	enable password (8l) WORD . . . . .	50
1.4.6	enable password LINE . . . . .	51
1.4.7	ggsn NAME . . . . .	51
1.4.8	hostname WORD . . . . .	51
1.4.9	line vty . . . . .	52
1.4.10	log alarms <2-32700> . . . . .	52
1.4.11	log file FILENAME [blocking-io] . . . . .	52
1.4.12	log gsmtap [HOSTNAME] . . . . .	53
1.4.13	log stderr [blocking-io] . . . . .	53
1.4.14	log syslog (authpriv cron daemon ftp lpr mail news user uucp) . . . . .	53
1.4.15	log syslog local <0-7> . . . . .	54
1.4.16	log systemd-journal [raw] . . . . .	54
1.4.17	no banner motd . . . . .	55
1.4.18	no enable password . . . . .	55
1.4.19	no ggsn NAME . . . . .	56
1.4.20	no hostname [HOSTNAME] . . . . .	56
1.4.21	no log alarms . . . . .	56
1.4.22	no log file FILENAME . . . . .	57
1.4.23	no log gsmtap [HOSTNAME] . . . . .	57
1.4.24	no log stderr . . . . .	57
1.4.25	no log syslog . . . . .	58
1.4.26	no log systemd-journal . . . . .	58
1.4.27	no service advanced-vty . . . . .	58
1.4.28	no service terminal-length [<0-512>] . . . . .	59
1.4.29	no stats reporter log [NAME] . . . . .	59
1.4.30	no stats reporter statsd [NAME] . . . . .	59
1.4.31	password (8l) WORD . . . . .	60
1.4.32	password LINE . . . . .	60
1.4.33	service advanced-vty . . . . .	61
1.4.34	service terminal-length <0-512> . . . . .	61
1.4.35	show history . . . . .	61
1.4.36	stats interval <0-65535> . . . . .	62
1.4.37	stats reporter log [NAME] . . . . .	62
1.4.38	stats reporter statsd [NAME] . . . . .	62
1.4.39	stats-tcp batch-size <1-65535> . . . . .	63
1.4.40	stats-tcp interval <0-65535> . . . . .	63
1.5	config-log . . . . .	63

1.5.1	logging color (01)	63
1.5.2	logging filter all (01)	64
1.5.3	logging level (ipltunlggsnlgsgnlicmp6llgloballllapdllinpllmuxllmillmibllsmsllctr...	64
1.5.4	logging level force-all (debuglinfolnoticeerrorlfatal)	67
1.5.5	logging level set-all (debuglinfolnoticeerrorlfatal)	67
1.5.6	logging print category (01)	68
1.5.7	logging print category-hex (01)	68
1.5.8	logging print extended-timestamp (01)	69
1.5.9	logging print file (01 basename) [last]	69
1.5.10	logging print level (01)	70
1.5.11	logging print thread-id (01)	70
1.5.12	logging timestamp (01)	71
1.5.13	no logging level force-all	71
1.6	config-stats	71
1.6.1	disable	71
1.6.2	enable	72
1.6.3	flush-period <0-65535>	72
1.6.4	level (globalpeerlsubscriber)	72
1.6.5	local-ip ADDR	73
1.6.6	mtu <100-65535>	73
1.6.7	no local-ip	73
1.6.8	no mtu	73
1.6.9	no prefix	74
1.6.10	prefix PREFIX	74
1.6.11	remote-ip ADDR	74
1.6.12	remote-port <1-65535>	74
1.7	config-line	75
1.7.1	bind A.B.C.D [<0-65535>]	75
1.7.2	login	75
1.7.3	no login	75
1.8	config-ctrl	75
1.8.1	bind A.B.C.D [<0-65535>]	76
1.9	config-cpu-sched	76
1.9.1	cpu-affinity (selfllll<0-4294967295> THREADNAME) CPUHEXMASK [delay]	76
1.9.2	policy rr <1-32>	77
1.10	config-ggsn	77
1.10.1	apn NAME	77
1.10.2	default-apn NAME	77
1.10.3	description .TEXT	78



1.10.4	echo-interval <1-36000>	78
1.10.5	gtp bind-ip A.B.C.D	78
1.10.6	gtp control-ip A.B.C.D	79
1.10.7	gtp state-dir PATH	79
1.10.8	gtp user-ip A.B.C.D	79
1.10.9	no apn NAME	80
1.10.10	no default-apn	80
1.10.11	no description	80
1.10.12	no echo-interval	81
1.10.13	no shutdown ggsn	81
1.10.14	show sgsn	81
1.10.15	shutdown ggsn	82
1.10.16	timer [(gtp)] [TNNNN] [(<0-2147483647> default)]	82
1.11	config-ggsn-apn	82
1.11.1	description .TEXT	82
1.11.2	g-pdu tx-sequence-numbers	83
1.11.3	gtpu-mode (tunlkernel-gtp)	83
1.11.4	ip dns <0-1> A.B.C.D	83
1.11.5	ip ifconfig A.B.C.D/M	84
1.11.6	ip prefix (staticdynamic) A.B.C.D/M	84
1.11.7	ipdown-script PATH	84
1.11.8	ipup-script PATH	85
1.11.9	ipv6 dns <0-1> X:X::X:X	85
1.11.10	ipv6 ifconfig X:X::X:X/M	85
1.11.11	ipv6 link-local X:X::X:X/M	86
1.11.12	ipv6 prefix (staticdynamic) X:X::X:X/M	86
1.11.13	no (iplip6) dns <0-1>	86
1.11.14	no description	87
1.11.15	no g-pdu tx-sequence-numbers	87
1.11.16	no ip ifconfig	88
1.11.17	no ipdown-script	88
1.11.18	no ipup-script	88
1.11.19	no ipv6 ifconfig	89
1.11.20	no ipv6 link-local	89
1.11.21	no shutdown	89
1.11.22	no type-support (v4lv6lv4v6)	90
1.11.23	shutdown	90
1.11.24	tun-device NAME	90
1.11.25	type-support (v4lv6lv4v6)	91

# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list [with-flags]

#### Command

```
list [with-flags]
```

#### Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

---

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.1.6 show vty-attributes

#### Command

```
show vty-attributes
```

#### Parameters

show

Show running system information

vty-attributes

List of VTY attributes

### 1.1.7 show vty-attributes (application|library|global)

#### Command

```
show vty-attributes (application|library|global)
```

#### Parameters

show

Show running system information

vty-attributes

List of VTY attributes

application

Application specific attributes only

library

Library specific attributes only

global

Global attributes only

---

### 1.1.8 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

### 1.1.9 write file [PATH]

Command

```
write file [PATH]
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

### 1.1.10 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.1.11 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

---

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable [expert-mode]

Command

```
enable [expert-mode]
```

Parameters

enable

Turn on privileged mode command

[expert-mode]

Enable the expert mode (show hidden commands)

### 1.2.2 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.3 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

---

### 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.2.6 logging level (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctr...

#### Command

```
logging level (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctr1|lgtp| ↵
lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ↵
lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal)
```



## Parameters

### logging

Configure logging

### level

Set the log level for a specified category

### ip

IP Pool and other groups

### tun

Tunnel interface

### ggsn

GGSN

### sgsn

SGSN Emulator

### icmp6

ICMPv6

### lglobal

Library-internal global log family

### llapd

LAPD in libosmogsm

### linp

A-bis Input Subsystem

### lmux

A-bis B-Subchannel TRAU Frame Multiplex

### lmi

A-bis Input Driver for Signalling

### lmib

A-bis Input Driver for B-Channels (voice)

### lsms

Layer3 Short Message Service (SMS)

### lctrl

Control Interface

### lgtp

GPRS GTP library

### lstats

Statistics messages and logging

### lgsup

Generic Subscriber Update Protocol

### loap

Osmocom Authentication Protocol

---

---

lss7  
libosmo-sigtran Signalling System 7

lscpp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lndata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
libosmocore IO Subsystem

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.2.7 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.2.8 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

---

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.9 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.2.10 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.12 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.13 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.2.14 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.2.15 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.16 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

##### 0

Don't prefix each log message

##### 1

Prefix each log message with current timestamp

### 1.2.17 logp (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|ls...

#### Command

```
logp (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵
lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata|lnssignal| ↵
liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal) .LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs

---

ip  
IP Pool and other groups

tun  
Tunnel interface

ggsn  
GGSN

sgsn  
SGSN Emulator

icmp6  
ICMPv6

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

---



---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnssignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
libosmocore IO Subsystem

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

---

### 1.2.18 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.19 show alarms

#### Command

```
show alarms
```

#### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.20 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

---

### 1.2.21 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.2.22 show ggsn [NAME]

#### Command

```
show ggsn [NAME]
```

#### Parameters

show

Show running system information

ggsn

Display information on the GGSN

[NAME]

(null)

### 1.2.23 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.2.24 show logging vty

#### Command

```
show logging vty
```

#### Parameters

show

Show running system information

logging

Show current logging configuration

vtty

Show current logging configuration for this vty

### 1.2.25 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.2.26 show pdp-context ggsn NAME

#### Command

```
show pdp-context ggsn NAME
```

#### Parameters

show

Show running system information

pdp-context

Show PDP Context Information

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

---

### 1.2.27 show pdp-context ggsn NAME apn APN

#### Command

```
show pdp-context ggsn NAME apn APN
```

#### Parameters

show

Show running system information

pdp-context

Show PDP Context Information

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

apn

Filter by APN

APN

APN name

### 1.2.28 show pdp-context ggsn NAME imsi IMSI [<0-15>]

#### Command

```
show pdp-context ggsn NAME imsi IMSI [<0-15>]
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

imsi

PDP contexts for given IMSI

IMSI

PDP context for given NSAPI

[<0-15>]

(null)

---

### 1.2.29 show pdp-context ggsn NAME ipv4 A.B.C.D

#### Command

```
show pdp-context ggsn NAME ipv4 A.B.C.D
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

ipv4

IPv4 address type

A.B.C.D

IP address

### 1.2.30 show pid

#### Command

```
show pid
```

#### Parameters

show

Show running system information

pid

Displays the process ID

### 1.2.31 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

[skip-zero]

Skip items with total count zero

### 1.2.32 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

[skip-zero]

Skip items with total count zero

### 1.2.33 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

[skip-zero]

Skip items with total count zero

---

### 1.2.34 show talloc-context (application|global|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.2.35 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled



full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

### 1.2.36 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.2.37 show timer [(gtp)] [TNNNN]

#### Command

```
show timer [(gtp)] [TNNNN]
```

#### Parameters

##### show

Show running system information

##### timer

Show timers

##### [gtp]

GTP (libgtp) timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.38 show uptime

#### Command

```
show uptime
```

#### Parameters

##### show

Show running system information

##### uptime

Displays how long the program has been running

### 1.2.39 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

---

### 1.2.40 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.41 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.2.42 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

---

### 1.3.1 **configure [terminal]**

#### Command

```
configure [terminal]
```

#### Parameters

##### configure

Configuration from vty interface

##### [terminal]

Configuration terminal

### 1.3.2 **copy running-config startup-config**

#### Command

```
copy running-config startup-config
```

#### Parameters

##### copy

Copy configuration

##### running-config

Copy running config to...

##### startup-config

Copy running config to startup config (same as write file)

### 1.3.3 **disable**

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

---

### 1.3.4 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.3.5 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

---

### 1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.3.8 logging level (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctr...

#### Command

```
logging level (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp| ↵  
lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ↵  
lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### ip

IP Pool and other groups

##### tun

Tunnel interface

##### ggsn

GGSN

---

sgsn  
SGSN Emulator

icmp6  
ICMPv6

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

---

ljibuf	libosmo-netif Jitter Buffer
lrspro	Remote SIM protocol
lns	GPRS NS layer
lbssgp	GPRS BSSGP layer
lnsdata	GPRS NS layer data PDU
lnssignal	GPRS NS layer signal PDU
liuup	Iu UP layer
lpfcp	libosmo-pfcp Packet Forwarding Control Protocol
lcsn1	libosmo-csn1 Concrete Syntax Notation 1 codec
lio	libosmocore IO Subsystem
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

### 1.3.9 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging



#### level

Set the log level for a specified category

#### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

#### debug

Log debug messages and higher levels

#### info

Log informational messages and higher levels

#### notice

Log noticeable messages and higher levels

#### error

Log error messages and higher levels

#### fatal

Log only fatal messages

### 1.3.10 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

---

### 1.3.11 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.3.12 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.13 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.14 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.15 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.3.16 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.3.17 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.18 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

##### 0

Don't prefix each log message

##### 1

Prefix each log message with current timestamp

### 1.3.19 logp (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|ls...

#### Command

```
logp (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵
    lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata|lnssignal| ↵
    liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal) .LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs

---

ip  
IP Pool and other groups

tun  
Tunnel interface

ggsn  
GGSN

sgsn  
SGSN Emulator

icmp6  
ICMPv6

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

---

---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnssignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
libosmocore IO Subsystem

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

---

### 1.3.20 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.21 show alarms

#### Command

```
show alarms
```

#### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.3.22 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

---



### 1.3.23 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.3.24 show ggsn [NAME]

#### Command

```
show ggsn [NAME]
```

#### Parameters

show

Show running system information

ggsn

Display information on the GGSN

[NAME]

(null)

### 1.3.25 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.3.26 show logging vty

#### Command

```
show logging vty
```

#### Parameters

show

Show running system information

logging

Show current logging configuration

vtty

Show current logging configuration for this vty

### 1.3.27 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.3.28 show pdp-context ggsn NAME

#### Command

```
show pdp-context ggsn NAME
```

#### Parameters

show

Show running system information

pdp-context

Show PDP Context Information

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

---

### 1.3.29 show pdp-context ggsn NAME apn APN

#### Command

```
show pdp-context ggsn NAME apn APN
```

#### Parameters

show

Show running system information

pdp-context

Show PDP Context Information

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

apn

Filter by APN

APN

APN name

### 1.3.30 show pdp-context ggsn NAME imsi IMSI [<0-15>]

#### Command

```
show pdp-context ggsn NAME imsi IMSI [<0-15>]
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

imsi

PDP contexts for given IMSI

IMSI

PDP context for given NSAPI

[<0-15>]

(null)

---

### 1.3.31 show pdp-context ggsn NAME ipv4 A.B.C.D

#### Command

```
show pdp-context ggsn NAME ipv4 A.B.C.D
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

ggsn

Gateway GPRS Support NODE (GGSN)

NAME

GGSN Name

ipv4

IPv4 address type

A.B.C.D

IP address

### 1.3.32 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

[skip-zero]

Skip items with total count zero

### 1.3.33 show startup-config

#### Command

```
show startup-config
```

#### Parameters

show

Show running system information

startup-config

Contentes of startup configuration

### 1.3.34 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### [skip-zero]

Skip items with total count zero

### 1.3.35 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### level

Set the maximum group level

##### global

Show global groups only

##### peer

Show global and network peer related groups

##### subscriber

Show global, peer, and subscriber groups

##### [skip-zero]

Skip items with total count zero

---

### 1.3.36 show talloc-context (application|global|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.3.37 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

### 1.3.38 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.3.39 show timer [(gtp)] [TNNNN]

#### Command

```
show timer [(gtp)] [TNNNN]
```

#### Parameters

##### show

Show running system information

##### timer

Show timers

##### [gtp]

GTP (libgtp) timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.3.40 show version

#### Command

```
show version
```

#### Parameters

##### show

Show running system information

##### version

Displays program version

### 1.3.41 shutdown

#### Command

```
shutdown
```

#### Parameters

##### shutdown

Request a shutdown of the program



### 1.3.42 stats report

#### Command

```
stats report
```

#### Parameters

##### stats

Stats related commands

##### report

Manurally trigger reporting of stats

### 1.3.43 stats reset

#### Command

```
stats reset
```

#### Parameters

##### stats

Stats related commands

##### reset

Reset all rate counter stats

### 1.3.44 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

---

### 1.3.45 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.46 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.3.47 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

---

### 1.3.48 who

#### Command

```
who
```

#### Parameters

who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

banner

Set banner string

motd

Strings for motd

default

Default string

### 1.4.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

banner

Set banner

motd

Banner for motd

file

Banner from a file

[FILE]

Filename

### 1.4.3 cpu-sched

#### Command

```
cpu-sched
```

#### Parameters

cpu-sched

Configure CPU Scheduler related settings

### 1.4.4 ctrl

#### Command

```
ctrl
```

#### Parameters

ctrl

Configure the Control Interface

### 1.4.5 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN 'enable' password string

---

### 1.4.6 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.7 ggsn NAME

#### Command

```
ggsn NAME
```

#### Parameters

##### ggsn

Configure the Gateway GPRS Support Node

##### NAME

GGSN Name (has only local significance)

### 1.4.8 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.4.9 line vty

#### Command

```
line vty
```

#### Parameters

line

Configure a terminal line

vtty

Virtual terminal

### 1.4.10 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.11 log file FILENAME [blocking-io]

#### Command

```
log file FILENAME [blocking-io]
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

[blocking-io]

Use blocking, synchronous I/O

---

### 1.4.12 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.13 log stderr [blocking-io]

#### Command

```
log stderr [blocking-io]
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

[blocking-io]

Use blocking, synchronous I/O

### 1.4.14 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

#### 1.4.15 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

#### 1.4.16 log systemd-journal [raw]

Command

```
log systemd-journal [raw]
```

Parameters

---



log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

[raw]

Offload rendering of the meta information (location, category) to systemd

### 1.4.17 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.4.18 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.19 no ggsn NAME

#### Command

```
no ggsn NAME
```

#### Parameters

no

Negate a command or set its defaults

ggsn

Remove the named Gateway GPRS Support Node

NAME

GGSN Name (has only local significance)

### 1.4.20 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.21 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.22 no log file FILENAME

#### Command

```
no log file FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

### 1.4.23 no log gsmtap [HOSTNAME]

#### Command

```
no log gsmtap [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.24 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

---

### 1.4.25 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.26 no log systemd-journal

#### Command

```
no log systemd-journal
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

### 1.4.27 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

---

### 1.4.28 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

### 1.4.29 no stats reporter log [NAME]

#### Command

```
no stats reporter log [NAME]
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.30 no stats reporter statsd [NAME]

#### Command

```
no stats reporter statsd [NAME]
```

#### Parameters

---

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

### 1.4.31 password (8|) WORD

Command

```
password (8|) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

### 1.4.32 password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

### 1.4.33 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

### 1.4.34 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

### 1.4.35 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.36 stats interval <0-65535>

#### Command

```
stats interval <0-65535>
```

#### Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<0-65535>

Interval in seconds (0 disables the reporting interval)

### 1.4.37 stats reporter log [NAME]

#### Command

```
stats reporter log [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.38 stats reporter statsd [NAME]

#### Command

```
stats reporter statsd [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

---



### 1.4.39 stats-tcp batch-size <1-65535>

#### Command

```
stats-tcp batch-size <1-65535>
```

#### Parameters

##### stats-tcp

Configure stats sub-system

##### batch-size

Set the number of tcp sockets that are processed per stats polling interval

<1-65535>

Number of sockets per interval

### 1.4.40 stats-tcp interval <0-65535>

#### Command

```
stats-tcp interval <0-65535>
```

#### Parameters

##### stats-tcp

Configure stats sub-system

##### interval

Set the tcp socket stats polling interval

<0-65535>

Interval in seconds (0 disables the polling interval)

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

---

**logging**

Configure logging

**color**

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

**1.5.2 logging filter all (0|1)**

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

**Command**

```
logging filter all (0|1)
```

**Parameters****logging**

Configure logging

**filter**

Filter log messages

**all**

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

**1.5.3 logging level (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctr...****Command**

```
logging level (ip|tun|ggsn|sgsn|icmp6|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp| ↵
lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata| ↵
lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

level  
Set the log level for a specified category

ip  
IP Pool and other groups

tun  
Tunnel interface

ggsn  
GGSN

sgsn  
SGSN Emulator

icmp6  
ICMPv6

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

---

---

- lscpp
  - libosmo-sigtran SCCP Implementation
- lsua
  - libosmo-sigtran SCCP User Adaptation
- lm3ua
  - libosmo-sigtran MTP3 User Adaptation
- lmgcp
  - libosmo-mgcp Media Gateway Control Protocol
- ljibuf
  - libosmo-netif Jitter Buffer
- lrspro
  - Remote SIM protocol
- lns
  - GPRS NS layer
- lbssgp
  - GPRS BSSGP layer
- lnsdata
  - GPRS NS layer data PDU
- lnssignal
  - GPRS NS layer signal PDU
- liuup
  - Iu UP layer
- lpfcp
  - libosmo-pfcp Packet Forwarding Control Protocol
- lcsn1
  - libosmo-csn1 Concrete Syntax Notation 1 codec
- lio
  - libosmocore IO Subsystem
- debug
  - Log debug messages and higher levels
- info
  - Log informational messages and higher levels
- notice
  - Log noticeable messages and higher levels
- error
  - Log error messages and higher levels
- fatal
  - Log only fatal messages

---

### 1.5.4 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.5.5 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

---

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.6 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.5.7 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.8 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.9 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.10 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.11 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID



### 1.5.12 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.13 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

#### Command

```
disable
```

#### Parameters

disable

Disable the reporter

---

### 1.6.2 enable

#### Command

```
enable
```

#### Parameters

enable

Enable the reporter

### 1.6.3 flush-period <0-65535>

#### Command

```
flush-period <0-65535>
```

#### Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush) every N-th reporting interval. Set to 0 to disable regular flush (default).

### 1.6.4 level (global|peer|subscriber)

#### Command

```
level (global|peer|subscriber)
```

#### Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

---

### 1.6.5 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.6 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

### 1.6.7 no local-ip

#### Command

```
no local-ip
```

#### Parameters

##### no

Negate a command or set its defaults

##### local-ip

Set the IP address to which we bind locally

### 1.6.8 no mtu

#### Command

```
no mtu
```

#### Parameters

##### no

Negate a command or set its defaults

##### mtu

Set the maximum packet size

---

### 1.6.9 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.10 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.11 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

### 1.6.12 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

---

## 1.7 config-line

Configure parameters of the Telnet/VTY Interface, such as to which IP address it should bind/listen to.

### 1.7.1 bind A.B.C.D [<0-65535>]

Command

```
bind A.B.C.D [<0-65535>]
```

Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

### 1.7.2 login

Command

```
login
```

Parameters

login

Enable password checking

### 1.7.3 no login

Command

```
no login
```

Parameters

no

Negate a command or set its defaults

login

Enable password checking

## 1.8 config-ctrl

Configure parameters of the CTRL Interface, such as to which IP address it should bind/listen to.

---

### 1.8.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

##### bind

Set bind address to listen for Control connections

##### A.B.C.D

Local IP address (default 127.0.0.1)

##### [<0-65535>]

Local TCP port number

## 1.9 config-cpu-sched

### 1.9.1 cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]

#### Command

```
cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### cpu-affinity

Set CPU affinity mask on a (group of) thread(s)

##### self

Set CPU affinity mask on thread running the VTY

##### all

Set CPU affinity mask on all process' threads

##### <0-4294967295>

Set CPU affinity mask on a thread with specified PID

##### THREADNAME

Set CPU affinity mask on a thread with specified thread name

##### CPUHEXMASK

CPU affinity mask

##### [delay]

If set, delay applying the affinity mask now and let the app handle it at a later point

---

## 1.9.2 policy rr <1-32>

### Command

```
policy rr <1-32>
```

### Global attributes

#### Flag: !

This command applies immediately

### Parameters

#### policy

Set the scheduling policy to use for the process

#### rr

Use the SCHED\_RR real-time scheduling algorithm

#### <1-32>

Set the SCHED\_RR real-time priority

## 1.10 config-ggsn

Configure an Instance of a (virtual) GGSN

### 1.10.1 apn NAME

#### Command

```
apn NAME
```

### Parameters

#### apn

APN Configuration

#### NAME

APN Name

### 1.10.2 default-apn NAME

#### Command

```
default-apn NAME
```

### Parameters

#### default-apn

Set a default-APN to be used if no other APN matches

#### NAME

APN Name

---

### 1.10.3 description .TEXT

#### Command

```
description .TEXT
```

#### Parameters

##### description

Save human-readable description of the object

##### .TEXT

Text until the end of the line

### 1.10.4 echo-interval <1-36000>

#### Command

```
echo-interval <1-36000>
```

#### Parameters

##### echo-interval

Gateway GPRS Support NODE (GGSN)

##### <1-36000>

GGSN Number

### 1.10.5 gtp bind-ip A.B.C.D

#### Command

```
gtp bind-ip A.B.C.D
```

#### Parameters

##### gtp

GTP Parameters

##### bind-ip

Set the IP address for the local GTP bind

##### A.B.C.D

IPv4 Address



### 1.10.6 gtp control-ip A.B.C.D

#### Command

```
gtp control-ip A.B.C.D
```

#### Parameters

gtp

GTP Parameters

control-ip

Set the IP address states as local IP in GTP-C messages

A.B.C.D

IPv4 Address

### 1.10.7 gtp state-dir PATH

#### Command

```
gtp state-dir PATH
```

#### Parameters

gtp

GTP Parameters

state-dir

Set the directory for the GTP State file

PATH

Local Directory

### 1.10.8 gtp user-ip A.B.C.D

#### Command

```
gtp user-ip A.B.C.D
```

#### Parameters

gtp

GTP Parameters

user-ip

Set the IP address states as local IP in GTP-U messages

A.B.C.D

IPv4 Address

---

### 1.10.9 no apn NAME

#### Command

```
no apn NAME
```

#### Parameters

no

Negate a command or set its defaults

apn

Remove APN Configuration

NAME

APN Name

### 1.10.10 no default-apn

#### Command

```
no default-apn
```

#### Parameters

no

Negate a command or set its defaults

default-apn

Remove default-APN to be used if no other APN matches

### 1.10.11 no description

#### Command

```
no description
```

#### Parameters

no

Negate a command or set its defaults

description

Remove description of the object

### 1.10.12 no echo-interval

#### Command

```
no echo-interval
```

#### Parameters

no

Gateway GPRS Support NODE (GGSN)

echo-interval

GGSN Number

### 1.10.13 no shutdown ggsn

#### Command

```
no shutdown ggsn
```

#### Parameters

no

Negate a command or set its defaults

shutdown

Gateway GPRS Support NODE (GGSN)

ggsn

Remove the GGSN from administrative shutdown

### 1.10.14 show sgsn

#### Command

```
show sgsn
```

#### Parameters

show

Negate a command or set its defaults

sgsn

Gateway GPRS Support NODE (GGSN)

### 1.10.15 shutdown ggsn

#### Command

```
shutdown ggsn
```

#### Parameters

##### shutdown

Put the GGSN in administrative shutdown

##### ggsn

Gateway GPRS Support NODE (GGSN)

### 1.10.16 timer [(gtp)] [TNNNN] [<0-2147483647>|default]

#### Command

```
timer [(gtp)] [TNNNN] [<0-2147483647>|default]
```

#### Parameters

##### timer

Configure or show timers

##### [gtp]

GTP (libgtp) timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

##### [<0-2147483647>]

New timer value

##### [default]

Set to default timer value

## 1.11 config-ggsn-apn

Configure an Access Point Name (APN) inside a GGSN Instance

### 1.11.1 description .TEXT

#### Command

```
description .TEXT
```

#### Parameters

##### description

Save human-readable description of the object

##### .TEXT

Text until the end of the line

---

### 1.11.2 g-pdu tx-sequence-numbers

#### Command

```
g-pdu tx-sequence-numbers
```

#### Parameters

g-pdu

G-PDU Configuration

tx-sequence-numbers

Enable transmission of G-PDU sequence numbers

### 1.11.3 gtpu-mode (tun|kernel-gtp)

#### Command

```
gtpu-mode (tun|kernel-gtp)
```

#### Parameters

gtpu-mode

Set the Mode for this APN (tun or Linux Kernel GTP)

tun

GTP-U in userspace using TUN device

kernel-gtp

GTP-U in kernel using Linux Kernel GTP

### 1.11.4 ip dns <0-1> A.B.C.D

#### Command

```
ip dns <0-1> A.B.C.D
```

#### Parameters

ip

IP information

dns

Configure DNS Server

<0-1>

primary/secondary DNS

A.B.C.D

IP address of DNS Sever

---

### 1.11.5 ip ifconfig A.B.C.D/M

#### Command

```
ip ifconfig A.B.C.D/M
```

#### Parameters

ip

IP information

ifconfig

GGSN-based interface configuration

A.B.C.D/M

IPv4 Adress/Prefix-Length

### 1.11.6 ip prefix (static|dynamic) A.B.C.D/M

#### Command

```
ip prefix (static|dynamic) A.B.C.D/M
```

#### Parameters

ip

IP information

prefix

Prefix (Network/Netmask)

static

IPv4 Adress/Prefix-Length

dynamic

(null)

A.B.C.D/M

(null)

### 1.11.7 ipdown-script PATH

#### Command

```
ipdown-script PATH
```

#### Parameters

ipdown-script

Configure name/path of ip-down script

PATH

File/Path name of ip-down script

### 1.11.8 ipup-script PATH

#### Command

```
ipup-script PATH
```

#### Parameters

##### ipup-script

Configure name/path of ip-up script

##### PATH

File/Path name of ip-up script

### 1.11.9 ipv6 dns <0-1> X:X::X:X

#### Command

```
ipv6 dns <0-1> X:X::X:X
```

#### Parameters

##### ipv6

IPv6 Information

##### dns

Configure DNS Server

##### <0-1>

primary/secondary DNS

##### X:X::X:X

IP address of DNS Sever

### 1.11.10 ipv6 ifconfig X:X::X:X/M

#### Command

```
ipv6 ifconfig X:X::X:X/M
```

#### Parameters

##### ipv6

IPv6 Information

##### ifconfig

GGSN-based interface configuration

##### X:X::X:X/M

IPv6 Adress/Prefix-Length

---

### 1.11.11 ipv6 link-local X:X::X:X/M

#### Command

```
ipv6 link-local X:X::X:X/M
```

#### Parameters

ipv6

IPv6 Information

link-local

GGSN-based interface configuration

X:X::X:X/M

IPv6 Link-local Adress/Prefix-Length

### 1.11.12 ipv6 prefix (static|dynamic) X:X::X:X/M

#### Command

```
ipv6 prefix (static|dynamic) X:X::X:X/M
```

#### Parameters

ipv6

IPv6 Information

prefix

Prefix (Network/Netmask)

static

IPv6 Address/Prefix-Length

dynamic

(null)

X:X::X:X/M

(null)

### 1.11.13 no (ip|ipv6) dns <0-1>

#### Command

```
no (ip|ipv6) dns <0-1>
```

#### Parameters

no

Negate a command or set its defaults



ip

IP information

ipv6

IPv6 Information

dns

Disable DNS Server

<0-1>

primary/secondary DNS

### 1.11.14 no description

Command

```
no description
```

Parameters

no

Negate a command or set its defaults

description

Remove description of the object

### 1.11.15 no g-pdu tx-sequence-numbers

Command

```
no g-pdu tx-sequence-numbers
```

Parameters

no

Negate a command or set its defaults

g-pdu

G-PDU Configuration

tx-sequence-numbers

Disable transmission of G-PDU sequence numbers

### 1.11.16 no ip ifconfig

#### Command

```
no ip ifconfig
```

#### Parameters

no

Negate a command or set its defaults

ip

IP information

ifconfig

GGSN-based interface configuration

### 1.11.17 no ipdown-script

#### Command

```
no ipdown-script
```

#### Parameters

no

Negate a command or set its defaults

ipdown-script

Disable ip-down script

### 1.11.18 no ipup-script

#### Command

```
no ipup-script
```

#### Parameters

no

Negate a command or set its defaults

ipup-script

Disable ip-up script

### 1.11.19 no ipv6 ifconfig

#### Command

```
no ipv6 ifconfig
```

#### Parameters

no

Negate a command or set its defaults

ipv6

IPv6 Information

ifconfig

GGSN-based interface configuration

### 1.11.20 no ipv6 link-local

#### Command

```
no ipv6 link-local
```

#### Parameters

no

Negate a command or set its defaults

ipv6

IPv6 Information

link-local

GGSN-based interface configuration

### 1.11.21 no shutdown

#### Command

```
no shutdown
```

#### Parameters

no

Negate a command or set its defaults

shutdown

Remove the APN from administrative shutdown

### 1.11.22 no type-support (v4|v6|v4v6)

#### Command

```
no type-support (v4|v6|v4v6)
```

#### Parameters

no

Negate a command or set its defaults

type-support

Disable support for PDP Type

v4

IPv4(-only) PDP Type

v6

IPv6(-only) PDP Type

v4v6

IPv4v6 (dual-stack) PDP Type

### 1.11.23 shutdown

#### Command

```
shutdown
```

#### Parameters

shutdown

Put the APN in administrative shutdown

### 1.11.24 tun-device NAME

#### Command

```
tun-device NAME
```

#### Parameters

tun-device

Configure tun device name

NAME

TUN device name

---

### 1.11.25 type-support (v4|v6|v4v6)

#### Command

```
type-support (v4|v6|v4v6)
```

#### Parameters

##### type-support

Enable support for PDP Type

##### v4

IPv4(-only) PDP Type

##### v6

IPv6(-only) PDP Type

##### v4v6

IPv4v6 (dual-stack) PDP Type