

## **OsmoSGSN VTY Reference**

Copyright © 2013-2014

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

<b>COLLABORATORS</b>
----------------------

	<i>TITLE :</i> OsmoSGSN VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		March 5, 2025	

<b>REVISION HISTORY</b>
-------------------------

NUMBER	DATE	DESCRIPTION	NAME
DRAFT	unknown	Automatically Generated VTY Reference	hf

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list [with-flags]	2
1.1.5	show running-config	3
1.1.6	show vty-attributes	3
1.1.7	show vty-attributes (application library global)	3
1.1.8	write	4
1.1.9	write file [PATH]	4
1.1.10	write memory	4
1.1.11	write terminal	4
1.2	view	5
1.2.1	bssgp bvc nsei <0-65535> bvci <0-65535> reset	5
1.2.2	enable [expert-mode]	5
1.2.3	logging color (0 1)	6
1.2.4	logging disable	6
1.2.5	logging enable	6
1.2.6	logging filter all (0 1)	7
1.2.7	logging filter bvc nsei <0-65535> bvci <0-65535>	7
1.2.8	logging filter nse nsei <0-65535>	8
1.2.9	logging filter nsvc nsvci <0-65535>	8
1.2.10	logging level (mml pagl meas refl gprs llc sndcp sl hcr anap sua v42bis gt prim rrl ...	9
1.2.11	logging level force-all (debug info notice error fatal)	11
1.2.12	logging level set-all (debug info notice error fatal)	12
1.2.13	logging print category (0 1)	13
1.2.14	logging print category-hex (0 1)	13
1.2.15	logging print extended-timestamp (0 1)	14
1.2.16	logging print file (0 1 basename) [last]	14

1.2.17	logging print level (01)	15
1.2.18	logging print thread-id (01)	15
1.2.19	logging set-log-mask MASK	16
1.2.20	logging timestamp (01)	16
1.2.21	logp (mm pag meas ref gprs llc s ndcp sl hcl ranap sua v42bis gt prim ral global ll...)	16
1.2.22	no logging level force-all	19
1.2.23	show alarms	20
1.2.24	show asciidoc counters	20
1.2.25	show bssgp	20
1.2.26	show bssgp nsei <0-65535> [stats]	21
1.2.27	show bssgp stats	21
1.2.28	show cpu-sched threads	21
1.2.29	show cs7 (sua lm3 ualipa) (sctp tcp) [<0-65534>]	22
1.2.30	show cs7 (sua lm3 ualipa) [<0-65534>]	22
1.2.31	show cs7 config	23
1.2.32	show cs7 instance <0-15> as (active all lm3 ualsua)	23
1.2.33	show cs7 instance <0-15> asp	24
1.2.34	show cs7 instance <0-15> asp name ASP_NAME	24
1.2.35	show cs7 instance <0-15> asp-assoc-status	25
1.2.36	show cs7 instance <0-15> asp-assoc-status name ASP_NAME	25
1.2.37	show cs7 instance <0-15> asp-remaddr	26
1.2.38	show cs7 instance <0-15> asp-remaddr name ASP_NAME	26
1.2.39	show cs7 instance <0-15> route [POINT_CODE]	27
1.2.40	show cs7 instance <0-15> route-lookup POINT_CODE from POINT_CODE sls <0-15> [lis...]	27
1.2.41	show cs7 instance <0-15> sccp addressbook	28
1.2.42	show cs7 instance <0-15> sccp connections	28
1.2.43	show cs7 instance <0-15> sccp ssn <0-65535>	29
1.2.44	show cs7 instance <0-15> sccp timers	29
1.2.45	show cs7 instance <0-15> sccp users	30
1.2.46	show cs7 instance <0-15> users	30
1.2.47	show history	31
1.2.48	show llc	31
1.2.49	show logging vty	31
1.2.50	show mm-context all [pdp]	32
1.2.51	show mm-context imsi IMSI [pdp]	32
1.2.52	show ns (nsei nsvc) <0-65535> [stats]	32
1.2.53	show ns binds [stats]	33
1.2.54	show ns entities [stats]	33
1.2.55	show ns persistent	34

1.2.56	show online-help . . . . .	34
1.2.57	show pdp-context all . . . . .	34
1.2.58	show pid . . . . .	35
1.2.59	show rate-counters [skip-zero] . . . . .	35
1.2.60	show sgsn . . . . .	35
1.2.61	show sndec . . . . .	36
1.2.62	show stats [skip-zero] . . . . .	36
1.2.63	show stats level (globalpeer subscriber) [skip-zero] . . . . .	36
1.2.64	show subscriber cache . . . . .	37
1.2.65	show talloc-context (application global all) (full brief DEPTH) . . . . .	37
1.2.66	show talloc-context (application global all) (full brief DEPTH) filter REGEXP . . . . .	38
1.2.67	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS . . . . .	38
1.2.68	show timer [TNNNN] . . . . .	39
1.2.69	show timer gtp [TNNNN] . . . . .	39
1.2.70	show uptime . . . . .	40
1.2.71	show version . . . . .	40
1.2.72	terminal length <0-512> . . . . .	40
1.2.73	terminal no length . . . . .	41
1.2.74	who . . . . .	41
1.3	enable . . . . .	41
1.3.1	bssgp bvc nsei <0-65535> bvci <0-65535> reset . . . . .	41
1.3.2	configure [terminal] . . . . .	42
1.3.3	copy running-config startup-config . . . . .	42
1.3.4	cs7 instance <0-15> asp NAME disconnect . . . . .	43
1.3.5	disable . . . . .	43
1.3.6	logging color (0 1) . . . . .	43
1.3.7	logging disable . . . . .	44
1.3.8	logging enable . . . . .	44
1.3.9	logging filter all (0 1) . . . . .	44
1.3.10	logging filter bvc nsei <0-65535> bvci <0-65535> . . . . .	45
1.3.11	logging filter nse nsei <0-65535> . . . . .	45
1.3.12	logging filter nsvc nsvci <0-65535> . . . . .	46
1.3.13	logging level (mml pagl meas refl gprs llc smd pls hlc ran aps ua v42bis gtp prim all... . . . .	46
1.3.14	logging level force-all (debug info notice error fatal) . . . . .	49
1.3.15	logging level set-all (debug info notice error fatal) . . . . .	49
1.3.16	logging print category (0 1) . . . . .	50
1.3.17	logging print category-hex (0 1) . . . . .	50
1.3.18	logging print extended-timestamp (0 1) . . . . .	51
1.3.19	logging print file (0 1 basename) [last] . . . . .	51

1.3.20	logging print level (01) . . . . .	52
1.3.21	logging print thread-id (01) . . . . .	52
1.3.22	logging set-log-mask MASK . . . . .	53
1.3.23	logging timestamp (01) . . . . .	53
1.3.24	logp (mmlpaglmeasreflgprslclclsndcp slhclranap sualv42bis gtplrimlral global ll... . . . .	54
1.3.25	no logging level force-all . . . . .	56
1.3.26	nse <0-65535> restart-sns . . . . .	57
1.3.27	nsvc <0-65535> (blocklunblocklreset) . . . . .	57
1.3.28	page imsi IMSI . . . . .	58
1.3.29	show alarms . . . . .	58
1.3.30	show asciidoc counters . . . . .	58
1.3.31	show bssgp . . . . .	59
1.3.32	show bssgp nsei <0-65535> [stats] . . . . .	59
1.3.33	show bssgp stats . . . . .	59
1.3.34	show cpu-sched threads . . . . .	60
1.3.35	show cs7 (sualm3ualipa) (sctpltcp) [<0-65534>] . . . . .	60
1.3.36	show cs7 (sualm3ualipa) [<0-65534>] . . . . .	61
1.3.37	show cs7 config . . . . .	61
1.3.38	show cs7 instance <0-15> as (activelalllm3ualsua) . . . . .	61
1.3.39	show cs7 instance <0-15> asp . . . . .	62
1.3.40	show cs7 instance <0-15> asp name ASP_NAME . . . . .	63
1.3.41	show cs7 instance <0-15> asp-assoc-status . . . . .	63
1.3.42	show cs7 instance <0-15> asp-assoc-status name ASP_NAME . . . . .	64
1.3.43	show cs7 instance <0-15> asp-remaddr . . . . .	64
1.3.44	show cs7 instance <0-15> asp-remaddr name ASP_NAME . . . . .	65
1.3.45	show cs7 instance <0-15> route [POINT_CODE] . . . . .	65
1.3.46	show cs7 instance <0-15> route-lookup POINT_CODE from POINT_CODE sls <0-15> [lis... . . . .	66
1.3.47	show cs7 instance <0-15> sccp addressbook . . . . .	66
1.3.48	show cs7 instance <0-15> sccp connections . . . . .	67
1.3.49	show cs7 instance <0-15> sccp ssn <0-65535> . . . . .	67
1.3.50	show cs7 instance <0-15> sccp timers . . . . .	68
1.3.51	show cs7 instance <0-15> sccp users . . . . .	68
1.3.52	show cs7 instance <0-15> users . . . . .	69
1.3.53	show history . . . . .	69
1.3.54	show llc . . . . .	70
1.3.55	show logging vty . . . . .	70
1.3.56	show mm-context all [pdp] . . . . .	70
1.3.57	show mm-context imsi IMSI [pdp] . . . . .	71
1.3.58	show ns (nseilnsvc) <0-65535> [stats] . . . . .	71

1.3.59	show ns binds [stats]	72
1.3.60	show ns entities [stats]	72
1.3.61	show ns persistent	72
1.3.62	show online-help	73
1.3.63	show pdp-context all	73
1.3.64	show rate-counters [skip-zero]	73
1.3.65	show sgsn	74
1.3.66	show sndcp	74
1.3.67	show startup-config	74
1.3.68	show stats [skip-zero]	75
1.3.69	show stats level (globalpeer subscriber) [skip-zero]	75
1.3.70	show subscriber cache	76
1.3.71	show talloc-context (application global all) (full brief DEPTH)	76
1.3.72	show talloc-context (application global all) (full brief DEPTH) filter REGEXP	77
1.3.73	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS	77
1.3.74	show timer [TNNNN]	78
1.3.75	show timer gtp [TNNNN]	78
1.3.76	show version	79
1.3.77	shutdown	79
1.3.78	stats report	79
1.3.79	stats reset	80
1.3.80	terminal length <0-512>	80
1.3.81	terminal monitor	80
1.3.82	terminal no length	81
1.3.83	terminal no monitor	81
1.3.84	update-subscriber imsi IMSI cancel (update-procedure subscription-withdraw)	81
1.3.85	update-subscriber imsi IMSI create	82
1.3.86	update-subscriber imsi IMSI destroy	82
1.3.87	update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC	83
1.3.88	update-subscriber imsi IMSI update-auth-info	83
1.3.89	update-subscriber imsi IMSI update-location-result (ok system-failure data-missi...	84
1.3.90	who	84
1.4	config	85
1.4.1	banner motd default	85
1.4.2	banner motd file [FILE]	85
1.4.3	bssgp	85
1.4.4	cpu-sched	86
1.4.5	cs7 instance <0-15>	86
1.4.6	ctrl	86



1.4.7	enable password (8l) WORD . . . . .	87
1.4.8	enable password LINE . . . . .	87
1.4.9	hostname WORD . . . . .	87
1.4.10	line vty . . . . .	88
1.4.11	log alarms <2-32700> . . . . .	88
1.4.12	log file FILENAME [blocking-io] . . . . .	88
1.4.13	log gsmtap [HOSTNAME] . . . . .	89
1.4.14	log stderr [blocking-io] . . . . .	89
1.4.15	log syslog (authpriv cron daemon ftp lpr mail news user uucp) . . . . .	89
1.4.16	log syslog local <0-7> . . . . .	90
1.4.17	log systemd-journal [raw] . . . . .	90
1.4.18	no banner motd . . . . .	91
1.4.19	no enable password . . . . .	91
1.4.20	no hostname [HOSTNAME] . . . . .	92
1.4.21	no log alarms . . . . .	92
1.4.22	no log file FILENAME . . . . .	92
1.4.23	no log gsmtap [HOSTNAME] . . . . .	93
1.4.24	no log stderr . . . . .	93
1.4.25	no log syslog . . . . .	93
1.4.26	no log systemd-journal . . . . .	94
1.4.27	no service advanced-vty . . . . .	94
1.4.28	no service terminal-length [<0-512>] . . . . .	94
1.4.29	no stats reporter log [NAME] . . . . .	95
1.4.30	no stats reporter statsd [NAME] . . . . .	95
1.4.31	ns . . . . .	95
1.4.32	password (8l) WORD . . . . .	96
1.4.33	password LINE . . . . .	96
1.4.34	service advanced-vty . . . . .	96
1.4.35	service terminal-length <0-512> . . . . .	97
1.4.36	sgsn . . . . .	97
1.4.37	show history . . . . .	97
1.4.38	stats interval <0-65535> . . . . .	98
1.4.39	stats reporter log [NAME] . . . . .	98
1.4.40	stats reporter statsd [NAME] . . . . .	98
1.4.41	stats-tcp batch-size <1-65535> . . . . .	99
1.4.42	stats-tcp interval <0-65535> . . . . .	99
1.5	config-log . . . . .	99
1.5.1	logging color (0 1) . . . . .	99
1.5.2	logging filter all (0 1) . . . . .	100

1.5.3	logging filter bvc nsei <0-65535> bvci <0-65535>	100
1.5.4	logging filter nse nsei <0-65535>	101
1.5.5	logging filter nsvc nsvci <0-65535>	101
1.5.6	logging level (mmlpaglmeasreflgprsllclsndcpplshclranaplsualv42bisltplrimlrall...	102
1.5.7	logging level force-all (debuglinfolnoticeerrorlfatal)	105
1.5.8	logging level set-all (debuglinfolnoticeerrorlfatal)	105
1.5.9	logging print category (0 1)	106
1.5.10	logging print category-hex (0 1)	106
1.5.11	logging print extended-timestamp (0 1)	107
1.5.12	logging print file (0 1 basename) [last]	107
1.5.13	logging print level (0 1)	108
1.5.14	logging print thread-id (0 1)	108
1.5.15	logging timestamp (0 1)	109
1.5.16	no logging level force-all	109
1.6	config-stats	109
1.6.1	disable	109
1.6.2	enable	110
1.6.3	flush-period <0-65535>	110
1.6.4	level (globalpeerlsubscriber)	110
1.6.5	local-ip ADDR	111
1.6.6	mtu <100-65535>	111
1.6.7	no local-ip	111
1.6.8	no mtu	111
1.6.9	no prefix	112
1.6.10	prefix PREFIX	112
1.6.11	remote-ip ADDR	112
1.6.12	remote-port <1-65535>	112
1.7	config-line	113
1.7.1	bind A.B.C.D [<0-65535>]	113
1.7.2	login	113
1.7.3	no login	113
1.8	config-ns	114
1.8.1	bind (frludp) ID	114
1.8.2	ip-sns-default bind ID	114
1.8.3	no bind ID	114
1.8.4	no ip-sns-default bind ID	115
1.8.5	no nse <0-65535>	115
1.8.6	nse <0-65535> [ip-sns-role-sgsn]	115
1.8.7	timer (tns-blockltns-block-retriesltns-resetltns-reset-retriesltns-testltns-aliv...	116

1.8.8	txqueue-max-length <1-4096>	117
1.9	config-bssgp	117
1.10	config-ctrl	117
1.10.1	bind A.B.C.D [<0-65535>]	117
1.11	config-cs7	117
1.11.1	as NAME (sualm3ualipa)	117
1.11.2	asp NAME <0-65535> <0-65535> (sualm3ualipa)	118
1.11.3	asp NAME <0-65535> <0-65535> (sualm3ualipa) (sctp tcp)	119
1.11.4	description .TEXT	119
1.11.5	network-indicator (international   national   reserved   spare)	120
1.11.6	no as NAME	120
1.11.7	no asp NAME	121
1.11.8	no sccp-address NAME	121
1.11.9	point-code POINT_CODE	122
1.11.10	point-code delimiter (default dash)	122
1.11.11	point-code format <1-24> [<1-23>] [<1-22>]	123
1.11.12	point-code format default	123
1.11.13	sccp max-optional-data (<0-999999> standard)	124
1.11.14	sccp-address NAME	124
1.11.15	sccp-timer (conn_est ias iar rell repeat_rell int guard reset reassembly) <1-99999...	125
1.11.16	secondary-pc POINT_CODE	126
1.11.17	xua rkm routing-key-allocation (static-only dynamic-permitted)	126
1.12	config-cs7-as	127
1.12.1	asp NAME	127
1.12.2	description .TEXT	127
1.12.3	no asp NAME	127
1.12.4	no traffic-mode	128
1.12.5	point-code override dpc PC	128
1.12.6	point-code override patch-sccp (disabled both)	128
1.12.7	qos-class <0-7>	129
1.12.8	recovery-timeout <1-2000>	129
1.12.9	routing-key RCONTEXT DPC	130
1.12.10	routing-key RCONTEXT DPC si (aal2 bicc b-isup h248 isup sat-isup sccp tup)	130
1.12.11	routing-key RCONTEXT DPC si (aal2 bicc b-isup h248 isup sat-isup sccp tup) ssn S...	131
1.12.12	routing-key RCONTEXT DPC ssn SSN	132
1.12.13	traffic-mode (broadcast   loadshare   roundrobin   override)	133
1.13	config-cs7-asp	133
1.13.1	block	133
1.13.2	description .TEXT	133

1.13.3	local-ip (A.B.C.D X:X::X:X) [primary]	134
1.13.4	no local-ip (A.B.C.D X:X::X:X)	134
1.13.5	no quirk (no_notify daud_in_asplnm_inactive)	135
1.13.6	no remote-ip (A.B.C.D X:X::X:X)	135
1.13.7	no sctp-param init (num-ostreams max-instreams max-attempts timeout)	136
1.13.8	qos-class <0-7>	136
1.13.9	quirk (no_notify daud_in_asplnm_inactive)	137
1.13.10	remote-ip (A.B.C.D X:X::X:X) [primary]	137
1.13.11	role (sglasplisp)	138
1.13.12	sctp-param init (num-ostreams max-instreams max-attempts timeout) <0-65535>	138
1.13.13	shutdown	139
1.13.14	timer lm (wait_asp_up wait_notify wait_notify_rkm wait_rk_reg_resp) <1-999999>	139
1.13.15	transport-role (client server)	140
1.14	config-cs7-sccpaddr	140
1.14.1	global-title	140
1.14.2	no global-title	140
1.14.3	no point-code	141
1.14.4	no subsystem-number	141
1.14.5	point-code POINT_CODE	142
1.14.6	routing-indicator (GT PC IP)	142
1.14.7	subsystem-number <0-4294967295>	143
1.15	config-cs7-sccpaddr-gt	143
1.15.1	digits DIGITS	143
1.15.2	global-title-indicator <0-15>	143
1.15.3	nature-of-address-indicator <0-127>	144
1.15.4	numbering-plan-indicator <0-15>	144
1.15.5	translation-type <0-255>	145
1.16	config-cpu-sched	145
1.16.1	cpu-affinity (self all <0-4294967295> THREADNAME) CPUHEXMASK [delay]	145
1.16.2	policy rr <1-32>	146
1.17	config-ns-bind	146
1.17.1	accept-dynamic-ip-sns	146
1.17.2	accept-ipaccess	146
1.17.3	dscp <0-63>	147
1.17.4	fr NETIF (fr frnet)	147
1.17.5	ip-sns signalling-weight <0-254> data-weight <0-254>	147
1.17.6	listen (A.B.C.D X:X::X:X) <1-65535>	148
1.17.7	no accept-dynamic-ip-sns	148
1.17.8	no accept-ipaccess	148

1.17.9	no dscp	149
1.17.10	no fr NETIF	149
1.17.11	no listen	149
1.17.12	socket-priority <0-255>	150
1.18	config-ns-nse	150
1.18.1	ip-sns-bind BINDID	150
1.18.2	ip-sns-remote (A.B.C.D X:X::X:X) <1-65535>	150
1.18.3	no ip-sns-bind BINDID	151
1.18.4	no ip-sns-remote (A.B.C.D X:X::X:X) <1-65535>	151
1.18.5	no nsvc fr NETIF dlci <16-1007>	151
1.18.6	no nsvc ipa BIND (A.B.C.D X:X::X:X) <1-65535> nsvci <0-65535>	152
1.18.7	no nsvc nsvci <0-65535>	153
1.18.8	no nsvc udp BIND (A.B.C.D X:X::X:X) <1-65535>	153
1.18.9	nsvc fr NETIF dlci <16-1007> nsvci <0-65535>	154
1.18.10	nsvc ipa BIND (A.B.C.D X:X::X:X) <1-65535> nsvci <0-65535>	154
1.18.11	nsvc udp BIND (A.B.C.D X:X::X:X) <1-65535>	155
1.18.12	nsvc udp BIND (A.B.C.D X:X::X:X) <1-65535> signalling-weight <0-254> data-weight...	155
1.19	config-ggsn	156
1.19.1	access-point-name NAME	156
1.19.2	apn APNAME ggsn <0-255>	156
1.19.3	apn APNAME imsi-prefix IMSIPRE ggsn <0-255>	157
1.19.4	asn1 debug (1 0)	157
1.19.5	asn1 xer-print (1 0)	158
1.19.6	auth-policy (accept-all closed acl-only remote)	158
1.19.7	authentication (optional required)	159
1.19.8	cdr filename NAME	159
1.19.9	cdr interval <1-2147483647>	159
1.19.10	cdr trap	160
1.19.11	compression rfc1144 active slots <1-256>	160
1.19.12	compression rfc1144 passive	160
1.19.13	compression v42bis active direction (mslsgsn both) codewords <512-65535> strlen ...	161
1.19.14	compression v42bis passive	161
1.19.15	cs7-instance-iu <0-15>	162
1.19.16	encryption cipher-plugin-path PATH	162
1.19.17	encryption gea <0-4> [<0-4>] [<0-4>] [<0-4>] [<0-4>]	162
1.19.18	encryption uea <0-2> [<0-2>] [<0-2>]	163
1.19.19	ggsn <0-255> echo-interval <1-36000>	163
1.19.20	ggsn <0-255> gtp-version (0 1)	164
1.19.21	ggsn <0-255> no echo-interval	164

1.19.22 ggsn <0-255> remote-ip A.B.C.D . . . . .	164
1.19.23 ggsn dynamic . . . . .	165
1.19.24 grx-dns-add A.B.C.D . . . . .	165
1.19.25 gsup ipa-name NAME . . . . .	165
1.19.26 gsup oap-id <0-65535> . . . . .	166
1.19.27 gsup oap-k K . . . . .	166
1.19.28 gsup oap-opc OPC . . . . .	167
1.19.29 gsup remote-ip A.B.C.D . . . . .	167
1.19.30 gsup remote-port <0-65535> . . . . .	167
1.19.31 gtp local-ip A.B.C.D . . . . .	168
1.19.32 gtp state-dir PATH . . . . .	168
1.19.33 imsi-acl (add del) IMSI . . . . .	168
1.19.34 iu rab-assign-addr-enc (x213 v4raw) . . . . .	169
1.19.35 mme NAME . . . . .	169
1.19.36 no access-point-name NAME . . . . .	169
1.19.37 no cdr filename . . . . .	170
1.19.38 no cdr trap . . . . .	170
1.19.39 no compression rfc1144 . . . . .	170
1.19.40 no compression v42bis . . . . .	171
1.19.41 no encryption cipher-plugin-path PATH . . . . .	171
1.19.42 no mme NAME . . . . .	171
1.19.43 timer [TNNNN] [(<0-2147483647> default)] . . . . .	172
1.19.44 timer gtp [TNNNN] [(<0-2147483647> default)] . . . . .	172
1.20 config-sgsn-mme . . . . .	173
1.20.1 gtp ran-info-relay <0-999> <0-999> <0-65535> . . . . .	173
1.20.2 gtp ran-info-relay default . . . . .	173
1.20.3 gtp remote-ip A.B.C.D . . . . .	173
1.20.4 gummei <0-999> <0-999> <0-65535> <0-254> . . . . .	174
1.20.5 no gtp ran-info-relay <0-999> <0-999> <0-65535> . . . . .	174
1.20.6 no gtp ran-info-relay default . . . . .	175
1.20.7 no gummei . . . . .	175

# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.



### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list [with-flags]

#### Command

```
list [with-flags]
```

#### Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

---

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.1.6 show vty-attributes

#### Command

```
show vty-attributes
```

#### Parameters

show

Show running system information

vty-attributes

List of VTY attributes

### 1.1.7 show vty-attributes (application|library|global)

#### Command

```
show vty-attributes (application|library|global)
```

#### Parameters

show

Show running system information

vty-attributes

List of VTY attributes

application

Application specific attributes only

library

Library specific attributes only

global

Global attributes only

---

### 1.1.8 write

#### Command

```
write
```

#### Parameters

write

Write running configuration to memory, network, or terminal

### 1.1.9 write file [PATH]

#### Command

```
write file [PATH]
```

#### Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

### 1.1.10 write memory

#### Command

```
write memory
```

#### Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.1.11 write terminal

#### Command

```
write terminal
```

#### Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal

---

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 bssgp bvc nsei <0-65535> bvci <0-65535> reset

#### Command

```
bssgp bvc nsei <0-65535> bvci <0-65535> reset
```

#### Parameters

##### bssgp

Initiate BVC RESET procedure for a given NSEI and BVCI

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

##### <0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

##### <0-65535>

BSSGP Virtual Connection Identifier (BVCI)

##### reset

Perform reset procedure

### 1.2.2 enable [expert-mode]

#### Command

```
enable [expert-mode]
```

#### Parameters

##### enable

Turn on privileged mode command

##### [expert-mode]

Enable the expert mode (show hidden commands)

### 1.2.3 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.4 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.2.5 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

---

### 1.2.6 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.2.7 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

##### <0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

##### <0-65535>

BSSGP Virtual Connection Identifier (BVCI)

---

### 1.2.8 logging filter nse nsei <0-65535>

#### Command

```
logging filter nse nsei <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nse

Filter based on NS Entity

##### nsei

Identify NSE by NSEI

##### <0-65535>

Numeric identifier

### 1.2.9 logging filter nsvc nsvci <0-65535>

#### Command

```
logging filter nsvc nsvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nsvc

Filter based on NS Virtual Connection

##### nsvci

Identify NS-VC by NSVCI

##### <0-65535>

Numeric identifier

### 1.2.10 logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|l...

#### Command

```
logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal| ↔  
llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua| ↔  
lmgcp|ljibuf|lrsprr|lms|lbssgp|lmsdata|lmsignal|liuup|lpfcp|lcsn1|lio) (debug|info ↔  
|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SNDP)

##### slhc

RFC1144 TCP/IP Header compression (SLHC)

##### ranap

RAN Application Part (RANAP)

##### sua

SCCP User Adaptation (SUA)

##### v42bis

V.42bis data compression (SNDP)

##### gtp

GPRS Tunnelling Protocol (GTP)

##### rim

RAN Information Management (RIM)



---

ra  
Routing Area

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

---

lrspro  
Remote SIM protocol

lrs  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lrsdata  
GPRS NS layer data PDU

lrsignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
libosmocore IO Subsystem

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

### 1.2.11 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.2.12 logging level set-all (debug|info|notice|error|fatal)

**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

---

### 1.2.13 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.2.14 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.15 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.16 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.17 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.2.18 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.2.19 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.20 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.2.21 logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal|ll...

#### Command

```
logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal|llapd| ↵
linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp| ↵
ljibuf|lrspro|lns|lbssgp|lndata|lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info| ↵
notice|error|fatal) .LOGMESSAGE
```

#### Parameters

logp  
Print a message on all log outputs; useful for placing markers in test logs

mm  
Layer3 Mobility Management (MM)

pag  
Paging Subsystem

meas  
Radio Measurement Processing

ref  
Reference Counting

gprs  
GPRS Packet Service

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDCP)

slhc  
RFC1144 TCP/IP Header compression (SLHC)

ranap  
RAN Application Part (RANAP)

sua  
SCCP User Adaptation (SUA)

v42bis  
V.42bis data compression (SNDCP)

gtp  
GPRS Tunnelling Protocol (GTP)

rim  
RAN Information Management (RIM)

ra  
Routing Area

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

---



lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

lns

GPRS NS layer

lbssgp

GPRS BSSGP layer

lndata

GPRS NS layer data PDU

lnsignal

GPRS NS layer signal PDU

---

liuup

Iu UP layer

lpfcp

libosmo-pfcp Packet Forwarding Control Protocol

lcsn1

libosmo-csn1 Concrete Syntax Notation 1 codec

lio

libosmocore IO Subsystem

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

.LOGMESSAGE

Arbitrary message to log on given category and log level

### 1.2.22 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.23 show alarms

#### Command

```
show alarms
```

#### Parameters

##### show

Show running system information

##### alarms

Show current logging configuration

### 1.2.24 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

##### show

Show running system information

##### asciidoc

Asciidoc generation

##### counters

Generate table of all registered counters

### 1.2.25 show bssgp

#### Command

```
show bssgp
```

#### Parameters

##### show

Show running system information

##### bssgp

Show information about the BSSGP protocol

### 1.2.26 show bssgp nsei <0-65535> [stats]

#### Command

```
show bssgp nsei <0-65535> [stats]
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

nsei

Show all BVCs on one NSE

<0-65535>

The NSEI

[stats]

Include Statistics

### 1.2.27 show bssgp stats

#### Command

```
show bssgp stats
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

stats

Include statistics

### 1.2.28 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.2.29 show cs7 (sua|m3ua|ipa) (sctp|tcp) [<0-65534>]

#### Command

```
show cs7 (sua|m3ua|ipa) (sctp|tcp) [<0-65534>]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

sctp

SCTP (Stream Control Transmission Protocol)

tcp

TCP (Transmission Control Protocol)

[<0-65534>]

Local Port Number

### 1.2.30 show cs7 (sua|m3ua|ipa) [<0-65534>]

#### Command

```
show cs7 (sua|m3ua|ipa) [<0-65534>]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

[<0-65534>]

Local Port Number

### 1.2.31 show cs7 config

#### Command

```
show cs7 config
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

config

Currently running cs7 configuration

### 1.2.32 show cs7 instance <0-15> as (active|all|m3ua|sua)

#### Command

```
show cs7 instance <0-15> as (active|all|m3ua|sua)
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

as

Application Server (AS)

active

Display all active ASs

all

Display all ASs (default)

m3ua

Display all m3ua ASs

sua

Display all SUA ASs

---

### 1.2.33 show cs7 instance <0-15> asp

#### Command

```
show cs7 instance <0-15> asp
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

asp

Application Server Process (ASP)

### 1.2.34 show cs7 instance <0-15> asp name ASP\_NAME

#### Command

```
show cs7 instance <0-15> asp name ASP_NAME
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

asp

Application Server Process (ASP)

name

Lookup ASP with a given name

ASP\_NAME

Name of the Application Server Process (ASP)

---

### 1.2.35 show cs7 instance <0-15> asp-assoc-status

#### Command

```
show cs7 instance <0-15> asp-assoc-status
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-assoc-status

Application Server Process (ASP) SCTP association status

### 1.2.36 show cs7 instance <0-15> asp-assoc-status name ASP\_NAME

#### Command

```
show cs7 instance <0-15> asp-assoc-status name ASP_NAME
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-assoc-status

Application Server Process (ASP) SCTP association information

##### name

Lookup ASP with a given name

##### ASP\_NAME

Name of the Application Server Process (ASP)

---



### 1.2.37 show cs7 instance <0-15> asp-remaddr

#### Command

```
show cs7 instance <0-15> asp-remaddr
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-remaddr

Application Server Process (ASP) remote addresses information

### 1.2.38 show cs7 instance <0-15> asp-remaddr name ASP\_NAME

#### Command

```
show cs7 instance <0-15> asp-remaddr name ASP_NAME
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-remaddr

Application Server Process (ASP) remote addresses information

##### name

Lookup ASP with a given name

##### ASP\_NAME

Name of the Application Server Process (ASP)

---

### 1.2.39 show cs7 instance <0-15> route [POINT\_CODE]

#### Command

```
show cs7 instance <0-15> route [POINT_CODE]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

route

Routing Table

[POINT\_CODE]

Destination Point Code

### 1.2.40 show cs7 instance <0-15> route-lookup POINT\_CODE from POINT\_CODE sls <0-15> [lis...

#### Command

```
show cs7 instance <0-15> route-lookup POINT_CODE from POINT_CODE sls <0-15> [list-asps]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

route-lookup

Look up route

POINT\_CODE

Destination PC

from

From

POINT\_CODE

Origin PC

sls

SLS

<0-15>

SLS value

[list-asps]

List ASPs of the AS if route points to an AS

### 1.2.41 show cs7 instance <0-15> sccp addressbook

Command

```
show cs7 instance <0-15> sccp addressbook
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

addressbook

List all SCCP addressbook entries

### 1.2.42 show cs7 instance <0-15> sccp connections

Command

```
show cs7 instance <0-15> sccp connections
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

connections

Show List of active SCCP connections

### 1.2.43 show cs7 instance <0-15> sccp ssn <0-65535>

Command

```
show cs7 instance <0-15> sccp ssn <0-65535>
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

ssn

Find an SCCP User registered for the given SSN

<0-65535>

Subsystem Number (SSN)

### 1.2.44 show cs7 instance <0-15> sccp timers

Command

```
show cs7 instance <0-15> sccp timers
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signaling Connection Control Part

timers

Show List of SCCP timers

### 1.2.45 show cs7 instance <0-15> sccp users

Command

```
show cs7 instance <0-15> sccp users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

users

Show List of SCCP Users registered

### 1.2.46 show cs7 instance <0-15> users

Command

```
show cs7 instance <0-15> users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

users

User Table

### 1.2.47 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

### 1.2.48 show llc

Command

```
show llc
```

Parameters

show

Show running system information

llc

Display information about the LLC protocol

### 1.2.49 show logging vty

Command

```
show logging vty
```

Parameters

show

Show running system information

logging

Show current logging configuration

vtty

Show current logging configuration for this vty

### 1.2.50 show mm-context all [pdp]

#### Command

```
show mm-context all [pdp]
```

#### Parameters

show

Show running system information

mm-context

MM Context

all

All MM Contexts

[pdp]

Include PDP Context Information

### 1.2.51 show mm-context imsi IMSI [pdp]

#### Command

```
show mm-context imsi IMSI [pdp]
```

#### Parameters

show

Show running system information

mm-context

MM Context

imsi

Identify by IMSI

IMSI

IMSI of the MM Context

[pdp]

Include PDP Context Information

### 1.2.52 show ns (nsei|nsvc) <0-65535> [stats]

#### Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

#### Parameters

---

show  
    Show running system information

ns  
    Display information about the NS protocol

nsei  
    Select one NSE by its NSE Identifier

nsvc  
    Select one NSE by its NS-VC Identifier

<0-65535>  
    The Identifier of selected type

[stats]  
    Include Statistics

### 1.2.53 show ns binds [stats]

Command

```
show ns binds [stats]
```

Parameters

show  
    Show running system information

ns  
    Display information about the NS protocol

binds  
    Display information about the NS protocol binds

[stats]  
    Include statistic

### 1.2.54 show ns entities [stats]

Command

```
show ns entities [stats]
```

Parameters

show  
    Show running system information

ns  
    Display information about the NS protocol

entities  
    Display information about the NS protocol entities (NSEs)

[stats]  
    Include statistics



### 1.2.55 show ns persistent

#### Command

```
show ns persistent
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

### 1.2.56 show online-help

#### Command

```
show online-help
```

#### Parameters

show

Show running system information

online-help

Online help

### 1.2.57 show pdp-context all

#### Command

```
show pdp-context all
```

#### Parameters

show

Show running system information

pdp-context

Display information on PDP Context

all

Show everything

---

### 1.2.58 show pid

#### Command

```
show pid
```

#### Parameters

##### show

Show running system information

##### pid

Displays the process ID

### 1.2.59 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

##### [skip-zero]

Skip items with total count zero

### 1.2.60 show sgsn

#### Command

```
show sgsn
```

#### Parameters

##### show

Show running system information

##### sgsn

Display information about the SGSN

---

### 1.2.61 show sndcp

#### Command

```
show sndcp
```

#### Parameters

show

Show running system information

sndcp

Display information about the SNDTCP protocol

### 1.2.62 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

[skip-zero]

Skip items with total count zero

### 1.2.63 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

[skip-zero]

Skip items with total count zero

### 1.2.64 show subscriber cache

Command

```
show subscriber cache
```

Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

### 1.2.65 show talloc-context (application|global|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.2.66 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### global

Global context (OTC\_GLOBAL)

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### filter

Filter chunks using regular expression

##### REGEXP

Regular expression

### 1.2.67 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.2.68 show timer [TNNNN]

Command

```
show timer [TNNNN]
```

Parameters

show

Show running system information

timer

Show timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.69 show timer gtp [TNNNN]

Command

```
show timer gtp [TNNNN]
```

Parameters

show

Show running system information

timer

Show timers

gtp

GTP (libgtp) timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.70 show uptime

Command

```
show uptime
```

Parameters

show

Show running system information

uptime

Displays how long the program has been running

### 1.2.71 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

### 1.2.72 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

---

### 1.2.73 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.2.74 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

### 1.3.1 bssgp bvc nsei <0-65535> bvci <0-65535> reset

#### Command

```
bssgp bvc nsei <0-65535> bvci <0-65535> reset
```

#### Parameters

##### bssgp

Initiate BVC RESET procedure for a given NSEI and BVCI

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered



<0-65535>

Network Service Entity Identifier (NSEI)

bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

reset

Perform reset procedure

### 1.3.2 **configure [terminal]**

Command

```
configure [terminal]
```

Parameters

configure

Configuration from vty interface

[terminal]

Configuration terminal

### 1.3.3 **copy running-config startup-config**

Command

```
copy running-config startup-config
```

Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)

---

### 1.3.4 cs7 instance <0-15> asp NAME disconnect

#### Command

```
cs7 instance <0-15> asp NAME disconnect
```

#### Parameters

cs7

ITU-T Signaling System 7

instance

Instance related commands

<0-15>

SS7 Instance Number

asp

ASP related commands

NAME

Name of ASP

disconnect

Disconnect the ASP (client will reconnect)

### 1.3.5 disable

#### Command

```
disable
```

#### Parameters

disable

Turn off privileged mode command

### 1.3.6 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

---

### 1.3.7 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.8 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.3.9 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

---

### 1.3.10 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### bvc

Filter based on BSSGP Virtual Connection

##### nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

##### bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

### 1.3.11 logging filter nse nsei <0-65535>

#### Command

```
logging filter nse nsei <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nse

Filter based on NS Entity

##### nsei

Identify NSE by NSEI

<0-65535>

Numeric identifier

### 1.3.12 logging filter nsvc nsvci <0-65535>

#### Command

```
logging filter nsvc nsvci <0-65535>
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### nsvc

Filter based on NS Virtual Connection

##### nsvci

Identify NS-VC by NSVCI

##### <0-65535>

Numeric identifier

### 1.3.13 logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|l...

#### Command

```
logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal| ↵
llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua| ↵
lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info ↵
|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

---

llc  
GPRS Logical Link Control Protocol (LLC)

sndcp  
GPRS Sub-Network Dependent Control Protocol (SNDCP)

slhc  
RFC1144 TCP/IP Header compression (SLHC)

ranap  
RAN Application Part (RANAP)

sua  
SCCP User Adaptation (SUA)

v42bis  
V.42bis data compression (SNDCP)

gtp  
GPRS Tunnelling Protocol (GTP)

rim  
RAN Information Management (RIM)

ra  
Routing Area

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

---

---

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnssignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
libosmocore IO Subsystem

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

---

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.14 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.15 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging



**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.3.16 logging print category (0|1)

**Command**

```
logging print category (0|1)
```

**Parameters****logging**

Configure logging

**print**

Log output settings

**category**

Configure log message

**0**

Don't prefix each log message

**1**

Prefix each log message with category/subsystem name

### 1.3.17 logging print category-hex (0|1)

**Command**

```
logging print category-hex (0|1)
```

**Parameters**

---

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.18 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.19 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.20 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.3.21 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.3.22 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.23 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.3.24 logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal|ll...

#### Command

```
logp (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal|llapd| ↵  
linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lsccp|lsua|lm3ua|lmgcp| ↵  
ljibuf|lrspro|lns|lbssgp|lndata|lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info| ↵  
notice|error|fatal) .LOGMESSAGE
```

#### Parameters

##### logp

Print a message on all log outputs; useful for placing markers in test logs

##### mm

Layer3 Mobility Management (MM)

##### pag

Paging Subsystem

##### meas

Radio Measurement Processing

##### ref

Reference Counting

##### gprs

GPRS Packet Service

##### llc

GPRS Logical Link Control Protocol (LLC)

##### sndcp

GPRS Sub-Network Dependent Control Protocol (SND CP)

##### slhc

RFC1144 TCP/IP Header compression (SLHC)

##### ranap

RAN Application Part (RANAP)

##### sua

SCCP User Adaptation (SUA)

##### v42bis

V.42bis data compression (SND CP)

##### gtp

GPRS Tunnelling Protocol (GTP)

##### rim

RAN Information Management (RIM)

##### ra

Routing Area

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

---

lms  
    GPRS NS layer

lbssgp  
    GPRS BSSGP layer

lmsdata  
    GPRS NS layer data PDU

lmsignal  
    GPRS NS layer signal PDU

liuup  
    Iu UP layer

lpfcp  
    libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
    libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
    libosmocore IO Subsystem

debug  
    Log debug messages and higher levels

info  
    Log informational messages and higher levels

notice  
    Log noticeable messages and higher levels

error  
    Log error messages and higher levels

fatal  
    Log only fatal messages

.LOGMESSAGE  
    Arbitrary message to log on given category and log level

### 1.3.25 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.26 nse <0-65535> restart-sns

Command

```
nse <0-65535> restart-sns
```

Parameters

nse

NSE specific commands

<0-65535>

NS Entity ID (NSEI)

restart-sns

Restart SNS procedure

### 1.3.27 nsvc <0-65535> (block|unblock|reset)

Command

```
nsvc <0-65535> (block|unblock|reset)
```

Parameters

nsvc

NS Virtual Connection

<0-65535>

NS Virtual Connection ID (NS-VCI)

block

Block a NSVC. As cause code O&M intervention will be used.

unblock

Unblock a NSVC. As cause code O&M intervention will be used.

reset

Reset a NSVC. As cause code O&M intervention will be used.



### 1.3.28 page imsi IMSI

#### Command

```
page imsi IMSI
```

#### Parameters

##### page

Send a PS paging request to subscriber

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

### 1.3.29 show alarms

#### Command

```
show alarms
```

#### Parameters

##### show

Show running system information

##### alarms

Show current logging configuration

### 1.3.30 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

##### show

Show running system information

##### asciidoc

Asciidoc generation

##### counters

Generate table of all registered counters

---

### 1.3.31 show bssgp

#### Command

```
show bssgp
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

### 1.3.32 show bssgp nsei <0-65535> [stats]

#### Command

```
show bssgp nsei <0-65535> [stats]
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

nsei

Show all BVCs on one NSE

<0-65535>

The NSEI

[stats]

Include Statistics

### 1.3.33 show bssgp stats

#### Command

```
show bssgp stats
```

#### Parameters

show

Show running system information

bssgp

Show information about the BSSGP protocol

stats

Include statistics

### 1.3.34 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.3.35 show cs7 (sua|m3ua|ipa) (sctp|tcp) [<0-65534>]

#### Command

```
show cs7 (sua|m3ua|ipa) (sctp|tcp) [<0-65534>]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

sctp

SCTP (Stream Control Transmission Protocol)

tcp

TCP (Transmission Control Protocol)

[<0-65534>]

Local Port Number

---

### 1.3.36 show cs7 (sua|m3ua|ipa) [<0-65534>]

#### Command

```
show cs7 (sua|m3ua|ipa) [<0-65534>]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

[<0-65534>]

Local Port Number

### 1.3.37 show cs7 config

#### Command

```
show cs7 config
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

config

Currently running cs7 configuration

### 1.3.38 show cs7 instance <0-15> as (active|all|m3ua|sua)

#### Command

```
show cs7 instance <0-15> as (active|all|m3ua|sua)
```

#### Parameters

---

show  
    Show running system information

cs7  
    ITU-T Signaling System 7

instance  
    An instance of the SS7 stack

<0-15>  
    An instance of the SS7 stack

as  
    Application Server (AS)

active  
    Display all active ASs

all  
    Display all ASs (default)

m3ua  
    Display all m3ua ASs

sua  
    Display all SUA ASs

### 1.3.39 show cs7 instance <0-15> asp

#### Command

```
show cs7 instance <0-15> asp
```

#### Parameters

show  
    Show running system information

cs7  
    ITU-T Signaling System 7

instance  
    An instance of the SS7 stack

<0-15>  
    An instance of the SS7 stack

asp  
    Application Server Process (ASP)

### 1.3.40 show cs7 instance <0-15> asp name ASP\_NAME

#### Command

```
show cs7 instance <0-15> asp name ASP_NAME
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp

Application Server Process (ASP)

##### name

Lookup ASP with a given name

##### ASP\_NAME

Name of the Application Server Process (ASP)

### 1.3.41 show cs7 instance <0-15> asp-assoc-status

#### Command

```
show cs7 instance <0-15> asp-assoc-status
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-assoc-status

Application Server Process (ASP) SCTP association status

---

### 1.3.42 show cs7 instance <0-15> asp-assoc-status name ASP\_NAME

#### Command

```
show cs7 instance <0-15> asp-assoc-status name ASP_NAME
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-assoc-status

Application Server Process (ASP) SCTP association information

##### name

Lookup ASP with a given name

##### ASP\_NAME

Name of the Application Server Process (ASP)

### 1.3.43 show cs7 instance <0-15> asp-remaddr

#### Command

```
show cs7 instance <0-15> asp-remaddr
```

#### Parameters

##### show

Show running system information

##### cs7

ITU-T Signaling System 7

##### instance

An instance of the SS7 stack

##### <0-15>

An instance of the SS7 stack

##### asp-remaddr

Application Server Process (ASP) remote addresses information

---

### 1.3.44 show cs7 instance <0-15> asp-remaddr name ASP\_NAME

#### Command

```
show cs7 instance <0-15> asp-remaddr name ASP_NAME
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

asp-remaddr

Application Server Process (ASP) remote addresses information

name

Lookup ASP with a given name

ASP\_NAME

Name of the Application Server Process (ASP)

### 1.3.45 show cs7 instance <0-15> route [POINT\_CODE]

#### Command

```
show cs7 instance <0-15> route [POINT_CODE]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

route

Routing Table

[POINT\_CODE]

Destination Point Code



### 1.3.46 show cs7 instance <0-15> route-lookup POINT\_CODE from POINT\_CODE sls <0-15> [lis...

#### Command

```
show cs7 instance <0-15> route-lookup POINT_CODE from POINT_CODE sls <0-15> [list-asps]
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

route-lookup

Look up route

POINT\_CODE

Destination PC

from

From

POINT\_CODE

Origin PC

sls

SLS

<0-15>

SLS value

[list-asps]

List ASPs of the AS if route points to an AS

### 1.3.47 show cs7 instance <0-15> sccp addressbook

#### Command

```
show cs7 instance <0-15> sccp addressbook
```

#### Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

addressbook

List all SCCP addressbook entries

### 1.3.48 show cs7 instance <0-15> sccp connections

Command

```
show cs7 instance <0-15> sccp connections
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

connections

Show List of active SCCP connections

### 1.3.49 show cs7 instance <0-15> sccp ssn <0-65535>

Command

```
show cs7 instance <0-15> sccp ssn <0-65535>
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

ssn

Find an SCCP User registered for the given SSN

<0-65535>

Subsystem Number (SSN)

### 1.3.50 show cs7 instance <0-15> sccp timers

Command

```
show cs7 instance <0-15> sccp timers
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signaling Connection Control Part

timers

Show List of SCCP timers

### 1.3.51 show cs7 instance <0-15> sccp users

Command

```
show cs7 instance <0-15> sccp users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

sccp

Signalling Connection Control Part

users

Show List of SCCP Users registered

### 1.3.52 show cs7 instance <0-15> users

Command

```
show cs7 instance <0-15> users
```

Parameters

show

Show running system information

cs7

ITU-T Signaling System 7

instance

An instance of the SS7 stack

<0-15>

An instance of the SS7 stack

users

User Table

### 1.3.53 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

### 1.3.54 show llc

#### Command

```
show llc
```

#### Parameters

##### show

Show running system information

##### llc

Display information about the LLC protocol

### 1.3.55 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

### 1.3.56 show mm-context all [pdp]

#### Command

```
show mm-context all [pdp]
```

#### Parameters

##### show

Show running system information

##### mm-context

MM Context

##### all

All MM Contexts

##### [pdp]

Include PDP Context Information

---

### 1.3.57 show mm-context imsi IMSI [pdp]

#### Command

```
show mm-context imsi IMSI [pdp]
```

#### Parameters

show

Show running system information

mm-context

MM Context

imsi

Identify by IMSI

IMSI

IMSI of the MM Context

[pdp]

Include PDP Context Information

### 1.3.58 show ns (nsei|nsvc) <0-65535> [stats]

#### Command

```
show ns (nsei|nsvc) <0-65535> [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

nsei

Select one NSE by its NSE Identifier

nsvc

Select one NSE by its NS-VC Identifier

<0-65535>

The Identifier of selected type

[stats]

Include Statistics

### 1.3.59 show ns binds [stats]

#### Command

```
show ns binds [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

binds

Display information about the NS protocol binds

[stats]

Include statistic

### 1.3.60 show ns entities [stats]

#### Command

```
show ns entities [stats]
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

entities

Display information about the NS protocol entities (NSEs)

[stats]

Include statistics

### 1.3.61 show ns persistent

#### Command

```
show ns persistent
```

#### Parameters

show

Show running system information

ns

Display information about the NS protocol

persistent

Show only persistent NS

### 1.3.62 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.3.63 show pdp-context all

#### Command

```
show pdp-context all
```

#### Parameters

##### show

Show running system information

##### pdp-context

Display information on PDP Context

##### all

Show everything

### 1.3.64 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

##### [skip-zero]

Skip items with total count zero

---



### 1.3.65 show sgsn

#### Command

```
show sgsn
```

#### Parameters

##### show

Show running system information

##### sgsn

Display information about the SGSN

### 1.3.66 show sndcp

#### Command

```
show sndcp
```

#### Parameters

##### show

Show running system information

##### sndcp

Display information about the SND CP protocol

### 1.3.67 show startup-config

#### Command

```
show startup-config
```

#### Parameters

##### show

Show running system information

##### startup-config

Content of startup configuration

### 1.3.68 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

[skip-zero]

Skip items with total count zero

### 1.3.69 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

[skip-zero]

Skip items with total count zero

---

### 1.3.70 show subscriber cache

#### Command

```
show subscriber cache
```

#### Parameters

show

Show running system information

subscriber

Show information about subscribers

cache

Display contents of subscriber cache

### 1.3.71 show talloc-context (application|global|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

---

### 1.3.72 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### global

Global context (OTC\_GLOBAL)

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### filter

Filter chunks using regular expression

##### REGEXP

Regular expression

### 1.3.73 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.3.74 show timer [TNNNN]

Command

```
show timer [TNNNN]
```

Parameters

show

Show running system information

timer

Show timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.3.75 show timer gtp [TNNNN]

Command

```
show timer gtp [TNNNN]
```

Parameters

show

Show running system information

timer

Show timers

gtp

GTP (libgtp) timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.3.76 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

### 1.3.77 shutdown

Command

```
shutdown
```

Parameters

shutdown

Request a shutdown of the program

### 1.3.78 stats report

Command

```
stats report
```

Parameters

stats

Stats related commands

report

Manurally trigger reporting of stats

### 1.3.79 stats reset

#### Command

```
stats reset
```

#### Parameters

##### stats

Stats related commands

##### reset

Reset all rate counter stats

### 1.3.80 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.3.81 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.82 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.3.83 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.3.84 update-subscriber imsi IMSI cancel (update-procedure|subscription-withdraw)

#### Command

```
update-subscriber imsi IMSI cancel (update-procedure|subscription-withdraw)
```

#### Parameters

##### update-subscriber

Update subscriber list

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

---



cancel

Cancel (remove) subscriber record

update-procedure

The MS moved to another SGSN

subscription-withdraw

The subscription is no longer valid

### 1.3.85 update-subscriber imsi IMSI create

Command

```
update-subscriber imsi IMSI create
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

create

Create a subscriber entry

### 1.3.86 update-subscriber imsi IMSI destroy

Command

```
update-subscriber imsi IMSI destroy
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

destroy

Destroy a subscriber entry

### 1.3.87 update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC

#### Command

```
update-subscriber imsi IMSI insert auth-triplet <1-5> sres SRES rand RAND kc KC
```

#### Parameters

##### update-subscriber

Update subscriber list

##### imsi

Use the IMSI to select the subscriber

##### IMSI

The IMSI

##### insert

Insert data into the subscriber record

##### auth-triplet

Update authentication triplet

##### <1-5>

Triplet index

##### sres

Set SRES value

##### SRES

SRES value (4 byte) in hex

##### rand

Set RAND value

##### RAND

RAND value (16 byte) in hex

##### kc

Set Kc value

##### KC

Kc value (8 byte) in hex

### 1.3.88 update-subscriber imsi IMSI update-auth-info

#### Command

```
update-subscriber imsi IMSI update-auth-info
```

#### Parameters

##### update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

update-auth-info

Complete the send authentication info procedure

### 1.3.89 update-subscriber imsi IMSI update-location-result (ok|system-failure|data-missi...

Command

```
update-subscriber imsi IMSI update-location-result (ok|system-failure|data-missing| ←  
unexpected-data-value|unknown-subscriber|roaming-not-allowed)
```

Parameters

update-subscriber

Update subscriber list

imsi

Use the IMSI to select the subscriber

IMSI

The IMSI

update-location-result

Complete the update location procedure

ok

The update location request succeeded

system-failure

Force error code SystemFailure

data-missing

Force error code DataMissing

unexpected-data-value

Force error code UnexpectedDataValue

unknown-subscriber

Force error code UnknownSubscriber

roaming-not-allowed

Force error code RoamingNotAllowed

### 1.3.90 who

Command

```
who
```

Parameters

who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

### 1.4.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

##### banner

Set banner

##### motd

Banner for motd

##### file

Banner from a file

##### [FILE]

Filename

### 1.4.3 bssgp

#### Command

```
bssgp
```

#### Parameters

##### bssgp

Configure the GPRS BSS Gateway Protocol

### 1.4.4 cpu-sched

#### Command

```
cpu-sched
```

#### Parameters

cpu-sched

Configure CPU Scheduler related settings

### 1.4.5 cs7 instance <0-15>

#### Command

```
cs7 instance <0-15>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cs7

ITU-T Signaling System 7

instance

Configure a SS7 Instance

<0-15>

An instance of the SS7 stack

### 1.4.6 ctrl

#### Command

```
ctrl
```

#### Parameters

ctrl

Configure the Control Interface

### 1.4.7 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN 'enable' password string

### 1.4.8 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.9 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

---

### 1.4.10 line vty

#### Command

```
line vty
```

#### Parameters

line

Configure a terminal line

vtty

Virtual terminal

### 1.4.11 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.12 log file FILENAME [blocking-io]

#### Command

```
log file FILENAME [blocking-io]
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

[blocking-io]

Use blocking, synchronous I/O

---

### 1.4.13 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.14 log stderr [blocking-io]

#### Command

```
log stderr [blocking-io]
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

[blocking-io]

Use blocking, synchronous I/O

### 1.4.15 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility



cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

#### 1.4.16 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

#### 1.4.17 log systemd-journal [raw]

Command

```
log systemd-journal [raw]
```

Parameters

---

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

[raw]

Offload rendering of the meta information (location, category) to systemd

#### 1.4.18 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

#### 1.4.19 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.20 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.21 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.22 no log file FILENAME

#### Command

```
no log file FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

### 1.4.23 no log gsmtap [HOSTNAME]

#### Command

```
no log gsmtap [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.24 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.25 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

---

### 1.4.26 no log systemd-journal

#### Command

```
no log systemd-journal
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

### 1.4.27 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.28 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

---

### 1.4.29 no stats reporter log [NAME]

#### Command

```
no stats reporter log [NAME]
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.30 no stats reporter statsd [NAME]

#### Command

```
no stats reporter statsd [NAME]
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

### 1.4.31 ns

#### Command

```
ns
```

#### Parameters

ns

Configure the GPRS Network Service

---

### 1.4.32 password (8|) WORD

#### Command

```
password (8|) WORD
```

#### Parameters

##### password

Assign the terminal connection password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN line password string

### 1.4.33 password LINE

#### Command

```
password LINE
```

#### Parameters

##### password

Assign the terminal connection password

##### LINE

The UNENCRYPTED (cleartext) line password

### 1.4.34 service advanced-vty

#### Command

```
service advanced-vty
```

#### Parameters

##### service

Set up miscellaneous service

##### advanced-vty

Enable advanced mode vty interface

### 1.4.35 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

### 1.4.36 sgsn

#### Command

```
sgsn
```

#### Parameters

##### sgsn

Configure the SGSN

### 1.4.37 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history



### 1.4.38 stats interval <0-65535>

#### Command

```
stats interval <0-65535>
```

#### Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<0-65535>

Interval in seconds (0 disables the reporting interval)

### 1.4.39 stats reporter log [NAME]

#### Command

```
stats reporter log [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.40 stats reporter statsd [NAME]

#### Command

```
stats reporter statsd [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

---

### 1.4.41 stats-tcp batch-size <1-65535>

#### Command

```
stats-tcp batch-size <1-65535>
```

#### Parameters

##### stats-tcp

Configure stats sub-system

##### batch-size

Set the number of tcp sockets that are processed per stats polling interval

<1-65535>

Number of sockets per interval

### 1.4.42 stats-tcp interval <0-65535>

#### Command

```
stats-tcp interval <0-65535>
```

#### Parameters

##### stats-tcp

Configure stats sub-system

##### interval

Set the tcp socket stats polling interval

<0-65535>

Interval in seconds (0 disables the polling interval)

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

---

## logging

Configure logging

## color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

## logging

Configure logging

## filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.5.3 logging filter bvc nsei <0-65535> bvci <0-65535>

#### Command

```
logging filter bvc nsei <0-65535> bvci <0-65535>
```

#### Parameters

## logging

Configure logging

filter

Filter log messages

bvc

Filter based on BSSGP Virtual Connection

nsei

NSEI of the BVC to be filtered

<0-65535>

Network Service Entity Identifier (NSEI)

bvci

BVCI of the BVC to be filtered

<0-65535>

BSSGP Virtual Connection Identifier (BVCI)

#### 1.5.4 logging filter nse nsei <0-65535>

Command

```
logging filter nse nsei <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nse

Filter based on NS Entity

nsei

Identify NSE by NSEI

<0-65535>

Numeric identifier

#### 1.5.5 logging filter nsvc nsvci <0-65535>

Command

```
logging filter nsvc nsvci <0-65535>
```

Parameters

logging

Configure logging

filter

Filter log messages

nsvc

Filter based on NS Virtual Connection

nsvci

Identify NS-VC by NSVCI

<0-65535>

Numeric identifier

## 1.5.6 logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|l...

Command

```
logging level (mm|pag|meas|ref|gprs|llc|sndcp|slhc|ranap|sua|v42bis|gtp|rim|ra|lglobal| ↔
llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscdp|lsua|lm3ua| ↔
lmgcp|ljibuf|lrspro|lns|lbssgp|lndata|lnssignal|liuup|lpfcp|lcsn1|lio) (debug|info ↔
|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

mm

Layer3 Mobility Management (MM)

pag

Paging Subsystem

meas

Radio Measurement Processing

ref

Reference Counting

gprs

GPRS Packet Service

llc

GPRS Logical Link Control Protocol (LLC)

sndcp

GPRS Sub-Network Dependent Control Protocol (SNDP)

slhc

RFC1144 TCP/IP Header compression (SLHC)

ranap

RAN Application Part (RANAP)

---

sua  
    SCCP User Adaptation (SUA)

v42bis  
    V.42bis data compression (SNDTCP)

gtp  
    GPRS Tunnelling Protocol (GTP)

rim  
    RAN Information Management (RIM)

ra  
    Routing Area

lglobal  
    Library-internal global log family

llapd  
    LAPD in libosmogsm

linp  
    A-bis Input Subsystem

lmux  
    A-bis B-Subchannel TRAU Frame Multiplex

lmi  
    A-bis Input Driver for Signalling

lmib  
    A-bis Input Driver for B-Channels (voice)

lsms  
    Layer3 Short Message Service (SMS)

lctrl  
    Control Interface

lgtp  
    GPRS GTP library

lstats  
    Statistics messages and logging

lgsup  
    Generic Subscriber Update Protocol

loap  
    Osmocom Authentication Protocol

lss7  
    libosmo-sigtran Signalling System 7

lsccp  
    libosmo-sigtran SCCP Implementation

---

---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnssignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

lio  
libosmocore IO Subsystem

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.5.7 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.5.8 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

---



info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.9 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.5.10 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.12 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.13 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.14 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.5.15 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.16 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

#### Command

```
disable
```

#### Parameters

disable

Disable the reporter

---

### 1.6.2 enable

#### Command

```
enable
```

#### Parameters

enable

Enable the reporter

### 1.6.3 flush-period <0-65535>

#### Command

```
flush-period <0-65535>
```

#### Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush) every N-th reporting interval. Set to 0 to disable regular flush (default).

### 1.6.4 level (global|peer|subscriber)

#### Command

```
level (global|peer|subscriber)
```

#### Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

---

### 1.6.5 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.6 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

### 1.6.7 no local-ip

#### Command

```
no local-ip
```

#### Parameters

##### no

Negate a command or set its defaults

##### local-ip

Set the IP address to which we bind locally

### 1.6.8 no mtu

#### Command

```
no mtu
```

#### Parameters

##### no

Negate a command or set its defaults

##### mtu

Set the maximum packet size

---

### 1.6.9 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.10 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.11 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

### 1.6.12 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

---

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

### 1.7.2 login

#### Command

```
login
```

#### Parameters

login

Enable password checking

### 1.7.3 no login

#### Command

```
no login
```

#### Parameters

no

Negate a command or set its defaults

login

Enable password checking



## 1.8 config-ns

### 1.8.1 bind (fr|udp) ID

#### Command

```
bind (fr|udp) ID
```

#### Parameters

##### bind

Configure local Bind

##### fr

Frame Relay

##### udp

UDP/IP

##### ID

Unique identifier for this bind (to reference from NS-VCs, NSEs, ...)

### 1.8.2 ip-sns-default bind ID

#### Command

```
ip-sns-default bind ID
```

#### Parameters

##### ip-sns-default

Defaults for dynamically created NSEs created by IP-SNS in SGSN role

##### bind

IP SNS binds

##### ID

Name of NS udp bind whose IP endpoint will be used as IP-SNS local endpoint. Can be given multiple times.

### 1.8.3 no bind ID

#### Command

```
no bind ID
```

#### Parameters

##### no

Negate a command or set its defaults

##### bind

Delete a bind

##### ID

Unique identifier for this bind

---

### 1.8.4 no ip-sns-default bind ID

#### Command

```
no ip-sns-default bind ID
```

#### Parameters

no

Negate a command or set its defaults

ip-sns-default

Defaults for dynamically created NSEs created by IP-SNS in SGSN role

bind

IP SNS binds

ID

Name of NS udp bind whose IP endpoint will be removed as IP-SNS local endpoint.

### 1.8.5 no nse <0-65535>

#### Command

```
no nse <0-65535>
```

#### Parameters

no

Negate a command or set its defaults

nse

Delete a Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

### 1.8.6 nse <0-65535> [ip-sns-role-sgsn]

#### Command

```
nse <0-65535> [ip-sns-role-sgsn]
```

#### Parameters

nse

Persistent NS Entity

<0-65535>

NS Entity ID (NSEI)

[ip-sns-role-sgsn]

Create NSE in SGSN role (default: BSS)

---

## 1.8.7 timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-aliv...

### Command

```
timer (tns-block|tns-block-retries|tns-reset|tns-reset-retries|tns-test|tns-alive|tns- ↵
    alive-retries|tsns-prov|tsns-size-retries|tsns-config-retries|tsns-procedures- ↵
    retries) <0-65535>
```

### Parameters

#### timer

Network Service Timer

#### tns-block

(un)blocking Timer (Tns-block) timeout

#### tns-block-retries

(un)blocking Timer (Tns-block) number of retries

#### tns-reset

Reset Timer (Tns-reset) timeout

#### tns-reset-retries

Reset Timer (Tns-reset) number of retries

#### tns-test

Test Timer (Tns-test) timeout

#### tns-alive

Alive Timer (Tns-alive) timeout

#### tns-alive-retries

Alive Timer (Tns-alive) number of retries

#### tsns-prov

SNS Provision Timer (Tsns-prov) timeout

#### tsns-size-retries

SNS Size number of retries

#### tsns-config-retries

SNS Config number of retries

#### tsns-procedures-retries

SNS Procedures number of retries

#### <0-65535>

Timer Value

### 1.8.8 txqueue-max-length <1-4096>

#### Command

```
txqueue-max-length <1-4096>
```

#### Parameters

##### txqueue-max-length

Set the maximum length of the txqueue (for UDP)

<1-4096>

Maximum length of the txqueue

## 1.9 config-bssgp

## 1.10 config-ctrl

### 1.10.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

##### bind

Set bind address to listen for Control connections

##### A.B.C.D

Local IP address (default 127.0.0.1)

[<0-65535>]

Local TCP port number

## 1.11 config-cs7

### 1.11.1 as NAME (sua|m3ua|ipa)

#### Command

```
as NAME (sua|m3ua|ipa)
```

#### Global attributes

Flag: !

This command applies immediately

---

### Parameters

as

Configure an Application Server

NAME

Name of the Application Server

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

## 1.11.2 asp NAME <0-65535> <0-65535> (sua|m3ua|ipa)

### Command

```
asp NAME <0-65535> <0-65535> (sua|m3ua|ipa)
```

### Global attributes

Flag: @

This command applies on VTY node exit

### Parameters

asp

Configure Application Server Process

NAME

Name of ASP

<0-65535>

Remote port number

<0-65535>

Local port number

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

### 1.11.3 asp NAME <0-65535> <0-65535> (sua|m3ua|ipa) (sctp|tcp)

#### Command

```
asp NAME <0-65535> <0-65535> (sua|m3ua|ipa) (sctp|tcp)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

asp

Configure Application Server Process

NAME

Name of ASP

<0-65535>

Remote port number

<0-65535>

Local port number

sua

SCCP User Adaptation

m3ua

MTP3 User Adaptation

ipa

IPA Multiplex (SCCP Lite)

sctp

SCTP (Stream Control Transmission Protocol)

tcp

TCP (Transmission Control Protocol)

### 1.11.4 description .TEXT

#### Command

```
description .TEXT
```

#### Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

---

### 1.11.5 network-indicator (international | national | reserved | spare)

#### Command

```
network-indicator (international | national | reserved | spare)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

network-indicator

Configure the Network Indicator

international

International Network

national

National Network

reserved

Reserved Network

spare

Spare Network

### 1.11.6 no as NAME

#### Command

```
no as NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

as

Disable Application Server

NAME

Name of AS

### 1.11.7 no asp NAME

#### Command

```
no asp NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

asp

Disable Application Server Process

NAME

Name of ASP

### 1.11.8 no sccp-address NAME

#### Command

```
no sccp-address NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

sccp-address

Delete an SCCP addressbook entry

NAME

Name of the SCCP Address



### 1.11.9 point-code POINT\_CODE

#### Command

```
point-code POINT_CODE
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Configure the local Point Code

POINT\_CODE

Point Code

### 1.11.10 point-code delimiter (default|dash)

#### Command

```
point-code delimiter (default|dash)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code

delimiter

Configure Point Code Delimiter

default

Use dot as delimiter

dash

User dash as delimiter

### 1.11.11 point-code format <1-24> [<1-23>] [<1-22>]

#### Command

```
point-code format <1-24> [<1-23>] [<1-22>]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code

format

Configure Point Code Format

<1-24>

Length of first PC component

[<1-23>]

Length of second PC component

[<1-22>]

Length of third PC component

### 1.11.12 point-code format default

#### Command

```
point-code format default
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code

format

Configure Point Code Format

default

Default Point Code Format (3.8.3)

---

### 1.11.13 sccp max-optional-data (<0-999999>|standard)

#### Command

```
sccp max-optional-data (<0-999999>|standard)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

sccp

Configure SCCP behavior

max-optional-data

Adjust the upper bound for the optional data length (the payload) for CR, CC, CREF and RLSD messages. For any Optional Data part larger than this value in octets, send CR, CC, CREF and RLSD messages without any payload, and send the data payload in a separate Data Form 1 message. ITU-T Q.713 sections 4.2 thru 4.5 define a limit of 130 bytes for the 'Data' parameter. This limit can be adjusted here. May be useful for interop with nonstandard SCCP peers.

<0-999999>

Set a non-standard maximum allowed number of bytes

standard

Use the ITU-T Q.713 4.2 to 4.5 standard value of 130

### 1.11.14 sccp-address NAME

#### Command

```
sccp-address NAME
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

sccp-address

Create/Modify an SCCP addressbook entry

NAME

Name of the SCCP Address

### 1.11.15 sccp-timer (conn\_est|ias|iar|rel|repeat\_rel|int|guard|reset|reassembly) <1-99999...

#### Command

```
sccp-timer (conn_est|ias|iar|rel|repeat_rel|int|guard|reset|reassembly) <1-999999>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### sccp-timer

Configure SCCP timer values, see ITU-T Q.714

##### conn\_est

Waiting for connection confirm message, 1 to 2 minutes (default: 60)

##### ias

Send keep-alive: on an idle connection, delay before sending an Idle Timer message, 5 to 10 minutes (default: 420)

##### iar

Receive keep-alive: on an idle connection, delay until considering a connection as stale, 11 to 21 minutes (default: 900)

##### rel

Waiting for release complete message, 10 to 20 seconds (default: 10)

##### repeat\_rel

Waiting for release complete message; or to repeat sending released message after the initial expiry, 10 to 20 seconds (default: 10)

##### int

Waiting for release complete message; or to release connection resources, freeze the LRN and alert a maintenance function after the initial expiry, extending to 1 minute (default: 60)

##### guard

Waiting to resume normal procedure for temporary connection sections during the restart procedure, 23 to 25 minutes (default: 1380)

##### reset

Waiting to release temporary connection section or alert maintenance function after reset request message is sent, 10 to 20 seconds (default: 10)

##### reassembly

Waiting to receive all the segments of the remaining segments, single segmented message after receiving the first segment, 10 to 20 seconds (default: 10)

##### <1-999999>

Timer value, in seconds

---

### 1.11.16 secondary-pc POINT\_CODE

#### Command

```
secondary-pc POINT_CODE
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

secondary-pc

Configure the local Secondary Point Code

POINT\_CODE

Point Code

### 1.11.17 xua rkm routing-key-allocation (static-only|dynamic-permitted)

#### Command

```
xua rkm routing-key-allocation (static-only|dynamic-permitted)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

xua

SIGTRAN xxxUA related

rkm

Routing Key Management

routing-key-allocation

Routing Key Management Allocation Policy

static-only

Only static (pre-configured) Routing Keys permitted

dynamic-permitted

Dynamically allocate Routing Keys for what ASPs request

---

## 1.12 config-cs7-as

### 1.12.1 asp NAME

Command

```
asp NAME
```

Global attributes

Flag: !

This command applies immediately

Parameters

asp

Specify that a given ASP is part of this AS

NAME

Name of ASP to be added to AS

### 1.12.2 description .TEXT

Command

```
description .TEXT
```

Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

### 1.12.3 no asp NAME

Command

```
no asp NAME
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

asp

Specify ASP to be removed from this AS

NAME

Name of ASP to be removed

### 1.12.4 no traffic-mode

#### Command

```
no traffic-mode
```

#### Parameters

no

Negate a command or set its defaults

traffic-mode

Remove explicit traffic mode of operation of this AS

### 1.12.5 point-code override dpc PC

#### Command

```
point-code override dpc PC
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Point Code Specific Features

override

Override (force) a point-code to hard-coded value

dpc

Override Source Point Code

PC

Override Destination Point Code

### 1.12.6 point-code override patch-sccp (disabled|both)

#### Command

```
point-code override patch-sccp (disabled|both)
```

#### Global attributes

Flag: !

This command applies immediately

---

#### Parameters

##### point-code

Point Code Specific Features

##### override

Override (force) a point-code to hard-coded value

##### patch-sccp

Patch point code values into SCCP called/calling address

##### disabled

Don't patch any point codes into SCCP called/calling address

##### both

Patch both origin and destination point codes into SCCP called/calling address

### 1.12.7 qos-class <0-7>

#### Command

```
qos-class <0-7>
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### qos-class

Specity QoS Class of AS

##### <0-7>

QoS Class

### 1.12.8 recovery-timeout <1-2000>

#### Command

```
recovery-timeout <1-2000>
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### recovery-timeout

Specifies the recovery timeout value in milliseconds

##### <1-2000>

Recovery Timeout in Milliseconds



### 1.12.9 routing-key RCONTEXT DPC

#### Command

```
routing-key RCONTEXT DPC
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### routing-key

Define a routing key

##### RCONTEXT

Routing context number

##### DPC

Destination Point Code

### 1.12.10 routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup)

#### Command

```
routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### routing-key

Define a routing key

##### RCONTEXT

Routing context number

##### DPC

Destination Point Code

##### si

Match on Service Indicator

##### aal2

ATM Adaption Layer 2

##### bicc

Bearer Independent Call Control

b-isup

Broadband ISDN User Part

h248

H.248

isup

ISDN User Part

sat-isup

Sattelite ISDN User Part

sccp

Signalling Connection Control Part

tup

Telephony User Part

### 1.12.11 routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup) ssn S...

Command

```
routing-key RCONTEXT DPC si (aal2|bicc|b-isup|h248|isup|sat-isup|sccp|tup) ssn SSN
```

Global attributes

Flag: !

This command applies immediately

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

si

Match on Service Indicator

aal2

ATM Adaption Layer 2

bicc

Bearer Independent Call Control

b-isup

Broadband ISDN User Part

h248

H.248

isup

ISDN User Part

sat-isup

Sattelite ISDN User Part

sccp

Signalling Connection Control Part

tup

Telephony User Part

ssn

Match on Sub-System Number

SSN

Sub-System Number to match on

### 1.12.12 routing-key RCONTEXT DPC ssn SSN

Command

```
routing-key RCONTEXT DPC ssn SSN
```

Global attributes

Flag: !

This command applies immediately

Parameters

routing-key

Define a routing key

RCONTEXT

Routing context number

DPC

Destination Point Code

ssn

Match on Sub-System Number

SSN

Sub-System Number to match on

### 1.12.13 traffic-mode (broadcast | loadshare | roundrobin | override)

#### Command

```
traffic-mode (broadcast | loadshare | roundrobin | override)
```

#### Parameters

##### traffic-mode

Specifies traffic mode of operation of the ASP within the AS

##### broadcast

Broadcast to all ASP within AS

##### loadshare

Share Load among all ASP within AS

##### roundrobin

Round-Robin between all ASP within AS

##### override

Override

## 1.13 config-cs7-asp

### 1.13.1 block

#### Command

```
block
```

#### Global attributes

##### Flag: @

This command applies on VTY node exit

#### Parameters

##### block

Allows a SCTP Association with ASP, but doesn't let it become active

### 1.13.2 description .TEXT

#### Command

```
description .TEXT
```

#### Parameters

##### description

Save human-readable description of the object

##### .TEXT

Text until the end of the line

---

### 1.13.3 local-ip (A.B.C.D|X:X::X:X) [primary]

#### Command

```
local-ip (A.B.C.D|X:X::X:X) [primary]
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

local-ip

Specify Local IP Address from which to contact ASP

A.B.C.D

Local IPv4 Address from which to contact of ASP

X:X::X:X

Local IPv6 Address from which to contact of ASP

[primary]

Signal the SCTP peer to use this address as Primary Address

### 1.13.4 no local-ip (A.B.C.D|X:X::X:X)

#### Command

```
no local-ip (A.B.C.D|X:X::X:X)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

no

Negate a command or set its defaults

local-ip

Specify Local IP Address from which to contact ASP

A.B.C.D

Local IPv4 Address from which to contact of ASP

X:X::X:X

Local IPv6 Address from which to contact of ASP

### 1.13.5 no quirk (no\_notify|daud\_in\_asp|snm\_inactive)

#### Command

```
no quirk (no_notify|daud_in_asp|snm_inactive)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

quirk

Disable quirk to work around interop issues

no\_notify

Peer SG doesn't send NTFY(AS-INACTIVE) after ASP-UP

daud\_in\_asp

Allow Rx of DAUD in ASP role

snm\_inactive

Allow Rx of [S]SNM in AS-INACTIVE state

### 1.13.6 no remote-ip (A.B.C.D|X:X::X:X)

#### Command

```
no remote-ip (A.B.C.D|X:X::X:X)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

no

Negate a command or set its defaults

remote-ip

Specify Remote IP Address of ASP

A.B.C.D

Remote IPv4 Address of ASP

X:X::X:X

Remote IPv6 Address of ASP

### 1.13.7 no sctp-param init (num-ostreams|max-instreams|max-attempts|timeout)

#### Command

```
no sctp-param init (num-ostreams|max-instreams|max-attempts|timeout)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

no

Negate a command or set its defaults

sctp-param

Configure SCTP parameters

init

Configure INIT related parameters

num-ostreams

Configure INIT Number of Outbound Streams

max-instreams

Configure INIT Maximum Inboud Streams

max-attempts

Configure INIT Maximum Attempts

timeout

Configure INIT Timeout (milliseconds)

### 1.13.8 qos-class <0-7>

#### Command

```
qos-class <0-7>
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

qos-class

Specify QoS Class of ASP

<0-7>

QoS Class

---

### 1.13.9 quirk (no\_notify|daud\_in\_asp|snm\_inactive)

#### Command

```
quirk (no_notify|daud_in_asp|snm_inactive)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### quirk

Enable quirk to work around interop issues

##### no\_notify

Peer SG doesn't send NTFY(AS-INACTIVE) after ASP-UP

##### daud\_in\_asp

Allow Rx of DAUD in ASP role

##### snm\_inactive

Allow Rx of [S]SNM in AS-INACTIVE state

### 1.13.10 remote-ip (A.B.C.D|X:X::X:X) [primary]

#### Command

```
remote-ip (A.B.C.D|X:X::X:X) [primary]
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

##### remote-ip

Specify Remote IP Address of ASP

##### A.B.C.D

Remote IPv4 Address of ASP

##### X:X::X:X

Remote IPv6 Address of ASP

##### [primary]

Set remote address as SCTP Primary Address

---



### 1.13.11 role (sg|asp|ipsp)

#### Command

```
role (sg|asp|ipsp)
```

#### Global attributes

#### Flag: @

This command applies on VTY node exit

#### Parameters

##### role

Specify the xUA role for this ASP

##### sg

SG (Signaling Gateway)

##### asp

ASP (Application Server Process)

##### ipsp

IPSP (IP Signalling Point)

### 1.13.12 sctp-param init (num-ostreams|max-instreams|max-attempts|timeout) <0-65535>

#### Command

```
sctp-param init (num-ostreams|max-instreams|max-attempts|timeout) <0-65535>
```

#### Global attributes

#### Flag: @

This command applies on VTY node exit

#### Parameters

##### sctp-param

Configure SCTP parameters

##### init

Configure INIT related parameters

##### num-ostreams

Configure INIT Number of Outbound Streams

##### max-instreams

Configure INIT Maximum Inboud Streams

##### max-attempts

Configure INIT Maximum Attempts

##### timeout

Configure INIT Timeout (milliseconds)

##### <0-65535>

Value of the parameter

---

### 1.13.13 shutdown

#### Command

```
shutdown
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

shutdown

Terminates SCTP association; New associations will be rejected

### 1.13.14 timer lm (wait\_asp\_up|wait\_notify|wait\_notify\_rkm|wait\_rk\_reg\_resp) <1-999999>

#### Command

```
timer lm (wait_asp_up|wait_notify|wait_notify_rkm|wait_rk_reg_resp) <1-999999>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

timer

Configure ASP default timer values

lm

Configure ASP default lm timer values

wait\_asp\_up

Restart ASP after timeout waiting for ASP UP (SG role) / ASP UP ACK (ASP role) (s) (default: 20)

wait\_notify

Restart ASP after timeout waiting for NOTIFY (s) (default: 2)

wait\_notify\_rkm

Restart ASP after timeout waiting for NOTIFY after RKM registration (s) (default: 20)

wait\_rk\_reg\_resp

Restart ASP after timeout waiting for RK\_REG\_RESP (s) (default: 10)

<1-999999>

Timer value, in seconds

### 1.13.15 transport-role (client|server)

#### Command

```
transport-role (client|server)
```

#### Global attributes

Flag: @

This command applies on VTY node exit

#### Parameters

##### transport-role

Specify the transport layer role for this ASP

##### client

Operate as a client; connect to a server

##### server

Operate as a server; wait for client connections

## 1.14 config-cs7-sccpaddr

### 1.14.1 global-title

#### Command

```
global-title
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

##### global-title

Add/Modify Global Title

### 1.14.2 no global-title

#### Command

```
no global-title
```

#### Global attributes

---

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

global-title

Remove Global Title

### 1.14.3 no point-code

Command

```
no point-code
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

point-code

Remove point-code Number

### 1.14.4 no subsystem-number

Command

```
no subsystem-number
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

subsystem-number

Remove Subsystem Number

### 1.14.5 point-code POINT\_CODE

#### Command

```
point-code POINT_CODE
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

point-code

Add point-code Number

POINT\_CODE

PC

### 1.14.6 routing-indicator (GT|PC|IP)

#### Command

```
routing-indicator (GT|PC|IP)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

routing-indicator

Add Routing Indicator

GT

by global-title

PC

by point-code

IP

by ip-address

### 1.14.7 subsystem-number <0-4294967295>

#### Command

```
subsystem-number <0-4294967295>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

subsystem-number

Add Subsystem Number

<0-4294967295>

SSN

## 1.15 config-cs7-sccpaddr-gt

### 1.15.1 digits DIGITS

#### Command

```
digits DIGITS
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

digits

Set Global Title Digits

DIGITS

Number digits

### 1.15.2 global-title-indicator <0-15>

#### Command

```
global-title-indicator <0-15>
```

#### Global attributes

---

Flag: !

This command applies immediately

Parameters

global-title-indicator

Set Global Title Indicator

<0-15>

GTI

### 1.15.3 nature-of-address-indicator <0-127>

Command

```
nature-of-address-indicator <0-127>
```

Global attributes

Flag: !

This command applies immediately

Parameters

nature-of-address-indicator

Set Global Title Nature of Address Indicator

<0-127>

NAI

### 1.15.4 numbering-plan-indicator <0-15>

Command

```
numbering-plan-indicator <0-15>
```

Global attributes

Flag: !

This command applies immediately

Parameters

numbering-plan-indicator

Set Global Title Numbering Plan Indicator

<0-15>

NPI

### 1.15.5 translation-type <0-255>

#### Command

```
translation-type <0-255>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

translation-type

Set Global Title Translation Type

<0-255>

TT

## 1.16 config-cpu-sched

### 1.16.1 cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]

#### Command

```
cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

cpu-affinity

Set CPU affinity mask on a (group of) thread(s)

self

Set CPU affinity mask on thread running the VTY

all

Set CPU affinity mask on all process' threads

<0-4294967295>

Set CPU affinity mask on a thread with specified PID

THREADNAME

Set CPU affinity mask on a thread with specified thread name

CPUHEXMASK

CPU affinity mask

[delay]

If set, delay applying the affinity mask now and let the app handle it at a later point

---



## 1.16.2 policy rr <1-32>

### Command

```
policy rr <1-32>
```

### Global attributes

#### Flag: !

This command applies immediately

### Parameters

#### policy

Set the scheduling policy to use for the process

#### rr

Use the SCHED\_RR real-time scheduling algorithm

#### <1-32>

Set the SCHED\_RR real-time priority

## 1.17 config-ns-bind

### 1.17.1 accept-dynamic-ip-sns

#### Command

```
accept-dynamic-ip-sns
```

#### Parameters

##### accept-dynamic-ip-sns

Allow to create dynamic NS Entities by IP-SNS PDUs

### 1.17.2 accept-ipaccess

#### Command

```
accept-ipaccess
```

#### Parameters

##### accept-ipaccess

Allow to create dynamic NS Entity by NS Reset PDU on UDP (ip.access style)

---

### 1.17.3 dscp <0-63>

#### Command

```
dscp <0-63>
```

#### Parameters

dscp

Set DSCP/TOS on the UDP socket

<0-63>

DSCP Value

### 1.17.4 fr NETIF (fr|frnet)

#### Command

```
fr NETIF (fr|frnet)
```

#### Parameters

fr

frame relay

NETIF

Interface name(e.g. ep0)

fr

fr (user) is used by BSS or SGSN attached to UNI of a FR network

frnet

frnet (network) is used by SGSN if BSS is directly attached

### 1.17.5 ip-sns signalling-weight <0-254> data-weight <0-254>

#### Command

```
ip-sns signalling-weight <0-254> data-weight <0-254>
```

#### Parameters

ip-sns

IP SNS

signalling-weight

signalling weight used by IP-SNS dynamic configuration

<0-254>

signalling weight used by IP-SNS dynamic configuration

data-weight

data weight used by IP-SNS dynamic configuration

<0-254>

data weight used by IP-SNS dynamic configuration

### 1.17.6 listen (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
listen (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

##### listen

Configure local IP + Port of this bind

##### A.B.C.D

Local IPv4 Address

##### X:X::X:X

Local IPv6 Address

##### <1-65535>

Local UDP Port

### 1.17.7 no accept-dynamic-ip-sns

#### Command

```
no accept-dynamic-ip-sns
```

#### Parameters

##### no

Negate a command or set its defaults

##### accept-dynamic-ip-sns

Disable dynamic creation of NS Entities by IP-SNS PDUs

### 1.17.8 no accept-ipaccess

#### Command

```
no accept-ipaccess
```

#### Parameters

##### no

Negate a command or set its defaults

##### accept-ipaccess

Reject NS Reset PDU on UDP (ip.access style)

---

### 1.17.9 no dscp

#### Command

```
no dscp
```

#### Parameters

no

Set DSCP/TOS on the UDP socket

dscp

DSCP Value

### 1.17.10 no fr NETIF

#### Command

```
no fr NETIF
```

#### Parameters

no

Negate a command or set its defaults

fr

Delete a frame relay link

NETIF

Delete a frame relay link

### 1.17.11 no listen

#### Command

```
no listen
```

#### Parameters

no

Negate a command or set its defaults

listen

Delete a IP/Port assignment

---

### 1.17.12 socket-priority <0-255>

#### Command

```
socket-priority <0-255>
```

#### Parameters

##### socket-priority

Set socket priority on the UDP socket

##### <0-255>

Priority Value (>6 requires CAP\_NET\_ADMIN)

## 1.18 config-ns-nse

### 1.18.1 ip-sns-bind BINDID

#### Command

```
ip-sns-bind BINDID
```

#### Parameters

##### ip-sns-bind

IP SNS binds

##### BINDID

Name of NS udp bind whose IP endpoint will be used as IP-SNS local endpoint. Can be given multiple times.

### 1.18.2 ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

##### ip-sns-remote

SNS Initial Endpoint

##### A.B.C.D

SGSN IPv4 Address

##### X:X::X:X

SGSN IPv6 Address

##### <1-65535>

SGSN UDP Port

---

### 1.18.3 no ip-sns-bind BINDID

#### Command

```
no ip-sns-bind BINDID
```

#### Parameters

no

Negate a command or set its defaults

ip-sns-bind

IP SNS binds

BINDID

Name of NS udp bind whose IP endpoint will not be used as IP-SNS local endpoint

### 1.18.4 no ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
no ip-sns-remote (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

no

Negate a command or set its defaults

ip-sns-remote

Delete a SNS Initial Endpoint

A.B.C.D

SGSN IPv4 Address

X:X::X:X

SGSN IPv6 Address

<1-65535>

SGSN UDP Port

### 1.18.5 no nsvc fr NETIF dlci <16-1007>

#### Command

```
no nsvc fr NETIF dlci <16-1007>
```

#### Parameters

no

Negate a command or set its defaults

nsvc

Delete frame relay NS-VC

fr

frame relay

NETIF

frame relay interface. Must be registered via fr vty

dlci

Data Link connection identifier

<16-1007>

Data Link connection identifier

### 1.18.6 no nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>

Command

```
no nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>
```

Parameters

no

Negate a command or set its defaults

nsvc

Delete a NS Virtual Connection

ipa

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

nsvci

NS Virtual Connection ID (NS-VCI)

<0-65535>

NS Virtual Connection ID (NS-VCI)

### 1.18.7 no nsvc nsvci <0-65535>

#### Command

```
no nsvc nsvci <0-65535>
```

#### Parameters

no

Negate a command or set its defaults

nsvc

Delete NSVC

nsvci

NS Virtual Connection ID (NS-VCI)

<0-65535>

NS Virtual Connection ID (NS-VCI)

### 1.18.8 no nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>

#### Command

```
no nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>
```

#### Parameters

no

Negate a command or set its defaults

nsvc

Delete a NS Virtual Connection

udp

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port



### 1.18.9 nsvc fr NETIF dlci <16-1007> nsvci <0-65535>

#### Command

```
nsvc fr NETIF dlci <16-1007> nsvci <0-65535>
```

#### Parameters

nsvc

NS Virtual Connection

fr

frame relay

NETIF

frame relay interface. Must be registered via fr vty

dlci

NS Virtual Connection ID (NS-VCI)

<16-1007>

NS Virtual Connection ID (NS-VCI)

nsvci

Data Link connection identifier

<0-65535>

Data Link connection identifier

### 1.18.10 nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>

#### Command

```
nsvc ipa BIND (A.B.C.D|X:X::X:X) <1-65535> nsvci <0-65535>
```

#### Parameters

nsvc

NS Virtual Connection

ipa

NS over UDP ip.access style (uses RESET/BLOCK)

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

nsvci

NS Virtual Connection ID (NS-VCI)

<0-65535>

NS Virtual Connection ID (NS-VCI)

### 1.18.11 nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>

Command

```
nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535>
```

Parameters

nsvc

NS Virtual Connection

udp

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

### 1.18.12 nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535> signalling-weight <0-254> data-weight...

Command

```
nsvc udp BIND (A.B.C.D|X:X::X:X) <1-65535> signalling-weight <0-254> data-weight <0-254>
```

Parameters

nsvc

NS Virtual Connection

udp

NS over UDP

BIND

A unique bind identifier created by ns bind

A.B.C.D

Remote IPv4 Address

X:X::X:X

Remote IPv6 Address

<1-65535>

Remote UDP Port

signalling-weight

Signalling weight of the NSVC (default = 1)

<0-254>

Signalling weight of the NSVC (default = 1)

data-weight

Data weight of the NSVC (default = 1)

<0-254>

Data weight of the NSVC (default = 1)

## 1.19 config-sgsn

Configure the remote GGSN, access-control and other attributes of the SGSN

### 1.19.1 access-point-name NAME

Command

```
access-point-name NAME
```

Parameters

access-point-name

Globally allow the given APN name for all subscribers.

NAME

Add this NAME to the list

### 1.19.2 apn APNAME ggsn <0-255>

Command

```
apn APNAME ggsn <0-255>
```

Parameters

apn

Configure the information per APN

APNAME

The APN gateway name optionally prefixed by '\*' (wildcard)

ggsn

Select the GGSN to use for the given APN gateway prefix

<0-255>

The GGSN id

### 1.19.3 apn APNAME imsi-prefix IMSIPRE ggsn <0-255>

#### Command

```
apn APNAME imsi-prefix IMSIPRE ggsn <0-255>
```

#### Parameters

##### apn

Configure the information per APN

##### APNAME

The APN gateway name optionally prefixed by '\*' (wildcard)

##### imsi-prefix

Select the GGSN to use for the given APN gateway prefix if and only if the IMSI matches the given prefix.

##### IMSIPRE

An IMSI prefix

##### ggsn

Select the GGSN to use when APN gateway and IMSI prefix match

##### <0-255>

The GGSN id

### 1.19.4 asn1 debug (1|0)

#### Command

```
asn1 debug (1|0)
```

#### Parameters

##### asn1

ASN.1 settings

##### debug

Enable ASN.1 debug messages

##### 1

Log ASN.1 debug messages to stderr

##### 0

Do not log ASN.1 debug messages to stderr

### 1.19.5 asn1 xer-print (1|0)

#### Command

```
asn1 xer-print (1|0)
```

#### Parameters

##### asn1

ASN.1 settings

##### xer-print

Log human readable representations of all ASN.1 messages to stderr

1

Log XML representation of all ASN.1 messages to stderr

0

Do not log decoded ASN.1 messages to stderr

### 1.19.6 auth-policy (accept-all|closed|acl-only|remote)

#### Command

```
auth-policy (accept-all|closed|acl-only|remote)
```

#### Parameters

##### auth-policy

Configure the Authorization policy of the SGSN. This setting determines which subscribers are permitted to register to the network.

##### accept-all

Accept all IMSIs (DANGEROUS)

##### closed

Accept only home network subscribers or those in the ACL

##### acl-only

Accept only subscribers in the ACL

##### remote

Use remote subscription data only (HLR)

### 1.19.7 authentication (optional|required)

#### Command

```
authentication (optional|required)
```

#### Parameters

##### authentication

Whether to enforce MS authentication in GERAN (only with auth-policy remote)

##### optional

Allow MS to attach via GERAN without authentication (default and only possible value for non-remote auth-policy)

##### required

Always require authentication (only available for auth-policy remote, default with that auth-policy)

### 1.19.8 cdr filename NAME

#### Command

```
cdr filename NAME
```

#### Parameters

##### cdr

CDR

##### filename

Set the file name for the call-data-record file, logging the data usage of each subscriber.

##### NAME

filename

### 1.19.9 cdr interval <1-2147483647>

#### Command

```
cdr interval <1-2147483647>
```

#### Parameters

##### cdr

CDR

##### interval

Set the interval for the call-data-record file

##### <1-2147483647>

interval in seconds

---

### 1.19.10 cdr trap

#### Command

```
cdr trap
```

#### Parameters

cdr

CDR

trap

Enable sending CDR via TRAP CTRL messages

### 1.19.11 compression rfc1144 active slots <1-256>

#### Command

```
compression rfc1144 active slots <1-256>
```

#### Parameters

compression

Configure compression

rfc1144

RFC1144 Header compression scheme

active

Compression is actively proposed

slots

Number of compression state slots

<1-256>

Number of compression state slots

### 1.19.12 compression rfc1144 passive

#### Command

```
compression rfc1144 passive
```

#### Parameters

compression

Configure compression

rfc1144

RFC1144 Header compression scheme

passive

Compression is available on request

### 1.19.13 compression v42bis active direction (ms|sgsn|both) codewords <512-65535> strlen ...

#### Command

```
compression v42bis active direction (ms|sgsn|both) codewords <512-65535> strlen <6-250>
```

#### Parameters

##### compression

Configure compression

##### v42bis

V.42bis data compression scheme

##### active

Compression is actively proposed

##### direction

Direction in which the compression shall be active (p0)

##### ms

Compress ms->sgsn direction only

##### sgsn

Compress sgsn->ms direction only

##### both

Both directions

##### codewords

Number of codewords (p1)

##### <512-65535>

Number of codewords

##### strlen

Maximum string length (p2)

##### <6-250>

Maximum string length

### 1.19.14 compression v42bis passive

#### Command

```
compression v42bis passive
```

#### Parameters

##### compression

Configure compression

##### v42bis

V.42bis data compression scheme

##### passive

Compression is available on request



### 1.19.15 cs7-instance-iu <0-15>

#### Command

```
cs7-instance-iu <0-15>
```

#### Parameters

##### cs7-instance-iu

Set SS7 to be used by the Iu-Interface.

##### <0-15>

SS7 instance reference number (default: 0)

### 1.19.16 encryption cipher-plugin-path PATH

#### Command

```
encryption cipher-plugin-path PATH
```

#### Parameters

##### encryption

Set encryption algorithms for SGSN

##### cipher-plugin-path

Path to gprs encryption cipher plugin directory

##### PATH

Plugin path

### 1.19.17 encryption gea <0-4> [<0-4>] [<0-4>] [<0-4>] [<0-4>]

#### Command

```
encryption gea <0-4> [<0-4>] [<0-4>] [<0-4>] [<0-4>]
```

#### Parameters

##### encryption

Set encryption algorithms for SGSN

##### gea

GPRS Encryption Algorithm

##### <0-4>

GEAn Algorithm Number

##### [<0-4>]

GEAn Algorithm Number

---

[<0-4>]

GEAn Algorithm Number

[<0-4>]

GEAn Algorithm Number

[<0-4>]

GEAn Algorithm Number

### 1.19.18 encryption uea <0-2> [<0-2>] [<0-2>]

Command

```
encryption uea <0-2> [<0-2>] [<0-2>]
```

Parameters

encryption

Set encryption algorithms for SGSN

uea

UTRAN (3G) encryption algorithms to allow: 0 = UEA0 (no encryption), 1 = UEA1, 2 = UEA2.

<0-2>

UEAn Algorithm Number

[<0-2>]

UEAn Algorithm Number

[<0-2>]

UEAn Algorithm Number

### 1.19.19 ggsn <0-255> echo-interval <1-36000>

Command

```
ggsn <0-255> echo-interval <1-36000>
```

Parameters

ggsn

Configure the GGSN information

<0-255>

GGSN Number

echo-interval

Send an echo request to this static GGSN every interval.

<1-36000>

Interval between echo requests in seconds.

---

### 1.19.20 ggsn <0-255> gtp-version (0|1)

#### Command

```
ggsn <0-255> gtp-version (0|1)
```

#### Parameters

##### ggsn

Configure the GGSN information

##### <0-255>

GGSN Number

##### gtp-version

GTP Version

##### 0

Version 0

##### 1

Version 1

### 1.19.21 ggsn <0-255> no echo-interval

#### Command

```
ggsn <0-255> no echo-interval
```

#### Parameters

##### ggsn

Configure the GGSN information

##### <0-255>

GGSN Number

##### no

Negate a command or set its defaults

##### echo-interval

Send an echo request to this static GGSN every interval.

### 1.19.22 ggsn <0-255> remote-ip A.B.C.D

#### Command

```
ggsn <0-255> remote-ip A.B.C.D
```

#### Parameters

---

ggsn

Configure the GGSN information

<0-255>

GGSN Number

remote-ip

Configure this static GGSN to use the specified remote IP address.

A.B.C.D

IPv4 Address

### 1.19.23 ggsn dynamic

Command

```
ggsn dynamic
```

Parameters

ggsn

Configure the GGSN information

dynamic

Enable dynamic resolving of GGSNs based on DNS resolving the APN name like in a GRX-style setup. Changing this setting requires a restart.

### 1.19.24 grx-dns-add A.B.C.D

Command

```
grx-dns-add A.B.C.D
```

Parameters

grx-dns-add

Use the specified IP address for DNS-resolving the AP names to GGSN IP addresses

A.B.C.D

IPv4 address

### 1.19.25 gsup ipa-name NAME

Command

```
gsup ipa-name NAME
```

Parameters

---

gsup

GSUP Parameters

ipa-name

Set the IPA name of this SGSN

NAME

A unique name for this SGSN. For example: PLMN + redundancy server number: SGSN-901-70-0. This name is used for GSUP routing and must be set if more than one SGSN is connected to the network. The default is 'SGSN-00-00-00-00-00-00'.

### 1.19.26 gsup oap-id <0-65535>

Command

```
gsup oap-id <0-65535>
```

Parameters

gsup

GSUP Parameters

oap-id

Set the OAP client ID for authentication on the GSUP protocol. This setting only applies if 'auth-policy remote' is used.

<0-65535>

OAP client ID (0 == disabled)

### 1.19.27 gsup oap-k K

Command

```
gsup oap-k K
```

Parameters

gsup

GSUP Parameters

oap-k

Set the OAP shared secret key K for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

K

K value (16 byte) hex

---

### 1.19.28 gsup oap-opc OPC

#### Command

```
gsup oap-opc OPC
```

#### Parameters

gsup

GSUP Parameters

oap-opc

Set the OAP shared secret OPC for authentication on the GSUP protocol. This setting only applies if auth-policy remote is used.

OPC

OPC value (16 byte) hex

### 1.19.29 gsup remote-ip A.B.C.D

#### Command

```
gsup remote-ip A.B.C.D
```

#### Parameters

gsup

GSUP Parameters

remote-ip

Set the IP address of the remote GSUP server (e.g. OsmoHLR). This setting only applies if 'auth-policy remote' is used.

A.B.C.D

IPv4 Address

### 1.19.30 gsup remote-port <0-65535>

#### Command

```
gsup remote-port <0-65535>
```

#### Parameters

gsup

GSUP Parameters

remote-port

Set the TCP port of the remote GSUP server, see also 'gsup remote-ip'

<0-65535>

Remote TCP port

---

### 1.19.31 gtp local-ip A.B.C.D

#### Command

```
gtp local-ip A.B.C.D
```

#### Parameters

##### gtp

GTP Parameters

##### local-ip

Set the IP address for the local GTP bind for the Gp interface (towards the GGSNs). Note: in case you would like to run the GGSN on the same machine as the SGSN, you can not run both on the same IP address, since both sides are specified to use the same GTP port numbers (2123 and 2152). For example, you could use 127.0.0.1 for the SGSN and 127.0.0.2 for the GGSN in such situations.

##### A.B.C.D

IPv4 Address

### 1.19.32 gtp state-dir PATH

#### Command

```
gtp state-dir PATH
```

#### Parameters

##### gtp

GTP Parameters

##### state-dir

Set the directory for the GTP State file

##### PATH

Local Directory

### 1.19.33 imsi-acl (add|del) IMSI

#### Command

```
imsi-acl (add|del) IMSI
```

#### Parameters

##### imsi-acl

Access Control List of foreign IMSIs

##### add

Add IMSI to ACL

##### del

Remove IMSI from ACL

##### IMSI

IMSI of subscriber

---

### 1.19.34 **iu rab-assign-addr-enc (x213|v4raw)**

#### Command

```
iu rab-assign-addr-enc (x213|v4raw)
```

#### Parameters

iu

Iu interface protocol options

rab-assign-addr-enc

Choose RAB Assignment's Transport Layer Address encoding

x213

ITU-T X.213 compliant address encoding (default)

v4raw

32bit length raw IPv4 address (for ip.access nano3G)

### 1.19.35 **mme NAME**

#### Command

```
mme NAME
```

#### Parameters

mme

Configure an MME peer

NAME

Name identifying the MME peer

### 1.19.36 **no access-point-name NAME**

#### Command

```
no access-point-name NAME
```

#### Parameters

no

Negate a command or set its defaults

access-point-name

Configure a global list of allowed APNs

NAME

Remove entry with NAME

---



### 1.19.37 no cdr filename

#### Command

```
no cdr filename
```

#### Parameters

no

Negate a command or set its defaults

cdr

CDR

filename

Disable saving CDR to file

### 1.19.38 no cdr trap

#### Command

```
no cdr trap
```

#### Parameters

no

Negate a command or set its defaults

cdr

CDR

trap

Disable sending CDR via TRAP CTRL messages

### 1.19.39 no compression rfc1144

#### Command

```
no compression rfc1144
```

#### Parameters

no

Negate a command or set its defaults

compression

Configure compression

rfc1144

disable rfc1144 TCP/IP header compression

---

### 1.19.40 no compression v42bis

#### Command

```
no compression v42bis
```

#### Parameters

no

Negate a command or set its defaults

compression

Configure compression

v42bis

disable V.42bis data compression

### 1.19.41 no encryption cipher-plugin-path PATH

#### Command

```
no encryption cipher-plugin-path PATH
```

#### Parameters

no

Negate a command or set its defaults

encryption

Set encryption algorithms for SGSN

cipher-plugin-path

Path to gprs encryption cipher plugin directory

PATH

Plugin path

### 1.19.42 no mme NAME

#### Command

```
no mme NAME
```

#### Parameters

no

Negate a command or set its defaults

mme

Delete an MME peer configuration

NAME

Name identifying the MME peer

---

### 1.19.43 timer [TNNNN] [(**<0-2147483647>**|default)]

#### Command

```
timer [TNNNN] [(<0-2147483647>|default)]
```

#### Parameters

##### timer

Configure or show timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

##### [<0-2147483647>]

New timer value

##### [default]

Set to default timer value

### 1.19.44 timer gtp [TNNNN] [(**<0-2147483647>**|default)]

#### Command

```
timer gtp [TNNNN] [(<0-2147483647>|default)]
```

#### Parameters

##### timer

Configure or show timers

##### gtp

GTP (libgtp) timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

##### [<0-2147483647>]

New timer value

##### [default]

Set to default timer value

## 1.20 config-sgsn-mme

### 1.20.1 gtp ran-info-relay <0-999> <0-999> <0-65535>

Command

```
gtp ran-info-relay <0-999> <0-999> <0-65535>
```

Parameters

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

<0-999>

MCC

<0-999>

MNC

<0-65535>

TAC

### 1.20.2 gtp ran-info-relay default

Command

```
gtp ran-info-relay default
```

Parameters

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

default

Set as default route

### 1.20.3 gtp remote-ip A.B.C.D

Command

```
gtp remote-ip A.B.C.D
```

Parameters

---

gtp

Configure GTP connection

remote-ip

Set Remote GTP IP address

A.B.C.D

IP information

#### 1.20.4 gummei <0-999> <0-999> <0-65535> <0-254>

Command

```
gummei <0-999> <0-999> <0-65535> <0-254>
```

Parameters

gummei

Configure the mme

<0-999>

MCC

<0-999>

MNC

<0-65535>

MME GroupId

<0-254>

MME Code

#### 1.20.5 no gtp ran-info-relay <0-999> <0-999> <0-65535>

Command

```
no gtp ran-info-relay <0-999> <0-999> <0-65535>
```

Parameters

no

Negate a command or set its defaults

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

<0-999>

MCC

<0-999>

MNC

<0-65535>

TAC

### 1.20.6 no gtp ran-info-relay default

#### Command

```
no gtp ran-info-relay default
```

#### Parameters

no

Negate a command or set its defaults

gtp

Configure GTP connection

ran-info-relay

Configure RAN Information Relay routing

default

Set as default route

### 1.20.7 no gummei

#### Command

```
no gummei
```

#### Parameters

no

Negate a command or set its defaults

gummei

Remove gummei